

Basic Blade Services Software on ATCA-7367

Programmer's Reference

P/N: 6806800K69F

June 2014



© Copyright 2014 Artesyn Embedded Technologies, Inc.

All rights reserved.

Trademarks

Artesyn Embedded Technologies, Artesyn and the Artesyn Embedded Technologies logo are trademarks and service marks of Artesyn Embedded Technologies, Inc. © 2014 Artesyn Embedded Technologies, Inc. All other product or service names are the property of their respective owners.

Intel® is a trademark or registered trademark of Intel Corporation or its subsidiaries in the United States and other countries.

Java™ and all other Java-based marks are trademarks or registered trademarks of Oracle America, Inc. in the U.S. and other countries.

Microsoft®, Windows® and Windows Me® are registered trademarks of Microsoft Corporation; and Windows XP™ is a trademark of Microsoft Corporation.

PICMG®, CompactPCI®, AdvancedTCA™ and the PICMG, CompactPCI and AdvancedTCA logos are registered trademarks of the PCI Industrial Computer Manufacturers Group.

UNIX® is a registered trademark of The Open Group in the United States and other countries.

Notice

While reasonable efforts have been made to assure the accuracy of this document, Artesyn assumes no liability resulting from any omissions in this document, or from the use of the information obtained therein. Artesyn reserves the right to revise this document and to make changes from time to time in the content hereof without obligation of Artesyn to notify any person of such revision or changes.

Electronic versions of this material may be read online, downloaded for personal use, or referenced in another document as a URL to an Artesyn website. The text itself may not be published commercially in print or electronic form, edited, translated, or otherwise altered without the permission of Artesyn.

It is possible that this publication may contain reference to or information about Artesyn products (machines and programs), programming, or services that are not available in your country. Such references or information must not be construed to mean that Artesyn intends to announce such Artesyn products, programming, or services in your country.

Limited and Restricted Rights Legend

If the documentation contained herein is supplied, directly or indirectly, to the U.S. Government, the following notice shall apply unless otherwise agreed to in writing by Artesyn.

Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data clause at DFARS 252.227-7013 (Nov. 1995) and of the Rights in Noncommercial Computer Software and Documentation clause at DFARS 252.227-7014 (Jun. 1995).

Contact Address

Artesyn Embedded Technologies
Marketing Communications
2900 S. Diablo Way, Suite 190
Tempe, Arizona 85282

Artesyn Embedded Technologies
Lilienthalstr. 17-19
85579 Neubiberg/Munich
Germany

Contents

About this Manual	13
1 Introduction	19
1.1 Overview	19
1.2 Software Building Blocks	19
2 Installing the Basic Blade Services Software	23
2.1 Overview	23
2.1.1 Installation Scripts	24
2.1.2 Package Information	25
2.1.3 Accessing the ATCA-7367 via Serial Console	27
2.2 Configuring TFTP, DHCP and PXE	27
2.2.1 Create /tftpboot Directory and Copy Target Files	28
2.2.2 Configuring a TFTP Server	28
2.2.3 Configuring DHCP	29
2.2.4 Configuring PXE	31
2.3 Installation Procedures	32
2.3.1 Configuring ATCA-7367 for Diskless Client Boot of the BBS Software	33
2.3.2 Installing BBS Software on Hard Disk Drive	34
2.3.3 Installing BBS Software on On-Board USB Disk	38
2.4 Upgrading the Software	40
2.5 Adapting the BBS Software to Customer's Needs	40
2.5.1 Modifying the NetBoot Root File System	40
2.5.2 Modifying Hard Disk Installation	41
2.5.3 Modifying the Hard Disk Installation Procedure	41
2.5.4 Modifying the Configuration of the Artesyn-Supplied PNE Linux Kernel	42
3 Linux Distribution Description	43
3.1 Distribution Description	43
3.2 Reliability	43
3.3 Login	43
3.4 Long POST/Diagnostics	44
3.4.1 Default Test Routines	44
3.4.2 Configuring the Long POST Behavior	45

3.5	Linux Services Initialization	46
3.5.1	RC Scripts	47
3.6	Network Services Configuration	47
3.6.1	ATCA-7367 Ethernet Interfaces	47
3.7	Tools	49
3.7.1	Performance Tool	50
3.7.2	IPMIBPAR	52
4	Firmware Upgrade Facility	55
4.1	Overview	55
4.2	Firmware Recovery Image Files	55
4.3	Backup Concept	56
4.4	fcu—Firmware Upgrade Command-Line Utility	61
4.5	Upgrading a Firmware Image	65
4.5.1	BIOS Upgrade	66
4.5.2	IPMC Upgrade	68
4.5.3	FPGA Upgrade	70
5	Hardware Platform Management	73
5.1	Overview	73
5.2	hpmagentd—HPM Agent Daemon	74
5.3	hpm—Start-Up Script	76
5.4	hpm—Shutdown and Reboot Scripts	77
5.5	hpmcmd—HPM Command Utility	78
5.5.1	Command Overview	80
5.5.2	Supported Commands	82
5.5.2.1	bye	83
5.5.2.2	bootbankget	83
5.5.2.3	bootbankset	84
5.5.2.4	bootparamerase	84
5.5.2.5	bootparamget	85
5.5.2.6	bootparamset	86
5.5.2.7	chinfo	87
5.5.2.8	cmd	88

5.5.2.9	deviceid	89
5.5.2.10	exit	90
5.5.2.11	frudata	90
5.5.2.12	fruinfoget	91
5.5.2.13	fruinv	92
5.5.2.14	fruread	92
5.5.2.15	fruwrite	93
5.5.2.16	help	94
5.5.2.17	ipmbaddress	94
5.5.2.18	ipmcdevice	94
5.5.2.19	ipmcstatus	94
5.5.2.20	ledget	95
5.5.2.21	ledprop	96
5.5.2.22	ledset	96
5.5.2.23	loglevelget	98
5.5.2.24	loglevelset	98
5.5.2.25	macaddress	99
5.5.2.26	motshelftype	99
5.5.2.27	partnumber	100
5.5.2.28	physlotnumber	100
5.5.2.29	portget	100
5.5.2.30	portset	102
5.5.2.31	quit	103
5.5.2.32	rebootpath	104
5.5.2.33	sdr	104
5.5.2.34	sdr_dump	105
5.5.2.35	sendcmd	105
5.5.2.36	sdrinfo	106
5.5.2.37	shelfaddress	106
5.5.2.38	shelfslots	107
5.5.2.39	shutdownpath	107
5.5.2.40	slotmap	108
5.5.2.41	slotnumber	108
5.5.2.42	solcfgget	108
5.5.2.43	solcfgset	109
5.5.2.44	upgrade	110

5.5.2.45 version	111
5.5.2.46 watchdog	111

6 Link Health Check 113

6.1 Overview	113
6.2 LHC MIB	113
6.2.1 Browsing the LHC MIB	114
6.2.2 Enabling SNMP Access to the LHC MIB	114
6.3 lhcd—LHC Daemon	114
6.4 lhc—lhcd Start-Stop Script	116
6.5 lhc—LHC Command Line Utility	118
6.5.1 Command Overview	119
6.5.2 Command Usage for Common Parameters	120
6.5.3 Available Commands	121
6.5.3.1 exit q quit	121
6.5.3.2 get	122
6.5.3.3 help	122
6.5.3.4 index	122
6.5.3.5 loglevel	123
6.5.3.6 next	124
6.5.3.7 objects	125
6.5.3.8 set	125
6.5.3.9 tables	126
6.5.3.10 values	126
6.5.3.11 version	127
6.5.3.12 walk	127
6.6 LHC Configuration Script and Configuration File	128
6.7 LHC Fault Management	128
6.7.1 Determining to Change Active Network Plane	128
6.7.2 Controlling the Active Network Plane	129
6.7.3 Monitoring for Changes to the Active Network Plane	129
6.7.4 Fault Management Notifications	130
6.8 LHC Configuration Examples	133
6.8.1 Proctor Configuration Examples	133
6.8.2 Responder Configuration Examples	135

6.8.3	Baseboard Processor on Carrier Blade Configuration Example	136
6.8.4	AMC/PMC Module on Carrier Blade Configuration Example.....	138
6.8.5	Leaky Bucket Description and Configuration Example	139
7	HPI-B Software	141
7.1	Overview	141
8	Board Control Module	143
8.1	Overview	143
8.2	Board Control Tool	145
8.2.1	LEDCTRL	145
8.2.2	FPGA_TEST.....	145
9	Clock Agent Command Module	147
9.1	Overview	147
9.2	clkcmd	147
9.2.1	Enable Clock Buffer	149
9.2.2	Enable Clock Routing Mode	150
9.2.3	Automatic Configuration.....	150
9.2.4	LCCB Mode.....	151
9.2.5	Reference Clock Selection.....	152
9.2.6	System Clock Selection	152
9.2.7	Get Status.....	154
9.2.8	List Entity	155
9.2.9	LCCB Default Configuration	155
9.2.10	Set LCCB Output Clock.....	156
9.2.11	LCCB Status Daemon	157
9.2.12	Verbose Output and Status Information	159
9.2.13	Example	159
10	Kernel and Root File System Config using PNE 3.0	161
10.1	Building Kernel and Root File System	161
10.1.1	Prerequisites	161

10.1.2	Additional Kernel Patches	162
10.1.3	Project Setup	162
10.1.3.1	Project Configure Script	163
10.1.3.2	Using Wind River Work Bench for PNE3.0	164
10.1.4	Kernel Configuration	166
10.1.5	Root File System Configuration	166
10.1.6	Making BBS modules	167
10.1.7	Getting Root File System and RAMDISK Image	167
11	Ethernet Controller Five Tuple Filter Utility	171
11.1	Introduction	171
11.2	Multi-queue Ethernet Controllers in ATCA-7367	171
11.2.1	Multi-queue of Intel 82599EB	171
11.2.2	Multi-queue of Intel 82576	172
11.2.3	Queue's MSI-X Interrupt Affinity with CPU Core	173
11.3	L3/L4 Five Tuple Filter Introduction	174
11.4	Utility Usage	175
11.4.1	Using ethtuple	175
11.5	CPU Core Affinity with Application Programs	179
A	Installing and Configuring BBS	181
A.1	Installing BBS Using Hard Disk	181
A.2	Setting up the Kdump Utility on a Hard Disk Driver Installed System	187
B	Related Documentation	199
B.1	Artesyn Embedded Technologies - Embedded Computing Documentation	199
B.2	Related Specifications	200
B.3	Additional Resources	200

List of Tables

Table 2-1	BBS Installation/Boot Options - Main Set-Up and Configuration Steps	23
Table 2-2	Installation Scripts	24
Table 2-3	BBS Distribution Packages	25
Table 3-1	Long POST Standard Test Routines - Generated IPMI Data	44
Table 3-2	Long POST Default Test Routines	44
Table 3-3	Long POST Script LPmain.sh - Options	46
Table 3-4	Generic Linux Run Levels	46
Table 5-1	Command Overview	80
Table 9-1	Clock commands and options	147
Table 9-2	Clock commands and options, for LCCB only	148
Table 9-3	Routing mode ids	150
Table 9-4	LCCB mode id	151
Table 9-5	Reference and source clock ids	152
Table 9-6	System clock id	153
Table 9-7	Options for the get status command	154
Table 9-8	LCCB output clock id	156
Table 10-1	ATCA-7367 specific kernel patches	162
Table 11-1	ethtuple parameters	176
Table A-1	Supported filtering levels	189
Table B-1	Artesyn Embedded Technologies - Embedded Computing Publications	199
Table B-2	Related Specifications	200
Table B-3	Additional Resources	200

List of Figures

Figure 1-1	BBS Architecture	20
Figure 5-1	Software Levels of the HPM Architecture	74
Figure 11-1	Intel 82599EB multi-queue	172
Figure 11-2	Overview of Affinity Status	174
Figure 11-3	Rx Queue Assignment	175
Figure 11-4	Binding Relationship	180

About this Manual

Overview of Contents

This manual is divided into the following chapters and appendices.

- [Chapter 1, *Introduction*, on page 19](#)
- [Chapter 2, *Installing the Basic Blade Services Software*, on page 23](#)
- [Chapter 3, *Linux Distribution Description*, on page 43](#)
- [Chapter 4, *Firmware Upgrade Facility*, on page 55](#)
- [Chapter 5, *Hardware Platform Management*, on page 73](#)
- [Chapter 6, *Link Health Check*, on page 113](#)
- [Chapter 7, *HPI-B Software*, on page 141](#)
- [Chapter 8, *Board Control Module*, on page 143](#)
- [Chapter 9, *Clock Agent Command Module*, on page 147](#)
- [Chapter 10, *Kernel and Root File System Config using PNE 3.0*, on page 161](#)
- [Chapter 11, *Ethernet Controller Five Tuple Filter Utility*, on page 171](#)
- [Appendix A, *Installing and Configuring BBS*, on page 181](#)
- [Appendix B, *Related Documentation*, on page 199](#)

Abbreviations

This document uses the following abbreviations:

Abbreviation	Definition
API	Application Programming Interface
AdvancedTCA	Advanced Telecommunications Computing Architecture
ATCA	Advanced Telecommunications Computing Architecture
BBS	Basic Blade Services
BIOS	Basic Input Output System
CGL	Carrier Grade Linux




Abbreviation	Definition
CPU	Central Processing Unit
DHCP	Dynamic Host Configuration Protocol
ECC	Embedded Communications Computing
FCU	FUF Command Line Utility
FM	Fault Management
FPGA	Field Programmable Gate Array
FRI	Firmware Recovery Image
FRU	Field Replaceable Unit
FUF	Firmware Upgrade Facility
FWH	Firmware Hub
GPIO	General Purpose Input/Output
HPI	Hardware Platform Interface
HPM	Hardware Platform Management
I/O	Input Output
IP	Internet Protocol
IPM	Intelligent Platform Management
IPMB	Intelligent Platform Management Bus
IPMC	Intelligent Platform Management Controller
IPMI	Intelligent Platform Management Interface
LED	Light Emitting Diode
LHC	Link Health Check
LSP	Linux Support Package
LUN	Logic Unit Number
MAC	Media Access Control
MIB	Management Information Base
MSI-X	Message Signaled Interrupt
NTP	Network Time Protocol
OEM	Original Equipment Manufacturer

Abbreviation	Definition
OSDL	Open Source Development Labs
PC	Personal Computer
PCI	Peripheral Component Interconnect
PCIx	PCI Express
PICMG	PCI Industrial Computers Manufacturers Group
PXE	Preboot Execution Environment
RAM	Random Access Memory
ROM	Read Only Memory
RPM	RedHat Package Manager
RSS	Receive-Side Scaling
RTM	Rear Transition Module
SAF	Service Availability Forum
SAS	Serial Attached SCSI
SATA	Serial ATA
SCSI	Small Computer System Interface
SDR	Sensor Data Record
SMI	Serial Management Interface
SNMP	Simple Network Management Protocol
SSD	Solid State Disk
SSH	Secure Shell
SSU	Synchronization Supply Unit
TAR	Tape Archive
TCP	Transmission Control Protocol
TFTP	Trivial File Transfer Protocol
UDP	User Datagram Protocol
USB	Universal Serial Bus

Conventions

The following table describes the conventions used throughout this manual.

Notation	Description
0x00000000	Typical notation for hexadecimal numbers (digits are 0 through F), for example used for addresses and offsets
0b0000	Same for binary numbers (digits are 0 and 1)
bold	Used to emphasize a word
Screen	Used for on-screen output and code related elements or commands in body text
Courier + Bold	Used to characterize user input and to separate it from system output
<i>Reference</i>	Used for references and for table and figure descriptions
File > Exit	Notation for selecting a submenu
<text>	Notation for variables and keys
[text]	Notation for software buttons to click on the screen and parameter description
...	Repeated item for example node 1, node 2, ..., node 12
.	Omission of information from example/command that is not necessary at the time being
..	Ranges, for example: 0..4 means one of the integers 0,1,2,3, and 4 (used in registers)
	Logical OR

Notation	Description
 <div style="background-color: orange; padding: 5px;">⚠ WARNING xxx xxx xxx</div>	Indicates a hazardous situation which, if not avoided, could result in death or serious injury
 <div style="background-color: yellow; padding: 5px;">⚡ CAUTION xxx xxx xxx</div>	Indicates a hazardous situation which, if not avoided, may result in minor or moderate injury
<div style="background-color: blue; color: white; padding: 5px;">NOTICE</div> <div style="padding: 5px;">xxx xxx xxx</div>	Indicates a property damage message
 <div style="border-top: 1px dashed black; height: 40px;"></div>	No danger encountered. Pay attention to important information

Summary of Changes

See the table below for manual revisions and changes.

Part Number	Date	Description
6806800K69A	June 2010	Initial release
6806800K69B	September 2010	Corrected Table 2-3 . Updated Firmware Recovery Image Files on page 55.
6806800K69C	March 2011	Added Chapter 11, Ethernet Controller Five Tuple Filter Utility , on page 171. Added Setting up the Kdump Utility on a Hard Disk Driver Installed System on page 187.
6806800K69D	August 2011	Updated file names in Firmware Recovery Image Files on page 55 and IPMC Upgrade on page 68.
6806800K69E	March 2013	Updated tables in Firmware Recovery Image Files on page 55 and ATCA-7367 Ethernet Interfaces on page 47.
6806800K69F	June 2014	Re-branded to Artesyn.

Introduction

1.1 Overview

This manual is applicable to part number: SA-BBS-WR30-7367.

The Basic Blades Services (BBS) software provides a set of services that support the blade on which the software is installed. BBS includes:


- Several custom hardware management functions for the unique hardware of the blade.
- A set of management routines for Linux and all hardware interfaces. Management access includes support for SNMP and a local console interface based on a standard Linux command shell.
- HPI-B
This release contains an RPM which contains all files necessary for developing HPI-B applications. For further information refer to the *System Management Interface Based on HPI-B (Centellis 2000/4440) User's Guide*.

1.2 Software Building Blocks

BBS services include a common set of functionality which is available for all AdvancedTCA blades and a unique set of functionality which is tailored to a particular blade.

Figure 1-1 depicts the architecture of the BBS software.

Figure 1-1 BBS Architecture



HPM: Hardware Platform Management

FUF: Firmware Upgrade Facility

SNMP: Simple Network Management Protocol

IPMC: Intelligent Peripheral Management Controller

HPI-B: Hardware Platform Interface (Version B)

LHC: Link Health Check

BBS for the ATCA-7367 consists of the following main software and services:

- Firmware Upgrade Facility**
 The Firmware Upgrade Facility (FUF) provides a uniform way to upgrade firmware on Artesyn blades, regardless on which flash locations the firmware is stored. FUF upgrades the BIOS firmware as well as the IPMC firmware (via HPM agent). The FUF currently consists of a Firmware Upgrade Command Line Utility (FCU), flash device drivers, and specially prepared firmware recovery image files. The FUF can be used on switch and node blades.
- Linux Operating System**
 Wind River Enterprise Linux 3.0 (Carrier Grade Linux) is the operating system for BBS blades and modules. The operating system comes with kernel 2.6.27. Various Linux services (above the kernel) will be activated by the BBS installation scripts.
- Hardware Platform Management**
 Hardware Platform Management (HPM) in AdvancedTCA systems is based on Intelligent Platform Management Interface specification (IPMI). IPMI commands can be complex and cumbersome. Using a certain set of commands, HPM facilitates the blade or module-level hardware management.

- **SNMP Agent**
As each BBS blade is individually managed, the default installation script installs and initializes the "Net-SNMP" agent.
- **HPI-B**
This release contains an RPM which contains all files necessary for developing HPI-B applications. For further information refer to the *System Management Interface Based on HPI-B (Centellis 2000/4440) User's Guide*.
- **Clock agent package**
The clock agent package supports configuration and operation of the telecom clock functionality on the ATCA-7367 board.
- **Link Health Check**
The Link Health Check (LHC) supports the configuration and operation of the LHC protocol. LHC performs the verification of Layer 2 connectivity and the distribution of the active network plane.

Installing the Basic Blade Services Software

2.1 Overview

Artesyn provides software images, including software updates, to its licensed customers. In order to obtain the latest BBS software versions, contact your local sales representative.

Generally, there are three typical ways of installing/booting the BBS software on ATCA-7367:

- Diskless client boot via network
- Installation and booting from SATA/SAS hard disk
- Installation and booting from on-board USB disk



On ATCA-7367 the SAS-HDD and SATA-HDD can reside in the AMC Bay or RTM when RTM-ATCA-7360-X installed. AMC Bay also supports SATA-HDD AMC without the installation of any RTMs. As an option a Solid State Disk (SSD) with SATA interface (SATA cube) can be placed on the front board.

For all these options you need to set up an external TFTP server to retrieve the required BBS files. Furthermore you need to do some initial configurations. [Table 2-1](#) provides an overview of the main steps you need to take for the three installation/boot options. The detailed procedures can be found in the following sections.

Table 2-1 BBS Installation/Boot Options - Main Set-Up and Configuration Steps

Installation/Boot Option	Main Set-Up and Configuration Steps
Diskless client boot. Refer Configuring ATCA-7367 for Diskless Client Boot of the BBS Software on page 33 .	<ol style="list-style-type: none"> 1. Set up and configure external TFTP boot server 2. Configure DHCP server 3. Configure PXE boot options 4. Configure ATCA-7367 BIOS to boot from network
Installation and booting from SATA/SAS hard disk. The hard disk can be located on the RTM or locally (as SATA cube) on the front board. Refer Installing BBS Software on Hard Disk Drive on page 34 .	<ol style="list-style-type: none"> 1. Set up and configure external TFTP boot server 2. Configure DHCP server 3. Configure PXE boot options 4. Configure ATCA-7367 BIOS for network boot 5. Boot BBS initrd image 6. Install BBS image on hard disk (via install script) 7. Configure ATCA-7367 BIOS to boot from hard disk

Table 2-1 BBS Installation/Boot Options - Main Set-Up and Configuration Steps (continued)

Installation/Boot Option	Main Set-Up and Configuration Steps
Installation and booting from on-board USB flash. Refer Installing BBS Software on On-Board USB Disk on page 38 .	<ol style="list-style-type: none"> 1. Set up and configure external TFTP boot server 2. Configure DHCP server 3. Configure PXE boot options 4. Configure ATCA-7367 BIOS for network boot 5. Boot BBS initrd image 6. Install BBS image on USB flash (via install script) 7. Configure ATCA-7367 BIOS to boot from USB flash

For more information about the rpm command, see its `man` page.

2.1.1 Installation Scripts

The following table describes the installation scripts required for installing the operating system and blade utilities for ATCA-7367. These installation scripts require a TFTP and a DHCP server to download the installation files.

Table 2-2 Installation Scripts

	linuxrc	flashrfsrc	flashrc
Installed packages	Kernel, RFS and additional packages	Kernel, RFS and additional packages	Kernel, Ramdisk (including BBS packages)
Features	Enhanced partition layout, SMART-/Timezone and NTP configuration, Autoconfig	Simple partition layout and autoconfig	Timezone-/NTP configuration
Suitable for devices	HDD, SSD > 30 GB	HDD, SSD or on-board USB flash	On-board USB flash or USB stick

2.1.2 Package Information

BBS software is packaged with the Red Hat Package Manager (RPM) and is installed as part of the standard installation. In general, you will not need to install or upgrade an individual package.

The BBS distribution contains the following packages.

Table 2-3 BBS Distribution Packages

Description	File Name
Operating System Kernel (Kernel version 2.6.27)	kernel
Ramdisk image for netboot	ramdisk.image.gz
Hard Disk Installation	
Root file system for hard disk installation	rootfs.tar.gz
Kernel command line	default.bbs-atca7367
Check sum of all files and RPMs	files.shalsum
BIOS package	bbs-cpu-atca7367-<version>.rpm
IPMI firmware package (front blade)	bbs-ipmc-atca7367-amc-poped-<version>.rpm bbs-ipmc-atca7367-amc-no-poped-<version>.rpm bbs-ipmc-atca7367-c01-<version>.rpm
IPMI booter package (front blade)	bbs-ipmc-amc-poped-boot-atca7367-<version>.rpm bbs-ipmc-amc-nopoped-boot-atca7367-<version>.rpm bbs-ipmc-atca7367-c01-boot-<version>.rpm
IPMI firmware package (RTM)	bbs-artm-atca7360-<version>.rpm
IPMI firmware booter package (RTM)	bbs-artm-boot-atca7360-<version>.rpm
FPGA firmware package	bbs-fpga-atca7367-<version>.rpm
Firmware Upgrade functionality - Upgrade tool for BIOS, FPGA and IPMC on front blade and RTM	bbs-fuf-atca7367-<version>-pne30.rpm

Table 2-3 BBS Distribution Packages (continued)

Description	File Name
Hardware Platform Management consisting of daemon and client	bbs-hpagentcmd-atca7367-<version>-pne30.rpm
Flash driver for SFMEM module	bbs-sfmem-atca7367-<version>-pne30.rpm
Persistent RAM driver	bbs-pram-atca7367-<version>-pne30.rpm
Link Health Check	bbs-lhc-atca7367-<version>-pne30.rpm
Board control utility to get FPGA data	bbs-boardctrl-atca7367-<version>-pne30.rpm
Telecom clock routing signaling configuration utility	bbs-clkagentcmd-atca7367-<version>-pne30.rpm
HPI-B package	bbs-hpib-<version>-wrs pne3.0-linux.rpm
HPI-B client package	bbs-hpib-clientsrc-<version>-wrs pne3.0-linux.rpm
HPI-B developer package	bbs-hpib-devel-<version>-wrs pne3.0-linux.rpm
Flashrom package (update tool for BIOS flash via SPI interface)	bbs-flashrom-atca7367-<version>-pne30.rpm
Kdump Supporting Files	
Statically linked Linux kernel executable file which includes the necessary information to make the kernel.	vmlinux
Dump-capture kernel	kernel-kdump
Dump-capture kernel modules	modules4kdump.tar.bz2

The following rpm commands are useful to review package information.

Command	Description
<code>rpm -qa</code>	List all installed packages. Use <code>rpm -qa grep hpi</code> to list only HPI packages.
<code>rpm -ql <package-name></code>	List the content of a package, where <code>package-name</code> is the name of a specific package, for example, <code>rpm -ql openhpi</code> .
<code>rpm -qi <package-name></code>	List information about a package, where <code>package-name</code> is the name of a specific package, for example, <code>rpm -qi openhpi</code> .
<code>rpm -qf <path to file></code>	Finds out which RPM a file belongs to.

2.1.3 Accessing the ATCA-7367 via Serial Console

In most procedures described in the following sections you need to invoke Linux commands or configure BIOS settings. In order to do this, you need to access the ATCA-7367 via the face plate serial port. If using a serial console or terminal emulator, the default serial port settings are:

- 9600 baud
- No parity
- Eight data bits
- One stop bit
- Flow control: xon/xoff
- Emulated terminal type: VT100

If you wish to access Linux via a Linux shell, the default account login is `root` with the password `root`. Refer [Login on page 43](#), for more information.

2.2 Configuring TFTP, DHCP and PXE

For all installation and boot options, you need to set up and configure a TFTP server. Furthermore, for the diskless client and hard disk installation/boot option, you need to configure the system's DHCP server and configure PXE boot options. All related steps are described in the following section.

2.2.1 Create /tftpboot Directory and Copy Target Files

It is customary to place TFTP files in a `tftpboot` directory. Regardless of the file system node you specify as the root for your TFTP service, the installation scripts expect a certain directory structure when retrieving files.

Creating the /tftpboot Directory and Copying the Target Files

To create the expected directory structure and copy the needed files, follow these steps.

1. On the host create a `/tftpboot` directory, if it does not already exist
`mkdir /tftpboot`
2. Create a subdirectory for ATCA-7367, for example:
`mkdir /tftpboot/atca-7367`
3. Depending on the boot/installation option, copy or move the required installation files to the subdirectory. Refer [Table 2-3 on page 25](#) for BBS distribution packaging.



The exact file names in your BBS release may be different. Refer the release notes applicable to your particular release. [Table 2-3 on page 25](#) is only an example of a possible packaging with example file names.

Please ensure that the file attributes are set to 755, so that PXE can access and load the files.

To ensure that the downloaded files are correct, sha1 checksums are used. If the sha1 checksums are not correct, an error message is displayed during the installation process. If you make changes to any of the files, you need to remember to update the sha1 checksum file as well. If you still get an error message during the installation, it is likely that one or more of the files have not been copied successfully. Copy all the files to the `tftpboot` directory again and restart the installation.

2.2.2 Configuring a TFTP Server

The instructions in this section can be used to configure standard TFTP servers (BSD compatible) that are under the control of `xinetd`. The exact configuration settings depend on the particular system configuration, the following instructions are only meant as a general guideline.

Configuring a TFTP Server

To configure TFTP as root on the host, complete the following steps:

1. Create (or edit) the file `/etc/inetd.d/tftp`. Depending on the particular system environment, it may contain the following entries.

```
#/etc/inetd.d/tftp
service tftp
{
    socket_type = dgram
    wait = yes
    user = root
    log_on_success += USERID
    log_on_failure += USERID
    server = /bin/in.tftpd
    server_args = -r blksize /tftpboot
    disable = no
    protocol = udp
}
```

2. Create the directory `/tftpboot` and add the needed files as described in [Create /tftpboot Directory and Copy Target Files on page 28](#).
3. If there are any TFTP daemons that have not timed out, you need to stop them. Enter the following command to do so:
killall in.tftpd
4. Enter the following command to have `inetd` re-read its configuration file:
/etc/rc.d/init.d/inetd restart

Your TFTP server is now configured.

2.2.3 Configuring DHCP

The DHCP configuration file on an TFTP server (for example ATCA-F120 or an external TFTP server) resides in `/etc/dhcpd.conf`. Make sure this file contains the following entries (IP addresses may be different in your configuration):

```
#
# Sample dhcpd configuration file
#
#

allow bootp;
allow booting;
authoritative;
filename "pxelinux.0";
ddns-update-style ad-hoc;


option domain-name "booting.com";


option subnet-mask 255.255.255.0;
default-lease-time 600;
max-lease-time 7200;


#Base 1 interfaces
subnet 192.168.21.0 netmask 255.255.255.0 {
    range 192.168.21.100 192.168.21.125;
    option broadcast-address 192.168.21.255;
}


#Base 2 interfaces
subnet 192.168.22.0 netmask 255.255.255.0 {
    range 192.168.22.100 192.168.22.125;
    option broadcast-address 192.168.22.255;
}


#Front interfaces
subnet 192.168.19.0 netmask 255.255.255.0 {
    range 192.168.19.100 192.168.19.125;
    option broadcast-address 192.168.19.255;
}
```

Restart DHCP service on your Linux DHCP server by issuing the following commands and make sure your DHCP service starts successfully against your configuration files:

```
#/etc/init.d/dhcp stop
```

```
#/etc/init.d/dhcp start
```

2.2.4 Configuring PXE

PXE determines which kernel and root file system image a blade gets from the server. The PXE environment as well as the bootable images usually reside in the `/tftpboot` directory on the server. The initial boot file is called `pxelinux.0` and the PXE configuration directory is in the `/tftpboot/pxelinux.cfg`. The default configuration file is called `/tftpboot/pxelinux.cfg/default`.

Example default file:

```
DEFAULT ATCA7367/kernel ramdisk_size=716800 console=ttyS0,9600n8
initrd=ATCA7367/ramdisk.image.gz root=/dev/ram0 ip=none ro pci=lastbus=255
quiet
```

In this configuration, the same images are served to all blades in the chassis. In order to distinguish between blades and to serve different images, you can use different default files and link them to different MAC addresses of different blades.



Depending on the particular BBS release, an example default file for the ATCA-7367 may be contained in the BBS package (check the release notes applicable to your blade release). This file contains all required kernel parameters. In order to use the default file, you need to link it to the MAC address of the ATCA-7367 as described below.

Example:

The following example shows how to set up the PXE environment for an ATCA-7367 blade. This is done by creating a new default file and linking it to the MAC address of the ATCA-7367 boot Ethernet interface, which is 00:80:42:1d:da:07 in the example.



PXE expects that the file name should be prefixed with "01" and all the characters in the file name are lower case letters.

Setting up the PXE Environment

Proceed as follows:

1. Make a new subdirectory in /tftpboot
`#mkdir -p /tftpboot/ATCA7367`
2. Copy the corresponding boot image and RPMs to this directory.
3. Set up a new default files in /tftpboot/pxelinux.cfg, for example default.7367.

The contents of default.7367 are:

```
DEFAULT ATCA7367/kernel ramdisk_size=600000
console=ttyS0,9600 initrd=ATCA7367/ramdisk.image.gz
root=/dev/ram0 rw
```

4. Link the MAC address of the blade to its boot default file, for example:
`#cd /tftpboot/pxelinux.cfg`
`#ln -s default.7367 01-00-80-42-1d-da-07`

2.3 Installation Procedures

The following subsections list the different BBS installation procedures.

2.3.1 Configuring ATCA-7367 for Diskless Client Boot of the BBS Software

This section describes the steps you need to take for performing diskless client boot of the BBS software.

Configuring BIOS for Diskless Client Boot

To configure BIOS for diskless client boot, proceed as follows:

1. Connect to the blade via the serial interface.
2. Power up or reboot the blade.
3. Quickly hold down the **<F2>** key on your keyboard until the BIOS menu appears.
4. Select **ADVANCED** on the top menu.
5. Scroll down to **BOOT FEATURES** by using the arrow keys.
6. Press **<ENTER>**.
7. Make sure that the following settings are enabled:

Base-Interface Network boot or Front Panel Network Boot
(depending on the interface you want to boot from).

If any of these settings is disabled, enable the setting(s) and press **<F10>** or select **Exit Saving Changes**. This will save the new settings and restart the BIOS. After the restart, press **<F2>** to enter BIOS again and continue with the BIOS configuration.

8. Depending on which interface you want to boot from, put either **Base Network 1**, **Base Network 2**, or **FrontPanel Network** to the first position of the **Boot priority** order list.
9. Save and exit.

Rebooting the Blade

To reboot a blade, proceed as follows:

1. Reboot the blade via:
 - Shelf manager
 - Opening and closing the lower handle switch on the face plate
 - Pressing the reset button on the face plate
2. Observe that the blade is getting a DHCP address and is loading the kernel and ramdisk image:

```
Try to load: pxelinux.cfg/<address>
boot:
Loading <blade/module>/kernel.....
Loading <blade/module>/ramdisk-image.gz....
```
3. Once the blade has fully come up, log on to the serial console as **root** with the default password **root**.

2.3.2 Installing BBS Software on Hard Disk Drive

This section describes how to install and boot the BBS software from hard disk. The BBS software can be installed on the following hard disk types:

- SAS/SATA hard disk drive installed on RTM or
- SATA cube on front board (optional)

The installation process starts with the booting of an initial ramdisk via network. The initial ramdisk is then used to copy (via TFTP) and interactively install the kernel, the root file system, and other BBS software on the disk.

The following procedures describe these steps in detail.

Configuring BIOS for Diskless Network Boot

To configure BIOS for network boot, proceed as follows:

1. Connect to the blade via the serial interface.
2. Power up or reboot the blade.
3. Quickly hold down the **<F2>** key on your keyboard until the BIOS menu appears.
4. Select **ADVANCED** on the top menu.
5. Scroll down to **BOOT FEATURES** by using the arrow keys.
6. Press **<ENTER>**.
7. Make sure that the following settings are enabled:

Base-Interface Network boot or Front Panel Network Boot
(depending on the interface you want to boot from).

If any of these settings is disabled, enable the setting(s) and press **<F10>** or select **Exit Saving Changes**. This will save the new settings and restart the BIOS. After the restart, press **<F2>** to enter BIOS again and continue with the BIOS configuration.

8. Depending on which interface you want to boot from, put either **Base Network 1**, **Base Network 2**, or **FrontPanel Network** to the first position of the **Boot priority** order list.
9. Save and exit.

Installing Files and Configuring TFTP on the ATCA-7367

After the system has come up, install Linux with the following procedure:

1. Login as **root**.
2. Identify the Linux device name of the hard disk on which you want to install BBS. To do so, enter **fdisk -l**. This displays available hard disks, their Linux device names and also the storage capacity.

3. Run the `linuxrc` script from the `/opt/bladeservices/tools` directory:
`./linuxrc`
The hard disk installation begins by checking for necessary commands on the system.
4. Enter the information requested by the script, such as the TFTP server address from where the software is loaded, NTP server address, and time zone.
5. Above steps installs all the BBS packages that are available after `tftpbboot` and Linux Boot loader, on the hard disk.

Refer [Installing BBS Using Hard Disk on page 181](#), for step-wise output of the installation and configuration procedure.

Performing the Final Configuration on the ATCA-7367

The final configuration includes configuring the host name and password and setting the time zone.

1. Configure the host name:
Choose a hostname for this machine []
There is no default hostname. Enter a value here.
2. Configure the root password:
Enter new UNIX password:
Retype new UNIX password:
There is no default root password.

Now the boot loader `grub` is installed. After that you need to configure BIOS to boot from the hard disk as described in the following procedure.

Configuring the ATCA-7367 BIOS to Boot from Hard Disk

To configure BIOS on an ATCA-7367 blade, proceed as follows:

1. Connect to the blade via the serial interface.
2. Power up or reboot the blade.

3. Quickly hold down the <F2> key on your keyboard until the BIOS menu appears.
4. Select **BOOT** on the top menu.
5. Scroll down to **BOOT OPTIONS** by using the arrow keys.
6. Press <ENTER>.
7. Depending on the hard disk type and the location where the hard disk is installed, make sure that the corresponding BIOS setting shown in the following table is enabled.

Hard Disk	BIOS Menu and Setting Which Must Be Enabled
SAS hard disk installed on RTM	"Boot Features" -> "ARTM SAS boot"

If the desired setting was previously NOT enabled, enable the desired setting and press <F10> or select **Exit Saving Changes**. This will save the new settings and restart the BIOS. After the restart, press <F2> to enter BIOS again and continue with the BIOS configuration.

8. Put the hard disk which you want to boot from to the first position of the Boot priority order list.
9. Save and exit.
After a successful reboot, you can logon as root using the password you have defined during the final configuration.

2.3.3 Installing BBS Software on On-Board USB Disk

The ATCA-7367 BBS supports network boot via `tftp`. You can use `flashrfsrc` script to install the root file system on the ATCA-7367 on-board flash and to boot from it. The `flashrfsrc` script performs the following tasks:

- formats the ATCA-7367 on-board flash device
- transfers the kernel, root file system, and BBS packages from the `tftp` server to the on-board flash device
- installs and configures the GRUB boot loader



Executing the `flashrfsrc` script will erase all the data existing on the on-board flash.

Configuring BIOS for Diskless Network Boot

To configure BIOS for network boot, proceed as follows:

1. Connect to the blade via the serial interface.
2. Power up or reboot the blade.
3. Quickly hold down the <F2> key on your keyboard, until the BIOS menu appears.
4. Select **BOOT** on the top menu.
5. Scroll down to **BOOT OPTIONS** by using the arrow keys.
6. Press <ENTER>.
7. Ensure that the following settings are enabled:
Base Network 1, **Base Network 2**, or **FrontPanel Network**; depending on the interface you want to boot from.
If any of these settings is disabled, enable the setting(s) and press <F10> or select **Exit Saving Changes**, to save the new settings and restart the BIOS. After the restart, press <F2> to enter BIOS again and continue with the BIOS configuration.

8. Depending on which interface you want to boot from, put either **Base Network 1**, **Base Network 2**, or **FrontPanel Network** to the first position of the Boot priority order list.
9. Save and exit.

Installing Root File System on the on-board Flash

To install the OS and BBS software on the on-board flash of RTM-ATCA-7360 module:

1. Start the blade using `tftp-boot`.
2. Execute `flashrfsrc` script (available in the directory of `/opt/bladervices/tools/`) after an initial netboot. It allows an automatic installation of the OS and BBS packages on the on-board USB flash disk. Provide the device name on which the software is to be installed when you are prompted for it. You can modify the configuration file `flashConfig.default` as per your requirement and use it for the installation.
3. Enter the information requested by the script, such as the TFTP server address from where the software is loaded, NTP server address, and time zone.
4. Above steps installs all the BBS packages that are available after `tftpboot` and Linux Boot loader, on the hard disk.
5. Reboot the blade.
6. Press <F2> to configure the BIOS.
7. In the Boot menu, move `onboard:USBHdd SMART eUSB` to the first option in the Boot Priority Order list.
8. Save and exit BIOS settings and continue booting.

After successful installation, the OS is loaded from the on-board USB flash disk drive.

Refer [Appendix A, Installing and Configuring BBS, on page 181](#), for step-wise output of the installation and configuration procedure.

2.4 Upgrading the Software

Software updates are usually delivered as rpm-files. To install the files on the disk of the blade, copy the new RPM file to the blade, stop the application using this rpm, remove the original files (using the `rpm -e <package>` command) and install the newly copied rpm (using the command `rpm -Uvh <package-name>` command).

To upgrade the BBS software for diskless clients, you have to delete the installation files in the `/tftpboot` directory on the tftpserver, copy the new installation files into this directory, and follow the instructions in [Configuring ATCA-7367 for Diskless Client Boot of the BBS Software on page 33](#).

2.5 Adapting the BBS Software to Customer's Needs

The BBS software structure allows a maximum flexibility with regards to customer's adaptations. Software packages can easily be installed into or removed from existing installations.

The following adaptations are possible:

- Modifying the NetBoot root file system
- Modifying the hard disk installation
- Modifying the hard disk installation procedure
- Modifying the Configuration of the Artesyn-Supplied CGL Kernel

2.5.1 Modifying the NetBoot Root File System

The netBoot root file system is stored in the file `ramdisk.image.gz` on the TFTP server. In order to change the system's behavior regarding network booting blades, you have to modify the root file system.

As root:

```
# cd /tftpboot/<blade or module to be modified>
# mkdir mnt
# gunzip ramdisk.image.gz
# mount -o loop ramdisk.image mnt
```

```
# pushd mnt
# ..... /* make all modifications and enhancements: delete, add or
change files*/
# popd
# umount mnt
# gzip -9 ramdisk.image
```

The blade will now boot the modified root file system.

2.5.2 Modifying Hard Disk Installation

The hard disk installation can be changed after the blade has been installed or by modifying the file `rootfs.tar.gz` prior to the installation. After modifying this file, you have to compute and add the sha1 checksum of the modified root file system to the `files.sha1sum` in the installation directory on the TFTP server.

The example below shows how to change the default login behavior.

```
# cd /tftpboot/... (cd to the directory containing the
rootfs.tar.gz you want to modify)
# mkdir rootfs
# cd rootfs
# tar xzf ../rootfs.tar.gz
* Make your modifications and enhancements to the root filesystem
in the current directory
# tar czf ../rootfs.tar.gz .
# cd ..
# shasum rootfs.tar.gz
*Correct the shasum for rootfs.tar.gz in files.sha1sum
```

2.5.3 Modifying the Hard Disk Installation Procedure

The hard disk installation procedure is based on the `files.sha1sum` in the installation directory on the TFTP server. All packages which are copied to the blade during installation are listed in the `files.sha1sum` together with their sha1sum. The standard installation process accepts rpm, tar, and tgz files and all files that have "kernel" in the file name.

The packages from `files.sha1sum` are installed in the same sequence as listed in the file `files.sha1sum`. The installation process re-calculates the sha1sum of the packages on the blade and compares it to the sha1sum determined by `files.sha1sum`. This ensures a protection against errors and faults during file transmission. The user will be notified in case of mismatch. In that case, you have to repeat the installation procedure.



The root file system must precede the rpm files in the **`files.sha1sum`** file.

2.5.4 Modifying the Configuration of the Artesyn-Supplied PNE Linux Kernel

The current kernel configuration of a running ATCA-7367 installation can be retrieved using the Linux command `zcat /proc/config.gz` or from `ATCA7367_custom_layer/template/board/atca7367/linux/atca7367.cfg` in the LSP directory of the Release package.

To modify the configuration of the CGL kernel supplied by Artesyn, consult your local Artesyn sales representative for assistance and further information.

Linux Distribution Description

3.1 Distribution Description

The BBS for the ATCA-7367 is based on Wind River Enterprise Linux 3.0, which is a Linux distribution built on Linux 2.6.27 kernel technology.

3.2 Reliability

The hard disk installation is configured to use the journaling file system `ext3`. In this distribution majority of errors that are caused due to improper shutdown are fixed automatically during the boot process. Catastrophic errors that cannot be fixed automatically will yield to a command prompt, allowing the super user to execute the `fsck` command on the affected partition.

3.3 Login

A Linux shell can be accessed via the face plate serial port.

If you use a serial console or terminal emulator, the serial/RTM port settings are 9600 baud, no parity, 8 data bits, and 1 stop bit.

If you use secure shell server, it starts in run levels 2–5 and listens on all the Ethernet interfaces. Root login for ssh is not permitted, you need to log in as user "admin". Refer [Network Services Configuration on page 47](#) for default IP address assignments.

If you want to login as `root` via SSH, you need to first configure SSH using the console serial port. Set `PermitRootLogin` in the file `/etc/ssh/sshd_config` to `yes`. For this to take effect you must either reboot the blade or run the command `/etc/init.d/ssh restart`.

The following table lists available default login accounts.

Login Name	Password	Description
admin	emerson	Non-privileged user account
root	root	Privileged user account

3.4 Long POST/Diagnostics

The long POST (Power-On Self test) is an extension to the standard POST which the ATCA-7367 executes after power-up. It is executed during the booting of the Linux operating system and includes higher-level tests. This section describes which tests are by default executed during the long POST, how to obtain the results of these tests and how to add your own test routines.

3.4.1 Default Test Routines

The long POST test routines are implemented as Linux scripts which are invoked during the Linux boot phase. The test scripts which are to be executed need to be defined in the IPMI boot parameter variable `runLP` or as additional parameter in the kernel command line (`runLP=... , ... ,`). Further details are given in [Configuring the Long POST Behavior on page 45](#).

Each test routine displays the test status on the console and writes it to the Linux log module (via `logger`). Furthermore, each test routine writes status information to the IPMI sensor "System Firmware Progress" (type `0xF0`). The used event data values are Artesyn-specific. The following table provides details.

Table 3-1 Long POST Standard Test Routines - Generated IPMI Data

Action	Data Written to System Firmware Progress Sensor
Test routine is started	Offset 0: 0x02 Offset 1: 0xFD Offset 2: 0x1E
Tests routine detects an error.	Offset 0: 0x00 Offset 1: 0xFD Offset 2: 0x1E

The following table lists the names of the default long POST test routines and describes which tests each routine performs.

Table 3-2 Long POST Default Test Routines

Test Routine Name	Description
<code>cpuspeed</code>	This tool gives an overview on the active performance governors and the frequency per core.

Table 3-2 Long POST Default Test Routines (continued)

Test Routine Name	Description
memSize	Checks the amount of memory physically installed and the memory seen by the Operating system.
rtctest	Tests the functionality of the real time clock.
eccTest.sh	This scripts tests checks the ECC Error counter in the memory controller.

3.4.2 Configuring the Long POST Behavior

The names of the test scripts which are to be executed have to be defined in the IPMI system boot parameter variable `runLP` as a comma-separated list, for example as follows:
`runLP=cpuspeed,memSize.sh,rtctest,eccTest.sh`

The scripts are expected to be located in the following directory:

`/opt/bladervices/tools/LP`. So in order to add your own scripts, simply add an entry to the IPMI boot variable `runLP` or add an appropriately defined kernel boot parameter `runLP` and place the script(s) in `/opt/bladervices/tools/LP`. Depending on your system configuration, you may want to design your test scripts to generate console output, write to the log module and store any results in the IPMI System firmware progress sensor as done by the default test scripts.



The IPMI boot parameter can be set by using the `hpm` command `bootparamset` (`hpm -c bootparamset`).

When Linux is booted, the Linux start-up script `/etc/init.d/LPmain.sh` is executed. It reads and analyses the IPMI boot parameter variable `runLP` and invokes the listed test scripts (if any) in the given order. For more advanced customizations, you may want to modify the `/etc/init.d/rd.d/LPmain.sh` script.

The `LPmain.sh` provides the following options:

Table 3-3 Long POST Script LPmain.sh - Options

Option	Description
start	Starts the Long POST for the specified test cases.
status	Gives information about the test cases to be executed during long POST and shows whether longPOST is switched on.
enableLP	Enables the long POST. The Long POST will be executed during the next OS startup.
disableSP	Disables the long POST. The long POST will not be executed during the next OS startup.

3.5 Linux Services Initialization

Table 3-4 describes the generic Linux run levels. Table 3-1 describe the services configured to start in the various Linux run levels. Per default, the blade first runs run level S and then boots into run level 3 as configured by the factory.

Table 3-4 Generic Linux Run Levels

Run Level	Description
S	Startup
0	Halt system
1	Single-user mode
2	Multiuser mode
3	Multiuser mode with network (default)
4	Not used
5	Not used
6	Reboot system

3.5.1 RC Scripts

In addition to the rc-scripts of the Wind River PNE 3.0 Linux configuration the following start/stop scripts are added to ATCA-7367.

Run Level	Script Name	Description
rc3.d	S01bbsrpms	Installs bbs-rpms during initial blade startup, for example, after blade installation or boot via network boot.
	S02bbsinit	Starts boardctrl driver and the optional persistent memory drivers (pram and sfmem when the optional memory module is installed).
	S03longPost	Performs some basic blade tests, before most of the OS services are started.
	S09hpm	Starts the hpmagent.
	S10ethDevOrdering	Performs the eth-device reordering and renaming.
	S20kdump	The kdump service script.
	S57bbsvlan	Configures ip-addresses for the fabric interfaces and brings up the base and fabric interfaces.
rc6.d	K05hpm	Stops the hpmagent.

3.6 Network Services Configuration

The following sections describe the default configuration for network services.

3.6.1 ATCA-7367 Ethernet Interfaces

The ethernet devices, such as eth0, eth1, and eth2 in Linux distribution are renamed to more meaningful name in ATCA-7367, such as base1, base2, and fabric1. This renaming is done in the `/etc/init.d/ethDevOrdering.sh` script, before the network startup.

The following table specifies the Ethernet devices supported by ATCA-7367.

Device Name	Description	Speed	Location	IP address
base1	Base Interface 1	1GbE	Base blade -> Backplane	Obtained by the DHCP client request.
base2	Base Interface 2	1GbE	Base blade -> Backplane	Obtained by the DHCP client request.
fabric1	Fabric Interface 1	10GbE	Base blade -> Fabric Interface on Backplane	Static IP address. It is computed as: <code>192.168.<fabricIf>.<slotnumber*10></code> <code>fabricIf</code> can have value of; '11" for Fabric Interface 1 and "12" for Fabric Interface2. <code>slotnumber</code> specifies the logical slot number converted to decimal. The setup of the IP Addresses for Fabric IF is done in the <code>/etc/init.d/bbsvlan.sh</code> file.
fabric2	Fabric Interface 2	10GbE	Base blade -> Fabric Interface on Backplane	Static IP address. It is computed as: <code>192.168.<fabricIf>.<slotnumber*10></code> <code>fabricIf</code> can have value of; "11" for Fabric Interface 1 and "12" for Fabric Interface2. <code>slotnumber</code> specifies the logical slot number converted to decimal. The setup of the IP Addresses for Fabric IF is done in the <code>/etc/init.d/bbsvlan.sh</code> file.

Device Name	Description	Speed	Location	IP address
front	Front Panel Interface	1GbE	Base blade	No IP address assigned.
update	Update Channel interface	1GbE	Base blade	No IP address assigned.
rtm1 rtm6	RTM 1 RTM 6	1GbE 1GbE	RTM (optional) RTM (optional)	No IP address assigned. NOTE: The ethernet devices on RTM are named from bottom to top on the face blade.
amc1 amc4	AMC 1 AMC 4	1GbE 1GbE	AMC AMC	No IP address assigned. NOTE: The AMC Ethernet interfaces are only available on the ATCA-7367 variants which have AMC Bay Present.

3.7 Tools

This section describes CPUSpeed and IPMIBPAR tools that can be used to change the processor performance governors and IPMI Boot Parameter list.

3.7.1 Performance Tool

The performance tool, CPUSpeed allows to change the processor performance governors and the core frequency (for userspace governor) on a per core base. It utilizes data stored in the `/sys/device/system/cpu` directory. The following table describes various governors.

Governor	Description
Performance	Core is running with maximum frequency.
Ondemand	Cores in idle state are running at lowest frequency. When the core is changed to the utilized state, the frequency of the core is changed to maximum.
Powersave	Core is running with minimum frequency.
Userspace	Core frequency can be adjusted by the user (in steps).



If the P-States are limited by BIOS the required driver is not loaded and therefore the CPUSpeed tool can not work.

CPUSpeed supports the following options:

Option	Description
-d	Dump CPU Frequency/Governor Info
-h	Help
-p	Print supported governors
-s	Set governor/frequency. It supports the following options: <ul style="list-style-type: none"> ● -c : Specifies the core. Valid values are 0 .. 15. Omitting this option means, all cores. ● -f : Specifies the frequency. Valid values are 1596000 .. 2129000. This parameter is ignored except for 'userspace governor'. ● -g : Specifies governors, such as performance, powersave, ondemand, and userspace.

Example:

```

root@ATCA-7367:/opt/bladeservices/tools#
/opt/bladeservices/tools/cpuspeed

##### CPU Frequency Info #####

Number Of Cores: 12

MinFrequency:    1596000

MaxFrequency:    1730000

Available Governors: ondemand userspace powersave performance

##### Frequency Info Per Core #####

Core:  Governor:      CurrentFrequency:

    0  performance      1730000
    1  performance      1730000
    2  performance      1730000
    3  performance      1730000
    4  performance      1730000
    5  performance      1730000
    6  performance      1730000
    7  performance      1730000
    8  performance      1730000
    9  performance      1730000
   10  performance      1730000
   11  performance      1730000

```

3.7.2 IPMIBPAR

The IPMIBPAR tool can be used to change the IPMI Boot Parameter list when Linux is up and running. It supports the following options:

Option	Description
-d	Enable debug output.
-a xx	IPMB Address, if not present local IPMC is used.
-i	Get device ID.
-g	Get IPMI Boot Parameter USER area.
-s file	Store IPMI Boot Parameter (USER area), read from file.
-h	Help.

The following example describes the steps required to change the BootOrder from SAS-HDD to Base Network1.

1. Read the IPMI boot parameter USER area from IPMC.

```
root@ATCA-7367:/opt/bladervices/bin# ipmibpar -g

ipmibpar - Version 1.02 - IPMI Boot Parameter Demo

Copyright 2008 Emerson Network Power Embedded Computing Inc.

Read System Boot Options from USER area (local IPMC)

Hexdump IPMI Boot Parameter:

Size = 182 (0xb6)

0000 b2 00 62 61 75 64 72 61 74 65 3d 39 36 30 30 00 <..baudrate=9600.>
0010 75 73 62 3d 66 70 5f 6f 6e 2c 72 74 6d 5f 6f 6e <usb=fp_on,rtm_on>
0020 2c 6f 6e 62 6f 61 72 64 5f 6f 6e 00 6f 73 5f 62 <,onboard_on.os_b>
0030 6f 6f 74 5f 77 61 74 63 68 64 6f 67 3d 6f 66 66 <oot_watchdog=off>
0040 2c 35 2c 72 65 73 65 74 00 66 72 6f 6e 74 6e 65 <,5,reset.frontne>
0050 74 5f 62 6f 6f 74 3d 6f 6e 00 62 61 73 65 6e 65 <t_boot=on.basene>
```



```

0060  74 5f 62 6f 6f 74 3d 6f 6e 00 61 72 74 6d 5f 6e  <t_boot=on.artm_n>
0070  65 74 5f 62 6f 6f 74 3d 6f 66 66 00 61 72 74 6d  <et_boot=off.artm>
0080  5f 73 61 73 5f 62 6f 6f 74 3d 6f 6e 00 61 72 74  <_sas_boot=on.art>
0090  6d 5f 66 63 5f 62 6f 6f 74 3d 6f 66 66 00 62 6f  <m_fc_boot=off.bo>
00a0  6f 74 5f 6f 72 64 65 72 3d 66 72 6f 6e 74 6e 65  <ot_order=frontne>
00b0  74 00 00 00 1d 42                                     <t....B>

```

IPMI Boot Parameter:

```

baudrate=9600
usb=fp_on,rtm_on,onboard_on
os_boot_watchdog=off,5,reset
frontnet_boot=on
basenet_boot=on
artm_net_boot=off
artm_sas_boot=on
artm_fc_boot=off
boot_order=frontnet

```

2. Save the received IPMI Boot Parameter list into a file (for example, bootparam.log) and change the boot order as follow.

```

baudrate=9600
usb=fp_on,rtm_on,onboard_on
os_boot_watchdog=off,10,reset
frontnet_boot=on
basenet_boot=on

```

```
artm_net_boot=off  
artm_sas_boot=on  
artm_fc_boot=off  
boot_order=basenet0,sashdd,basenet1,sashdd,usbonboard,frontnet
```

3. Write the IPMI parameter list file (for example, bootparam.log).

```
ipmibpar -s <filename>
```

Firmware Upgrade Facility

4.1 Overview

The Firmware Upgrade Facility (FUF) provides a uniform way to upgrade firmware on Artesyn hub blades and node blades. It consists of a Firmware Upgrade Command-line Utility (FCU), flash device drivers, and specially prepared firmware recovery image files. On the ATCA-7367 FUF allows you to upgrade the following firmware types:

- BIOS firmware
- IPMC firmware
- MMC firmware on RTM
- FPGA image

4.2 Firmware Recovery Image Files

FCU supports specially prepared firmware recovery image (FRI) files as well as firmware images in the HPM.1 format. HPM.1 is a PICMG standard to upgrade IPMCs.

By default, the image files for the current hardware configurations are loaded as part of the BBS software in `/opt/bladervices/rom` when the blade-specific firmware support packages are installed.

The following image files are currently supported.

Filename	Description
<code>atca-7367-cpu-<version>.fri</code>	BIOS image in FRI format
<code>atca-7367-cpu-<version>.hpm</code>	BIOS image in HPM.1 format
<code>atca-7367-c01-ipmc.hpm</code>	IPMC firmware for ATCA-7367 variant of ATCA-7367-C01
<code>atca-7367-amc-poped-ipmc.hpm</code>	IPMC firmware for ATCA-7367 variants with Amc Bay Present (Including ATCA-7367-0GB, ATCA-7367-12GB, ATCA-7367-24GB).
<code>atca-7367-amc-no-poped-ipmc.hpm</code>	IPMC firmware for ATCA-7367 variants with AMC Bay not present (Including ATCA-7367-0GB-LS, ATCA-7367-12GB-LS).
<code>atca-7367-ipmc-c01-boot.hpm</code>	IPMC boot loader for ATCA-7367 variant of ATCA-7367-C01

Filename	Description
atca-7367-ipmc-amc-poped-boot.hpm	IPMC boot loader for ATCA-7367 variants with Amc Bay Present (Including ATCA-7367-0GB, ATCA-7367-12GB, ATCA-7367-24GB).
atca-7367-ipmc-amc-nopoped-boot.hpm	IPMC boot loader for ATCA-7367 variants with AMC Bay not present (Including ATCA-7367-0GB-LS, ATCA-7367-12GB-LS).
atca-7367-fpga-<version>.bin	FPGA image in HPM.1 format
artm-7360-ipmc.hpm	IPMC Firmware for ARTM
artm-7360-ipmc-boot.hpm	IPMC boot loader for ARTM

4.3 Backup Concept

The BIOS firmware for the ATCA-7367 is stored in redundant, persistent memory devices. This allows the firmware image in one bank to serve as a backup for the other bank. This is particularly useful for firmware upgrades.

During normal operation, the CPU on the ATCA-7367 determines which bank to boot from based on a chip select signal controlled by the IPMC. This bank is considered the active boot device. FCU will only allow you to upgrade an inactive device. FUF allows you to upgrade only the BIOS boot bank from which the blade has not booted. This means that you need to reboot the blade in case you want to upgrade both the banks of the BIOS flash. The BIOS firmware image can be programmed via the payload by using FUF or via IPMC.

The IPMC firmware consists of a boot loader as well as an active and a stand-by IPMI firmware. The boot loader maintains both the active and stand-by firmware in the flash memory of the ATCA-7367. Please note that the BootLoader Firmware is not installed in the BBS by default, as the BootLoader update must be performed on Artesyn request only.

Each time the IPMC firmware is upgraded, the most recent firmware version is kept in flash memory and the older firmware version is overwritten by the new one. Once the new IPMI firmware is programmed, the IPMC resets itself to boot from the new image. The boot loader validates the new IPMC firmware. Provided the IPMC can power up successfully the current image is made active and the previously active image is made backup. In case of power-up failures, the boot loader automatically recovers from crisis and boots from the previous image.

The FPGA bank can be updated via FCU or IPMC. This means that a corrupt FPGA image can be restored using IPMC. Do remember NOT to power off the blade in case you failed to upgrade the FPGA firmware. Otherwise, your blade may be malfunction or even cannot be powered up due to a corrupted FPGA image. You may recover the corrupted FPGA image through IPMB from shelf manger using ipmitool while the blade is still running.

The following sample output displays the information regarding BIOS, IPMI, and FPGA. Depending on your setup, you may get a different output.

fcu -q

```
*****[[[REPORT BEGIN]]]]*****
```

```
OPERATION : Query
```

```
RESULT    : SUCCESS
```

```
MESSAGE   : Device: atca-7367-cpu
```

```
Part number      : 0106865F08A....
```

```
Part revision    : R1.2.
```

```
BANK            : A
```

```
Firmware Name    : AMI-BIOS
```

```
Firmware Version : 1.0.0
```

```
Marked for next use : no
```

--> Installed BIOS Version on Bank0

```
BANK            : B Firmware
```

```
Name            : AMI-BIOS
```

```
Firmware Version : 1.0.0
```

```
Marked for next use : yes
```

--> Installed BIOS Version on Bank1

```
OPERATION : Query
```

```
RESULT    : SUCCESS
```

```
MESSAGE      : Device: atca-7367-hpm.1-ipmc
Part number   : 0106865F08A....
Part revision : R1.2.
BANK          : A - Operational
Firmware Name : H8S-AMCc F/W
Firmware Version : 2.0.00000007
```

--> Currently activated IPMC firmware bank. Only readable to IPMC which has booted up with it.

```
BANK          : B - Rollback
Firmware Name : H8S-AMCc F/W
Firmware Version : 2.0.00000007
```

--> Rollback IPMC firmware bank. The bank which will be wrote upon an IPMC firmware upgrade request.

```
BANK          : D - Operational
Firmware Name : H8S-AMCc B/L
Firmware Version : 2.0.00000006
```

--> Installed IPMC FW Boot Loader. Single bank. Upgradeable.

```
BANK          : G - Operational
Firmware Name : H8S-AMCc F/I
Firmware Version : 0.0.00000000
```

--> Internal IPMI Bank (FRU Info). No subject to be updated!

```
BANK          : J - Operational
Firmware Name : H8S-AMCc F/C
Firmware Version : 0.0.00000000
```

--> Internal IPMI Bank (FRU Info Carrier). No subject to be updated

BANK : M - Operational

Firmware Name : FPGA

Firmware Version : 0.0.0000000D

--> Installed FPGA Version. Single bank. Upgradeable.

BANK : P - Operational

Firmware Name : BIOS

Firmware Version : 1.0.00000000

--> Inactive BIOS Version (seen by IPMC)

BANK : S - Operational

Firmware Name : BIOS

Firmware Version : 0.0.00000000

--> Activated BIOS Bank (not seen by IPMC).

OPERATION : Query

RESULT : SUCCESS

MESSAGE : Device: artm-7360-hpm.1-ipmc

Part number : unknown

Part revision : unknown

IPMI address : MMC=0x72

BANK : A - Operational

Firmware Name : AVR-AMCm F/W

Firmware Version : 1.51.00000002

--> Installed IPMI FW for ARTM on Bank1

BANK : B - Rollback

Firmware Name : AVR-AMCm F/W

Firmware Version : 1.51.00000002

--> Installed rollback IPMI FW for ARTM on Bank2

BANK : D - Operational

Firmware Name : AVR-AMCm B/L

Firmware Version : 1.51.00000001

--> Installed IPMI Booter FW for ARTM

*****[[[[[REPORT END]]]]*****

4.4 fcu—Firmware Upgrade Command-Line Utility

Description

The Firmware Upgrade Command-line Utility (FCU) allows you to

- Query the current versions of firmware installed on the ATCA-7367 and determine which firmware devices are active
- Verify that a specified upgrade image is sound and compatible with the current hardware
- Upgrade a firmware image
- Mark a device to be used as the boot source on the next reset
- Show the version of a specified firmware image file and compare the version of a specified firmware image file with the version of an installed firmware image

By default, the FCU binary executable is installed in `/opt/bladeservices/bin`. This directory has been added to the PATH environment variable.

FCU works in conjunction with device drivers created specifically for the flash devices on Artesyn blades.

The FCU verify and upgrade operations require specially prepared FRI or HPM files (see [Firmware Recovery Image Files on page 55](#)).

FCU also relies on the Hardware Platform Management Agent daemon to interact with the local IPMC. Most commands will fail if the HPM Agent is not running. For information on configuring and running HPM Agent, see [Chapter 5, Hardware Platform Management, on page 73](#).

Synopsis

```
fcu --help
fcu --version
fcu -q [-d <device-id>]
fcu -v -f <filename>
fcu -u -f <filename>
fcu -a -f <filename>
fcu -m -b <bank-letter> -d <device-id>
```

Parameters

`-a`
`--full-upgrade`

This option is a shortcut for performing the verify, upgrade, and mark operations. The file option `-f` is required. This option should not be combined with other operations.

`-b <bank-letter>`
`--bank=<bank-letter>`

Specifies the bank to mark for next boot, where `<bank-letter>` is the letter designating a specific bank. For BIOS banks, possible values are A and B. For FPGA images, possible values are B (default EEPROM) and C (user-programmable EEPROM). This option is used with the mark operation. Use the query option `-q` to display available banks.

`-c`
`-compare`

Compares the image contained in the specified device with a specified file in the file system. This may be useful after an image upgrade to verify that the device actually contains a new and different image.

`-d <device-id>`
`--device=<device-id>`

Specifies a target firmware device, where `<device-id>` is the name of the device. This option is used with the mark or query operations. Device ID values vary by hardware. You can display supported devices on a given blade by using **fcu --help**. Currently supported values are listed in the following table.

Device ID	Description
<code>atca-7367-cpu</code>	BIOS firmware image on ATCA-7367
<code>atca-7367-hpm.1-ipmc</code>	IPMC firmware, RTM MMC firmware and FPGA image on ATCA-7367

`-f <filename>`
`--file=<filename>`

Specifies the FRI file, where `<filename>` is the complete path and filename of the image file. This option is used with the verify and upgrade operations.

`--force`

This option allows the installation of images with non-matching part-number and part-revision FRU data fields. This option should be used with extreme caution only because installing an incompatible image on a device may render it inoperable.

`--help`

Displays a brief message describing command usage. It also displays a list of the devices supported on the blade. This option is exclusive and should not be used with other options.

This option needs a target destination `-t` argument added when working with the IPMC or ARTM.

`-m`

`--mark`

Tells FCU to set the boot select so that on the next boot the specified firmware bank will be active. When mark is combined with the upgrade operation, there is no need to specify a bank; the bank just upgraded will be marked. Otherwise, you must specify a bank and a device.

Currently, the mark operation only supports CPU firmware devices.

`-q`

`--query`

Tells FCU to return firmware information for a specific device (if used with `-d`) or information about all firmware devices. The query operation is exclusive and is not intended to be combined with other operations.

`-s`

`show`

Shows detailed information about a specified file. The information shown includes for example image type, version, manufacturer name etc. This command may be useful before a firmware upgrade to determine the version of a new image file.

`-u`

`--upgrade`

Tells FCU to upgrade the currently inactive bank of the device specified by the target FRI file. The file option `-f` is required. The upgrade operation may be combined with the verify and mark operations.

`-v`
`--verify`

Tells FCU to verify the image file specified by the required `-f` option. This operation verifies that the specified file is sound and compatible with the current hardware. The verify operation may be combined with the upgrade and mark operations.

`--version`

Displays version information for the utility. This option is exclusive and should not be used with other options.

Usage

Some FCU options can be combined. Some options are exclusive. The following list describes the valid option combinations:

- `--compare --file=<filename>`
- `--full-upgrade --file=<filename>`
- `--help`
- `--mark --bank=<bank-letter> --device=<device-id>`
- `--query`
- `--query --device=<device-id>`
- `--show --file=<filename>`
- `--upgrade --file=<filename>`
- `--upgrade --mark --file=<filename>`
- `--upgrade --file=<filename>`
- `--verify --file=<filename>`
- `--verify --upgrade --file=<filename>`
- `--verify --upgrade --mark --file=<filename>`
- `--version`

Multi character options may be abbreviated so long as they are unique. For example, `--full` is equivalent to `--full-upgrade`. Typing `--ver`, however, will not work since it matches both `--verify` and `--version`.

Single-character options may be combined without repeating the hyphen, as in these examples:

- `fcu -vf /opt/bladeservices/rom/<filename>`
- `fcu -q -d <device-id>`
- `fcu -q -d <device-id>`
- `fcu -mb a -d <device-id>`

Options are not case-sensitive. For example, `--help` is equivalent to `--HeLp`. However, option arguments, such as filename and device ID, are case-sensitive.

When upgrading firmware, it is strongly recommended that you upgrade only one device at a time. While FCU performs many checks during upgrade to ensure success, if something goes wrong and both firmware banks become corrupted, the blade will be inoperable.

4.5 Upgrading a Firmware Image

This section describes recommended procedures for upgrading firmware devices. The procedures for upgrading BIOS and IPMC differ slightly.

NOTICE

The upgrade fails if the following is not taken into consideration:

Upgrade only one bank at a time, then reboot and verify the upgrade using the query option. If the upgrade fails and both banks become corrupted for any reason, the ATCA-7367 will be rendered inoperable.

To prepare the ATCA-7367 for a BIOS upgrade, the dip-switches of the ATCA-7367 must be set such that all BIOS flashes are writable. This is the default configuration. Refer to the ATCA-7367 Installation and Use guide for further details about dip switch settings.

4.5.1 BIOS Upgrade

The BIOS can only be upgraded from the ATCA-7367 on which the BIOS is running. You have to upgrade the BIOS by using `fcu`.

Upgrading the BIOS Firmware with FCU Utility

Follow these steps to upgrade the BIOS. The shown file names and paths are only meant as an example and should be replaced with file names and paths applicable to your configuration.

1. Query the current BIOS firmware images on the blade.

```
fcu -qd atca-7367-cpu
```

2. Show the version of the new BIOS file (to verify that it has actually a newer version than the already installed BIOS)

```
fcu --show -f /opt/bladeservices/rom/atca-7367-cpu-  
<version>.fri
```

or

```
fcu --show -f /opt/bladeservices/rom/atca-7367-cpu-  
<version>.hpm
```

3. Upgrade the firmware image:

```
fcu --upgrade -f /opt/bladeservices/rom/atca-7367-cpu-  
<version>.fri
```

or

```
fcu --upgrade -f /opt/bladeservices/rom/atca-7367-cpu-  
<version>.hpm
```

FCU writes the new image and then reads back the image and performs a binary compare to ensure that the write was successful. If the upgrade was not successful, you will see an error message. Try the upgrade again. If it is still not successful, contact your Artesyn representative.

4. Query the new image to ensure that the version information is correct,

```
fcu -qd atca-7367-cpu
```

5. Mark the new image as active so that it will be used for the next boot, for example:

```
fcu --mark -b <bank-letter> -d atca-7367-cpu
```

where <bank-letter> is the letter of the upgraded bank, for example: a



ATCA-7367 payload should be power-cycled after a BIOS upgrading to make the updated BIOS active. Note that the installed AMC and RTM will also be power-cycled automatically when the ATCA-7367 payload is power-cycled.

Upgrading the BIOS Firmware with IPMITOOL utility via Shelf Manger

Follow these steps to upgrade the BIOS with ipmitool utility from shelf manager. The shown file names and paths are only meant as an example and should be replaced with the file names and paths which are applicable to your configuration.

1. Before starting the BIOS upgrade, please make sure all of the DIP SW is at the factory default OFF status.
2. Install the blade into shelf, and wait until the hotswap blue LED is off.
3. Copy the HPM.1 BIOS image to your local machine which can access the shelf manger by IP. Upgrade the HPM.1 BIOS image to ATCA-7367 via shelf manger.

Note that bank switch is a MUST to flash both of the two banks.

1. Switch Bank to bank 0:

```
/usr/bin/ipmitool -I lan -H <ShelfManger-IP-Address> -t  
blade's <ATCA-7367-IPMB-Address> -b 0x00 -A none raw 0x00  
0x08 0x60 0x00 0x00
```

2. Flash the bank 0:

```
/usr/bin/ipmitool -I lan -H <ShelfManger-IP-Address> -t  
blade's <ATCA-7367-IPMB-Address> -b 0x00 hpm upgrade  
atca-7367-cpu-<version>.hpm activate
```

And now, program the bank 1:

1. Switch Bank to bank 1:

```
/usr/bin/ipmitool -I lan -H <ShelfManger-IP-Address> -t  
blade's <ATCA-7367-IPMB-Address> -b 0x00 -A none raw  
0x00 0x08 0x60 0x00 0x01
```
2. Flash the bank 1:

```
/usr/bin/ipmitool -I lan -H <ShelfManger-IP-Address> -t  
blade's <ATCA-7367-IPMB-Address> -b 0x00 hpm upgrade  
atca-7367-cpu-<version>.hpm activate
```
4. Reset the blade, and the blade should be able to start with the above flashed BIOS images.

4.5.2 IPMC Upgrade

Upgrading the IPMC Firmware

Follow these steps to upgrade an IPMC. The shown file names and paths are only meant as an example and should be replaced with file names and paths applicable to your configuration.



The general procedure to upgrade the MMC image of an RTM is the same, except that you need to use **artm-7360-hpm.1-ipmc** as device ID.

NOTICE

Please make sure you are updating your ATCA-7367 with the correct IPMC firmware between **atca-7367-amc-poped-ipmc.hpm**, **atca-7367-amc-no-poped-ipmc.hpm** and **atca-7367-c01-ipmc.hpm**.

Upgrading an invalid IPMC firmware to your blade may cause the blade malfunction. Refer to [Firmware Recovery Image Files on page 55](#) for more details.

1. Query the current IPMC firmware images on the blade.

```
fcu -q -d atca-7367-hpm.1-ipmc
```

2. Show the version of the new IPMC file (to verify that it has actually a newer version than the already installed image)

```
fcu --show -f /opt/bladeservices/rom/atca-7367-amc-poped-ipmc.hpm
```

3. Upgrade the firmware image,

```
fcu --upgrade -f /opt/bladeservices/rom/atca-7367-amc-poped-ipmc.hpm
```

Once the new IPMI firmware is programmed, the IPMC resets itself to boot from the new image. The boot loader validates the new IPMC firmware. Provided the IPMC can power up successfully the current image is made active and the previously active image is made backup. In case of power-up failures, the boot loader automatically recovers from crisis and boots from the previous image.

4. Query the new image to ensure that the version information is correct,

```
fcu -qd atca-7367-hpm.1-ipmc
```

If the version you just installed is now the active image, the upgrade was successful.

4.5.3 FPGA Upgrade

Upgrading the FPGA Firmware

The ATCA-7367 uses an EEPROM which contains the FPGA firmware.

The following procedure describes how to upgrade the FPGA image stored in the user-programmable EEPROM. The shown file names and paths are only meant as an example and should be replaced with file names and paths applicable to your configuration.

1. Query the current FPGA firmware images on the blade.

```
fcu -q -d atca-7367-hpm.1-ipmc
```



The FCU tool reads the FPGA firmware version directly from the FPGA and not from the EEPROM. Therefore, you need to perform a blade power cycle before you can see the version of a newly installed FPGA firmware.

2. Show the version of the new FPGA file (to verify that it has actually a newer version than the already installed image).

```
fcu --show -f /opt/bladeservices/rom/atca-7367-fpga-  
<version>.bin
```

3. Upgrade the firmware image.

There are two options to do this: via the `--full-upgrade` option and via the `--upgrade` option. Both the options are equivalent.

```
fcu --full-upgrade -f /opt/bladeservices/rom/atca-7367-  
<version>.bin
```

or

```
fcu --upgrade -f /opt/bladeservices/rom/atca-7367-fpga-  
<version>.bin
```

This upgrades the user-programmable FPGA EEPROM with the specified FPGA image file.

4. Power-cycle the blade, if the upgrade successful.



Note that you **MUST NOT** power off the blade if the blade fails to start up after an FPGA upgrade; you need to reprogram the FPGA EEPROM via IPMB from shelf manger using ipmitool.

Upgrade the FPGA firmware via Shelf Manger

1. Copy the FPGA firmware to your local machine which can access the shelf manger through IP. And then use the following command to upgrade the FPGA:

```
/usr/bin/ipmitool -I lan -H <ShelfManger-IP-Address> -t  
<ATCA-7367-IPMB-Address> -b 0x00 -A none hpm upgrade atca-  
7367-fpga-<version>.bin
```

2. Use the following command to check the FPGA version:

```
/usr/bin/ipmitool -I lan -H <ShelfManger-IP-Address> -t  
<ATCA-7367-IPMB-Address> -b 0x00 -A none hpm compprop 4 2
```


Hardware Platform Management

5.1 Overview

Hardware management in AdvancedTCA systems is based on the Intelligent Platform Management Interface (IPMI) specification. IPMI commands can be complex and cumbersome. To facilitate blade-level management, Artesyn provides the Hardware Platform Management (HPM) package that provides a set of commands that are based on IPMI commands but which are easier to use than the IPMI command itself. An HPM command can encapsulate a sequence of IPMI commands for example upgrade the firmware or read the FRU data. An HPM command can be the unifier for OEM IPMI commands that are different on different blade types, for example reading the CPU boot bank. For a catalogue of supported IPMI commands of the blade refer to the respective IPMI manual.

The HPM package consists of

- HPM daemon called `hpmagentd`
- Command line client called `hpmcmd`
- Script framework for managing shutdown and reboot events


The `hpmcmd` sends a given HPM command to the `hpmagentd` and displays the received response on the console. The `hpmagentd` executes the incoming HPM commands and returns the result to a `hpmcmd` client.

HPM commands include:

- Retrieving and modifying FRU data
- Reading and controlling status of IPMI-controlled LEDs
- Executing shutdown and reboot scripts in response to cold reset or graceful reboot requests
- Communicating local slot location information

The `hpmagentd` makes use of OpenIPMI to talk to the local IPMC. OpenIPMI consists of two main parts: A device driver that goes into the Linux kernel, and a user-level library. The following picture shows the software levels that are involved in the HPM architecture:

Figure 5-1 Software Levels of the HPM Architecture



BT Block Transfer Interface
 SIP Serial Interface Protocol
 SMI System Management Interface
 KCS Keyboard Control Style

The SMI (System Management Interface) driver provides the low level interface for talking to the IPMC and could be a KCS driver or BT (block transfer driver) or other.

If you need more information about the software aspects of the blade IPM controller, refer to the respective IPMI manual.

5.2 hpmagentd—HPM Agent Daemon

Description

The HPM agent daemon handles local communication to the intelligent platform management controller (IPMC) on a blade using the SMI. This SMI gets set up by the OpenIPMI driver.

By default, the `hpmagentd` binary executable is installed in `/opt/bladeservices/bin/`. This directory has been added to the PATH environment variable.

This daemon has an init script called `hpm` that will start the daemon in run level 2 with the default settings.

When `hpmagentd` receives a graceful reboot or shutdown alert from the IPMC, it will call the respective script to run the reboot or shutdown sequence.

Synopsis

```
hpmagentd [-l log-level] [-r reboot-script] [-s shutdown-script]
hpmagentd {-i | -u | -h | -v}
```

Parameters

`-l log-level`

Specifies the level of message logging, where `log-level` is one of the standard syslog levels:

Log Level	Description
0	Emergency
1	Alert
2	Critical
3	Error
4	Warning
5	Notice (default)
6	Information
7	Debug

`-r reboot-script`

Specifies a graceful reboot script that will be called when a blade graceful reboot request is received by the IPMC, where `reboot-script` is the complete path and filename of the target script. The default is `/opt/bladervices/bin/hpmreboot` (see [hpm—Shutdown and Reboot Scripts on page 77](#)).

`-s shutdown-script`

Specifies a shutdown script that will be called when a blade shutdown request is received by the IPMC, where shutdown-script is the complete path and filename of the target script. The default is `/opt/bladeservices/bin/hpmshutdown` (see [hpm—Shutdown and Reboot Scripts on page 77](#)).

`-i`

hpmagend runs interactively, that is it will not run as daemon.

`-u | -h`

Displays a brief message about command usage.

`-v`

Displays the version of hpmagend and the version of the OpenIPMI library it is linked against.

5.3 hpm—Start-Up Script

Description

An HPM agent init script, `hpm`, allows you to start, stop, and restart the HPM agent daemon using the agent's default option settings. By default, this script is installed in the `/opt/bladeservices/etc/init.d` directory during installation of the BBS software. It is also linked to `/etc/rc.d/rcS.d` to automatically start the HPM agent when the system boots.

Synopsis

```
hpm {start | stop | restart | force-reload}
```

Parameters

`start`

Starts the hpm agent daemon.

`stop`

Terminates the hpm agent daemon.

`restart`

Terminates and then starts the hpm agent daemon.

`force-reload`

Terminates and then starts the hpm agent daemon.

5.4 hpm—Shutdown and Reboot Scripts

Description

At any time during normal operation, a shelf manager may issue a shutdown (FRU Activation Deactivate) or graceful reboot (FRU Control Reboot) request to the IPMC on a given blade. The IPMC then forwards this information to the HPM agent. The HPM agent listens for such requests from the IPMC. When it receives a request, it calls the respective script to run the reboot or shutdown sequence. In case of a shutdown indication, all running processes should be notified about the shutdown. In case of a reboot notification, the payload is responsible for invoking the reboot procedure. The IPMC is not involved in this process. This allows processes currently running on the blade to prepare for shutdown. After the notification, it takes roughly 30 seconds before the payload is powered off.

Two default scripts, `hpmshutdown` and `hpmreboot`, are installed by default in the `/opt/bladeservices/bin` directory. Currently, these scripts simply print a banner indicating they have run and then issue `shutdown -h now` (`hpmshutdown` script) or `reboot` (`hpmreboot` script).

You may modify the default scripts to suit the needs of your system application or create new scripts. If you create new scripts, use the `-s` and `-r` options when starting `hpmagentd` to specify the new locations and names of the scripts. You may also need to update the hpm start up script in `/opt/bladeservices/etc/init.d/hpm`.

Synopsis

`hpmshutdown`

`hpmreboot`

5.5 hpmcmd—HPM Command Utility

Description

The HPM command utility uses a socket to send commands to the HPM agent. The HPM agent takes care of translating the user-friendly commands into the elaborated IPMI commands that the IPMC is able to understand. Those IPMI commands are transferred to the local IPMC.

Only one HPM command can be outstanding with the HPM agent at any particular moment. This means that even though multiple instances of `hpmcmd` can be started, the HPM agent will handle only one command at a time. Once a command is sent, the `hpmcmd` program waits until the answer from the HPM agent is received or until a time-out occurs.

The HPM command utility can be started in interactive mode, where a prompt is displayed and the user enters commands; it can read in a file of commands; or it can process a single command.

By default, the `hpmcmd` binary executable is installed in `/opt/bladeservices/bin`. During installation of the BBS software, this directory is added to the `PATH` environment variable.

If you do not provide any options you will see the following prompt once the program starts running:

```
hpmcmd>
```

From there you can start executing commands.

Synopsis

```
hpmcmd [-p new-prompt] [-o output] [-i input | -c command]
hpmcmd [--prompt new_prompt] [--output_file output] [--input_file
input | -cmd_line command]
```

Parameters

`-p new-prompt`

Specifies the prompt you would like to have for the `hpmcmd` interactive mode, where new-prompt is any string. The default prompt is `hpmcmd>`. This option should not be combined with the `-r` or `-c` options.

`-i input-file`

Specifies the name of a file with HPM commands, where `input-file` is the complete path and filename of the target file, a standard ASCII file with one command per line (comments are not supported). The default is Standard Input (`stdin`). This option should not be combined with the `-c` option.

Once it has executed all commands in the file, `hpmcmd` terminates.

`-o output-file`

Specifies the name of an output file, where `output-file` is the complete path and filename of the target file. The default is Standard Output (`stdout`).

`-c command`

This option executes a single command and terminates, where `command` is one of the supported commands. This allows you to use the arrow history functions supported in the base shell; a history is not available inside the `hpmcmd` program. This option should not be combined with the `-i` option.

If this option is combined with `-o`, `-c` should be last option entered, since all arguments that follow `-c` on the command line will be considered part of the command.

5.5.1 Command Overview

The following table lists all commands from the hpmcmd program available on the ATCA-7367. You can display this list and a short command description using the help command (see section [help on page 94](#)). A detailed description of the commands is given in section [Supported Commands on page 82](#).

Table 5-1 Command Overview

Command	Description
<i>bootbankget</i>	Gets the bootbank to boot from
<i>bootbankset</i>	Sets the bootbank to boot from
<i>bootparamerase</i>	Erase boot parameter value
<i>bootparamget</i>	Get boot parameter value
<i>bootparamset</i>	Set a boot parameter value
<i>bye</i>	Exit the hpmCmd program
<i>chinfo</i>	Retrieve channel info
<i>cmd</i>	Execute any IPMI command
<i>deviceid</i>	Gets the Device Id.
<i>exit</i>	Exit the hpmcmd program
<i>frudata</i>	Allows to get FRU info in hex numbers
<i>fruinfoget</i>	Gets string fields from the FRU
<i>fruinv</i>	Allows to get the FRU size and addressable units
<i>fruread</i>	Allows to read x number of bytes from the FRU
<i>fruwrite</i>	Allows to write x number of bytes from the FRU
<i>help</i>	List of hpmcmd commands.
<i>ipmbaddress</i>	Shows the local board IPMB address
<i>ipmcdevice</i>	Shows the payload interface to the IPMC
<i>ipmcstatus</i>	Gets the IPMC Status
<i>ledget</i>	Gets the state of a specific FRU LED
<i>ledprop</i>	Get the LED properties for this FRU.
<i>ledset</i>	Controls the state of a specific FRU LED

Table 5-1 Command Overview (continued)

Command	Description
<i>loglevelget</i>	Gets the hpmagentd log level
<i>loglevelset</i>	Sets the hpmagentd log level(0-7)
<i>macaddress</i>	Lists the MAC addresses
<i>motshelftype</i>	Gets the Artesyn Shelf Type from the Shelf FRU (Board Product Name)
<i>partnumber</i>	Gets the board part number
<i>physlotnumber</i>	Gets the board physical slot number
<i>portget</i>	Shows the current state E-Key governed intfs
<i>portset</i>	Enables/Disables ports in a channel
<i>quit</i>	Exit the hpmcmd program
<i>rebootpath</i>	Gets hpmagentd reboot script path
<i>sdr</i>	Shows the SDR records
<i>sdr_dump</i>	Shows the SDR records in raw format
<i>sdrinfo</i>	Shows SDR information
<i>sendcmd</i>	Sends an IPMI command
<i>shelfaddress</i>	Gets the Shelf Address String
<i>shelfslots</i>	Gets number of slots in the shelf
<i>shutdownpath</i>	Gets hpmagentd shutdown script path
<i>slotmap</i>	Prints the slotmap of the shelf
<i>slotnumber</i>	Shows the board logical slot number
<i>solcfgget</i>	Get SOL configuration parameter
<i>solcfgset</i>	Set SOL configuration parameter
<i>upgrade</i>	Allows to upgrade the IPMC firmware
<i>version</i>	Shows the hpmCmd version and the hpmagentd version
<i>watchdog</i>	Control Payload WDT functionality

5.5.2 Supported Commands

This section lists the supported commands. All commands are case insensitive. The examples illustrate the use of `hpmcmd` in single-command mode (`-c`). If you start `hpmcmd` without the `-c` or `-i` options (that is, interactive mode), you simply enter these commands at the HPM command prompt.

Some of the `hpm` commands can be sent to a remote IPMC by specifying the `-t` option. This option is not mandatory. If it is not specified, the command is sent to the local IPMC.

5.5.2.1 **bye**

Description

This command is for exiting the hpmcmd program when running in interactive mode.

Synopsis

`bye`

5.5.2.2 **bootbankget**

Description

This command retrieves the boot bank which is currently marked as active for the CPU specified by `payload_cpu_selector`.

Firmware for the CPU on Artesyn AdvancedTCA blades is stored in redundant, persistent memory devices. This allows the firmware image in one bank to serve as a backup for the other bank. During normal operation, the CPU on a blade determines which bank to boot from based on a GPIO signal controlled by the IPMC. This bank is considered the active boot device.

Because you can change the “active” device with the `hpmcmd bootbankset` command, active status does not necessarily indicate which device was used on the last boot. It simply represents which device is set to be used on the next boot.

Synopsis

```
bootbankget <payload_cpu_selector>
```

Parameters

`payload_cpu_selector`

Is an integer between 0 and the number of CPU devices supported on the blade.

Example

```
hpmcmd -c bootbankget 0
```

5.5.2.3 bootbankset

Description

This command sets the boot bank for a particular CPU from which the blade is supposed to boot.

Synopsis

```
bootbankset <payload_cpu_selector> <newBootBank>
```

Parameters

`payload_cpu_selector`

Is an integer between 0 and the number of CPU devices supported on the blade.

`newBootBank`

Can be set to BANK0 or BANK1

Example

```
hpmcmd -c bootbankset 0 bank1
```

5.5.2.4 bootparamerase

Description

This command allows you to erase data which is stored in the IPMC boot parameters storage area. The data which is stored in this area can be accessed from the IPMI subsystem and also from the OS and boot firmware. The storage area can for example be used in order to pass boot parameters to the boot firmware. For further details, refer to the *ATCA-7367 Installation and Use Guide*.

Synopsis

```
bootparamget section name [-t ipmbAddr[:mmcAddr]]
```

Parameters

section

Section within the IPMC storage area in which data is to be erased. Possible values are:

- USER
- DEFAULT
- TEST
- OS_PARAM

name

Name of the parameter which is to be erased

-t

Sends the command to ipmbAddr:mmcAddr. The ipmbAddr is the string lc if it is a local mmcAddr.

Example

```
hpmcmd -c bootparamerase USER boot_order
```

Successful bootparamerase Operation

5.5.2.5 bootparamget

Description

This command allows you to read data which is stored in the IPMC boot parameters storage area. The data which is stored in this area can be accessed from the IPMI subsystem and also from the OS and boot firmware. The storage area can for example be used in order to pass boot parameters to the boot firmware. For further details, refer to the *ATCA-7367 Installation and Use Guide*.

Synopsis

```
bootparamget section [name] [-t ipmbAddr[:mmcAddr]]
```

Parameters

section

Section within the IPMC storage area from which data is to be read. Possible values are:

- USER
- DEFAULT
- TEST
- OS_PARAM

name

Name of the parameter whose value is to be read

-t

Sends the command to ipmbAddr:mmcAddr. The ipmbAddr is the string lc if it is a local mmcAddr.

Example

```
hpmcmd -c bootparamget USER boot_order
```

```
boot_order = sashdd,sata3,sata1,basenet0,basenet1
```

5.5.2.6 bootparamset

Description

This command allows you to write data to the IPMC boot parameters storage area. The data which is stored in this area can be accessed from the IPMI subsystem and also from the OS and boot firmware. The storage area can for example be used in order to pass boot parameters to the boot firmware. For further details, refer to the *ATCA-7367 Installation and Use Guide*.

Synopsis

```
bootparamset section name=value [-t ipmbAddr[:mmcAddr]]
```

Parameters

section

Section within the IPMC storage area where to write the data to. Possible values are:

- USER
- DEFAULT
- TEST
- OS_PARAM

name

Name of the parameter which is to be set

value

Value of the parameter

-t

Sends the command to ipmbAddr:mmcAddr. The ipmbAddr is the string lc if it is a local mmcAddr.

Example

```
hpmcmd -c bootparamset USER
bootboot_order=sashdd,sata3,sata1,basenet0,basenet1,usbonboard
```

Successful bootparamset Operation

5.5.2.7 chinfo

Description

Retrieve channel information

Synopsis

```
chinfo channel [-t ipmbAddr[:mmcAddr]]
```

Parameters

channel

Channel number

-t

Sends the command to `ipmbAddr:mmcAddr`. The `ipmbAddr` is the string `lc` if it is a local `mmcAddr`.

Example

```
hpmcmd -c chinfo 0
```

```
Channel Medium Type   : IPMB (I2C)
Channel Protocol Type : IPMB-1.0
Session Support       : session-less
Active Session Count  : 0
Protocol Vendor ID    : 001BF2
```

```
root@ATCA7367_HDD:~# hpmcmd -c chinfo 4
Channel Medium Type   : System Interface (KCS, SMIC, or BT)
Channel Protocol Type : KCS
Session Support       : session-less
Active Session Count  : 0
Protocol Vendor ID    : 001BF2
```

```
root@ATCA7367_HDD:~# hpmcmd -c chinfo 1
Channel Medium Type   : Asynch. Serial/Modem (RS-232)
Channel Protocol Type : TMode
Session Support       : session-less
Active Session Count  : 0
Protocol Vendor ID    : 00400A
```

5.5.2.8 cmd

Description

This command allows you to enter commands understood by the IPMC. Commands are entered as a sequence of hexadecimal numbers as defined in the *IPMI 1.5 Specification*.

Synopsis

```
cmd <ipmi address> <netfn cmd> <cmd data>
```

Parameters

`ipmi address`

The IPMI address specifies the IPMC that receives the command, it can be the local IPMC or another IPMC on the IPMB. The IPMI address for the local IPMC consists of <f LUN> where f is the BMC channel number. The IPMI address for a remote IPMC consists of <0 SA LUN>.

`netfn cmd`

Identifies the command type.

`cmd data`

Specifies the message data associated with the command.

Example

GetDeviceId command to the local IPMC:

```
hpmcmd -c cmd f 0 6 1
```

GetDeviceId command to the remote IPMC on address 9a:

```
hpmcmd -c cmd 0 9a 0 6 1
```

GetDeviceId command to the remote IPMC on address 7a:

```
hpmcmd -c cmd 0 7a 0 6 1
```

5.5.2.9 deviceid

Description

This command retrieves the raw IPMI Get Device ID response and decodes the IPMI message.

Synopsis

```
deviceid -t [ipmbAddr[:mmcAddr]]
```

Parameters

`-t`

Sends the command to ipmbAddr:mmcAddr. ipmbAddr is the string lc if it is a local mmcAddr.

Example

```
hpmcmd -c deviceid
```



The least significant byte of the Auxiliary Revision indicates the build number inside the release.

5.5.2.10 exit

Description

This command is for exiting the hpmcmd program when running in interactive mode.

Synopsis

```
exit
```

5.5.2.11 frudata

Description

This command dumps the content of the FRU data in hexadecimal format.

Synopsis

```
frudata <fruid> [-t ipmbAddr[:mmcAddr]]
```

Parameters

fruid

Is 0 for the main blade and 1 for the rear transition module.

-t

Sends the command to ipmbAddr:mmcAddr. ipmbAddr is the string lc if it is a local mmcAddr.

Example

```
hpmcmd -c frudata 0
```

5.5.2.12 fruinfoget

Description

This command retrieves information from the specified FRU.

Synopsis

```
fruinfoget <fruid> [field] [-v] [-t ipmbAddr[:mmcAddr]]
```

Parameters

fruid

Is 0 for the main blade and 1 for the rear transition module.

field

Is one of the following data fields. If no field is specified, it retrieves the whole fruinfo for that FRU.

Field	Description
bmanufacturer	Board manufacturer
bproductname	Board product name
bserialnumber	Board serial number
bpartnumber	Board part number
pmanufacturer	Product manufacturer
pproductname	Product product name
ppartnumber	Product part number
pversion	Product version number
pserialnumber	Product serial number
passettag	Product inventory asset identifier

-v

Verbose mode to get point-to-point connectivity information where no specific field is requested.

-t

Sends the command to ipmbAddr:mmcAddr. ipmbAddr is the string lc if it is a local mmcAddr.

Example

```
hpmcmd -c fruinfoget 1 bmanufacturer
```

The following example for fruinfoget is without fields and -v option.

```
hpmcmd -c fruinfoget 0
```

5.5.2.13 fruinv

Description

This command retrieves the FRU size and the addressable unit for the specified FRU.

Synopsis

```
fruinv <fruid> [-t ipmbAddr[:mmcAddr]]
```

Parameters

fruid

Is 0 for the main blade and 1 for the rear transition module (if supported).

-t

Sends the command to ipmbAddr:mmcAddr. ipmbAddr is the string lc if it is a local mmcAddr.

Example

```
hpmcmd -c fruinv 0
```

5.5.2.14 fruread

Description

This command gets a range of data from the specified FRU.

Synopsis

```
fruread <fruid> <startAddress> <nBytes> [-t ipmbAddr[:mmcAddr]]
```

Parameters

fruid

Is 0 for the main blade and 1 for the rear transition module (if supported).

startAddress

Is the starting address in decimal.

nbytes

Number of bytes to read in decimal; cannot exceed 16 because of IPMI message size limitations.

Example

```
hpmcmd -c fruread 0 0 8
```

5.5.2.15 fruwrite

Description

This command allows to write x number of bytes to a FRU.

Synopsis

```
fruwrite <fruid> <startAddress> <nBytes> [-t ipmbAddr[:mmcAddr]]
```

Parameters

fruid

Is 0 for the main blade.

startAddress

Starting address in decimal numbers.

nBytes

is the number of bytes to write in decimal. nBytes cannot exceed 16 because of IPMI message size limitations.

5.5.2.16 help

Description

This command lists the available commands from the hpmcmd program with a brief explanation about the command.

Synopsis

help

5.5.2.17 ipmbaddress

Description

This command retrieves the blade IPMB address.

Synopsis

ipmbaddress

5.5.2.18 ipmcdevice

Description

This command retrieves the payload tty device.

Synopsis

ipmcdevice

5.5.2.19 ipmcstatus

Description

This command retrieves the IPMC operating mode, payload control and outstanding events.

Synopsis

```
ipmcstatus [-v] [-t ipmbAddr]
```

Parameters

-v

Verbose mode to get additional information operation

Example

```
hpmcmd -c ipmcstatus -v
```

5.5.2.20 ledget

Description

This command gets information about a specified LED controlled by the IPMC.

Synopsis

```
ledget <fruid> <led> [-t ipmbAddr[:mmcAddr]]
```

Parameters

fruid

Is 0 for the main blade and 1 for the rear transition module (if supported).

led

Is BLUE for the hot swap LED or LEDN for FRU LED<n>. <n> is a number between 1 and the maximum FRU LEDs supported by the blade.

-t

Sends the command to ipmbAddr:mmcAddr. ipmbAddr is the string lc if it is a local mmcAddr.

Example

```
hpmcmd -c ledget 0 led1
```

5.5.2.21 ledprop

Description

This command displays the FRU LED properties under IPMC control.

Synopsis

```
ledprop <fruid>
```

Parameters

`fruid`

0 for the main board and 1 for the RTM.

Example

```
hpmcmd -c ledprop 0
```

```
FRU LEDs under IPMC control:
```

```
LED0 = BLUE
```

```
LED1 = RED or AMBER
```

```
LED2 = GREEN
```

5.5.2.22 ledset

Description

This command controls the override state of a specific FRU LED. The RTM FRU LEDs reflect the state of the main blade (FRU 0) LEDs. Therefore, overriding the state to something different than the main FRU LED state will not have any effect.

The blue LED is the only one that can be controlled separately.

Synopsis

```
ledset <fruid> <led> <operation> [offms] [onms] [color] [-t  
ipmbAddr[:mmcAddr]]
```

Parameters

`fruid`

Is 0 for the main blade and 1 for the rear transition module (if supported).

`led`

Is BLUE for the hot swap LED or LEDN for FRU LED<n>. <n> is a number between 1 and the maximum FRU LEDs supported by the blade

`operation`

ON = enable override state and turn LED on.

OFF = enable override state and turn LED off.

BLINK = enable override state and blink LED; off_duration and on_duration specify the blink duration; the default on and off duration is 300 ms.

LOCAL = cancel override state and restore LED control to the IPMC, that is, local state.

TEST = run lamp test for specified on_duration, then restore prior state.

`offms`

10–2500 in 10-millisecond increments; only valid if operation is BLINK

`onms`

Only valid if operation is BLINK or TEST:

If operation is BLINK, 10–2500 in 10-millisecond increments

If operation is TEST, 100–12800 in 100-millisecond increments

`color`

LED0 = BLUE

LED1 = RED

LED2 = GREEN

LED3 = AMBER

`-t ipmbAddr`

sends the command to ipmbAddr.

Example

```
hpmcmd -c ledset 0 led1 on
```

5.5.2.23 loglevelget

Description

This command retrieves the current `hpmagentd` log level. See `loglevelset` for more detail.

Synopsis

```
loglevelget
```

Example

```
hpmcmd -c loglevelget
```

```
LogLevel 5 (NOTICE)
```

5.5.2.24 loglevelset

Description

This command sets the level of message logging for `hpmagentd`.

Synopsis

```
loglevelset <newLogLevel>
```

Parameters

`newLogLevel`

Is one of the standard syslog levels:

Level	Description
0	Emergency
1	Alert
2	Critical
3	Error

Level	Description
4	Warning
5	Notice
6	Information
7	Debug

Example

```
hpmcmd -c loglevelset 7
```

5.5.2.25 macaddress

Description

This command retrieves a list of available MAC addresses.

Synopsis

```
macaddress [-t ipmbAddr]
```

Parameters

-t ipmbAddr

Sends the command to ipmbAddr.

Example

```
hpmcmd -c macaddress
BASE Interface Channel 0 : 00:0E:0C:85:E9:91

BASE Interface Channel 1 : 00:0E:0C:85:E9:90
```

5.5.2.26 motshelftype

Description

This command retrieves the shelf FRU (IPMB 20) Board Area Product Name (FRU 254).

Synopsis

motshelftype

Example

```
hpmcmd -c motshelftype  
CHS1406
```

5.5.2.27 partnumber

Description

This command retrieves the part number of the main blade.

Synopsis

```
partnumber [-t ipmbAddr[:mmcAddr]]
```

Parameters

-t ipmbAddr

Sends the command to ipmbAddr.

Example

```
hpmcmd -c partnumber
```

5.5.2.28 physlotnumber

Description

This command retrieves the physical slot number in which the blade is plugged in.

Synopsis

```
physlotnumber
```

5.5.2.29 portget

Description

This command shows the current state of interfaces governed by e-keying. If no channel is specified, portget returns data for all channels in the specified interface. If neither interface nor channel are specified, portget will return data for all interfaces.

Synopsis

```
portget [interface] [channel] [-t ipmbAddr[:mmcAddr]]
```

Parameters

interface

Valid values are:

BASE | FABRIC | UPDATE

channel

an integer in the following range:

1–16 for Base

1–15 for Fabric

1 for Update

The value of channel must be valid for the blade. For example, node blades have only 2 channels for the base interface; using a value of 4 will return an error.

-t ipmbAddr

Sends the command to ipmbAddr.

Example

```
hpmcmd -c portget AMC 0
```

5.5.2.30 portset

Description

This command enables and disables ports in a channel. The following table lists the valid values for each parameter.

Synopsis

```
portset <intf> <chan> <grpid> <type> <typeX> <ports> <oper> [-t  
ipmbAddr[:mmcAddr]]
```

Parameters

intf

Valid values are:

BASE | FABRIC | UPDATE

chan

an integer in the following range:

1–16 for Base

1–15 for Fabric

1 for Update

The value of channel must be valid for the blade. For example, node blades have only 2 channels for the base interface; using a value of 4 will return an error.

grpid

Always 0 according to current shelf FRU information

type

Valid values are:

Valid Value	Description
BASE	for base interface
ETHER	for fabric interface
OEM	for the update interface, which is Artesyn specific

`typeX`

Always 0 in current implementation. Valid values are:

0 (for 1000Base-BX)

1 (for 10GBase-BX4)

2 (for FC-PI)

`ports`

A sequence of ports to act on.

For base and update channels, port is always 0.

For fabric channels, port can specify up to 4 ports as specified in PICMG 3.1:

Option 1: 0

Option 2: 01

Option 9: 0123

`oper`

Valid values are DISABLE or ENABLE.

Example

```
hpmcmd -c portset base 1 0 base 0 0 enable
```

5.5.2.31 quit

Description

This command is for exiting the hpmcmd program when running in interactive mode.

Synopsis

quit

5.5.2.32 rebootpath

Description

This command retrieves the path and filename of the current `hpmagentd` reboot script.

Synopsis

```
rebootpath
```

Example

```
hpmcmd -c rebootpath  
/opt/bladervices/bin/hpmreboot
```

5.5.2.33 sdr

Description

This command shows the SDR records.

Synopsis

```
sdr
```

Example

```
hpmcmd -c sdr  
  
recID 0: management controller device locator record  
  I2C slave addr: 42  
  Channel number: 00  
  Power state: 06  
  Global init: 0C  
  Capabilities: 2D  
  Entity Id: PICMG front board  
  Entity instance: 60  
  OEM: 00  
  Id string: ATCA-7367  
  
recID 1: full sensor record  
  owner is IPMB 84 sensor num 00 on lun 00 channel 00
```

```

logical entity: PICMG front board - instance 60
Hot Swap Carrier : FRU hot swap : sensor-specific discrete

recID 2: full sensor record
owner is IPMB 84 sensor num 01 on lun 00 channel 00
logical entity: AMC - instance 65
Hotswap_AMC1 : FRU hot swap : sensor-specific discrete

```

5.5.2.34 sdr_dump

Description

This command shows the SDR records in binary and hex format.

Synopsis

```
sdr_dump
```

Example

```
hpmcmd -c sdr_dump
```

```
SDR Records: 01 00 51 12 14 94 00 cc 2d 00 00 00 a0 60 00 c9
"..Q....i-..._`.é" 41 54 43 41 2d 37 33 36 37 "ATCA-7367"
```

5.5.2.35 sendcmd

Description

This command allows a user to send any of the commands supported in the IPMI spec to a remote IPMC.

Synopsis

```
sendcmd <IPMBaddress> <netfn> <cmd> <data0> ... <dataN>
```

Parameters

IPMBaddress

Destination IPMB address in hex digits.

netfn

IPMI request net function in hex digits.

cmd

IPMI request command in hex digits

data0 ... dataN

IPMI request data bytes. if any, in hex digits.

Example

```
hpmcmd -c sendcmd 90 06 59
07 59 C1
```

5.5.2.36 sdrinfo

Description

This command shows the SDR information.

Synopsis

sdrinfo

Example

```
hpmcmd -c sdrinfo

SDR Information:

LUN 0 has 062 sensors; static sensor population
LUN 1 has 000 sensors
LUN 2 has 000 sensors
LUN 3 has 000 sensors
```

5.5.2.37 shelfaddress

Description

This command retrieves the shelf address string from the shelf FRU.

Synopsis

```
shelfaddress
```

Example

```
hpmcmd -c shelfaddress  
01
```

5.5.2.38 shelfslots

Description

This command retrieves the total number of blade slots in the shelf.

Synopsis

```
shelfslots
```

Example

```
hpmcmd -c shelfslots  
  
2 slots           //e.g. in a Centellis 2000 System
```

5.5.2.39 shutdownpath

Description

This command retrieves the path and filename of the current `hpmagentd` shutdown script.

Synopsis

```
shutdownpath
```

Example

```
hpmcmd -c shutdownpath  
/opt/bladeservices/bin/hpmshutdown
```

5.5.2.40 slotmap

Description

This command prints a slotmap table for the shelf the blade is installed in.

Synopsis

```
slotmap
```

Example

```
hpmcmd -c slotmap
```

```
Physical Slot : 01 02 03 04 . 05 06 07 08 . 09 10 11 12 . 13 14
Logical Slot : 13 11 09 07 . 05 01 03 04 . 02 06 08 10 . 12 14
IPMB Address : 9A 96 92 8E . 8A 82 86 88 . 84 8C 90 94 . 98 9C
```

5.5.2.41 slotnumber

Description

This command retrieves the logical slot number of the slot where the blade is plugged in.

Synopsis

```
slotnumber
```

Example

```
hpmcmd -c slotnumber
2
```

5.5.2.42 solcfgget

Description

Retrieves the current serial over LAN (SOL) configuration. SOL is a feature which allows you to redirect the serial console of the blade via an IPMI session over the network. Refer to the blade's hardware user manual for further details.

Synopsis


```
solcfgget channel [param] [-t ipmbAddr[:mmcAddr]]
```

Parameters

channel

Channel number

param

The configuration parameter whose value you want to retrieve. Possible values are:

- enable
- authentication
- char-settings
- retry
- nonvolatile-bit-rate
- volatile-bit-rate
- payload-channel
- payload-port

-t

Sends the command to ipmbAddr:mmcAddr . ipmbAddr is the string lc if it is a local mmcAddr.

5.5.2.43 solcfgset

Description

Sets a serial over LAN (SOL) configuration parameter. SOL is a feature which allows you to redirect the serial console of the blade via an IPMI session over the network. Refer to the blade's hardware user manual for further details.

Synopsis

```
solcfgset channel param value [-t ipmbAddr[:mmcAddr]]
```

Parameters

`channel`

Channel number

`param`

The configuration parameter whose value you want to retrieve. Possible values are:

- `enable`
- `authentication`
- `char-settings`
- `retry`
- `nonvolatile-bit-rate`
- `volatile-bit-rate`
- `payload-channel`
- `payload-port`

`value`

The value which you want to set

`-t`

Sends the command to `ipmbAddr:mmcAddr` . `ipmbAddr` is the string `lc` if it is a local `mmcAddr`.

5.5.2.44 upgrade

Description

This command is used to upgrade the IPMC firmware.

It is only possible to upgrade the firmware remotely from one blade to another, not from the blade itself. In case of an RTM upgrade the front blade will be powered down.

Synopsis

```
upgrade <image> -f <filepath>
```

Parameters

image

Full path of the upgrade image file

-f filepath

Full path of the upgrade image file. This operation will make the current image the backup one.

5.5.2.45 version

Description

This command retrieves the version of the hpmcmd software and sends a request to get the version of the hpmagent daemon that is running. Once the information is gathered, it is printed.

Synopsis

version

Example

```
hpmcmd -c version
hpmcmd version bbs 3.1.0 build X
hpmagentd version bbs 3.1.0 build X
```

5.5.2.46 watchdog

Description

This command is used handle the payload BMC watchdog.

Synopsis

```
watchdog set <tmr_use> <tmr_action> <pre_timeout> <flags> <lsb_val>
<msb_val>
watchdog set default
```

```
watchdog get
watchdog start
watchdog stop
watchdog reset
```

Parameters

set

Possible values are

tmr_use	dont_stop stop
tmr_action	no_action hard_reset power_cycle power_down
pre_timeout	0-255
flags	clear dont_clear
lsb_val	0-255
msb_val	0-255

Link Health Check

6.1 Overview

The Link Health Check (LHC) package supports configuration and operation of the LHC protocol.

LHC performs two functions within a Centellis system:

- Verification of Layer2 connectivity
- Distribution of active network plane

The LHC daemon can be configured to manage one or more instances. Each instance has a role of either proctor or responder. In the proctor role, LHC periodically sends QUERY messages and expects RESPONSE messages. It also sends RESPONSE messages in response to QUERY messages received from other proctors. In the responder role, LHC sends RESPONSE messages in response to received QUERY messages.

Generally, the LHC daemon on hub blades will be configured with one instance with a proctor role. The LHC daemon on a payload blade with no internal switches will be configured with one instance with a responder role. The LHC daemon on carrier blades with an internal switch will be configured with two instances. One instance will have a responder role with respect to the system network and the other one will have a proctor role with respect to the blade's internal network that connects to the AMCs/PMCs. The LHC daemon on an AMC/PMC will be configured with one instance with a responder role.

The LHC package includes:

- SNMP access to LHC
- Configuration and management daemon
- Command line utility program

6.2 LHC MIB

LHC makes its internal structures available as MIB tables and objects. To enable SNMP access, you must link to the enterprise MIB provided in the LHC package and enable SNMP access on the blade. You can also configure LHC by using the `lhcd` configuration script or via the `lhccmd` command line utility.

6.2.1 Browsing the LHC MIB

To support LHC, Artesyn has created an enterprise MIB known as the LHC MIB, `/opt/ bladeservices/mibsLHC-MIB.txt`. This MIB defines the tables, objects, and MIB variables used to control and monitor LHC.

This MIB can be reviewed with any SNMPv2 compatible MIB browser.

6.2.2 Enabling SNMP Access to the LHC MIB

By default, the LHC MIB is installed in `/opt/ bladeservices/mibs`. Add this directory to the MIBDIRS environment variable:

```
export MIBDIRS=$MIBDIRS:/opt/ bladeservices/mibs
```

The blade is delivered with SNMP disabled per default. To enable the SNMP daemon, the start script in `/etc/init.d/snmpd.disabled` must be renamed to `/etc/init.d/snmpd`. The default `/etc/snmp/snmpd.conf` file creates the user "LocalUser" with the password "LocalUserPassword". You can simply modify `snmpd.conf` to add, delete, or modify users or communities you require.

After you modify `snmp.conf` or `/etc/default/snmpd`, you must start or restart the SNMP daemon for changes to take effect.

6.3 lhcd—LHC Daemon

Description

The Link Health Check (LHC) management daemon, `lhcd`, manages the LHC protocol. It serves several purposes:

- Provides, through a command interface, the ability to customize operation of the LHC protocol
- Collects operational statistics which allow monitoring of the LHC protocol
- Accepts commands from fault management to change the active network plane
- Notifies fault management of events of interest, such as responder not responding

During normal operation, the LHC daemon process, `lhcd`, is created and runs as a system daemon. An init script, `lhc`, allows you to start and stop the LHC daemon. For further information, see [lhc—lhcd Start-Stop Script on page 116](#).

Synopsis

```
lhcd [-c config_file] -f shelfnum -s slotnum -t sitenum  
[-l log-level][-p pid-file]  
  
lhcd -v
```

Parameters

`-h`

Displays a brief usage.

`-c config_file`

If supplied, LHC reads in the specified file (including path) that contains commands to configure LHC.

`-f shelfnum`

Blade is in shelf specified by `shelfnum`. This is a required option. The shelf number, slot number, site number, and instance number are used in MIB indices to uniquely identify each LHC instance. This is particularly significant in multishelf configurations.

`-s slotnum`

Blade is in slot specified by `slotnum`, where `slotnum` is the logical slot number where the blade is inserted. You can retrieve the slot number by entering `hpmcmd -c slotnumber`. This is a required option. The shelf number, slot number, site number, and instance number are used in MIB indices to uniquely identify each LHC instance.

`-t sitenum`

Blade is in site specified by sitenum, where sitenum is the logical site number where the blade is inserted. This is a required option. The shelf number, slot number, site number, and instance number are used in MIB indices to uniquely identify each LHC instance. Note that even though the site number is used to identify an AMC on a carrier blade, a site number must be supplied for LHC instances that are not running on an AMC/PMC. The recommended value for non-AMC/PMC is 255.

`-l log-level`

Sets log level to one of the standard syslog levels:

Log Level	Description
0	Emergency
1	Alert
2	Critical
3	Error
4	Warning
5	Notice (default)
6	Information
7	Debug

`-p pidfile`

Is the complete path and filename for the daemon's process ID file. This file is used by start-stop daemon to locate the correct lhcd process when stopping the daemon. If no PID file is specified, the file `lhc.pid` is created in the current working directory (`pwd`) from which LHC was started.

`-v`

Displays the version information.

6.4 lhc—lhcd Start-Stop Script

Description

The `lhc` init script allows you to start, stop, and restart the LHC daemon. The script relies on the HPM agent to retrieve important blade-specific information.

By default, this script is installed in the `/opt/ bladeservices/etc/init.d` directory during installation of the BBS software.

It is linked to `/etc/rc.d/rc2.d` so that LHC starts automatically in the run level 3.

You can use this script to start, stop, or restart the LHC daemon by changing to the `/opt/ bladeservices/etc/init.d` directory and typing `lhc` with the appropriate option, for example:

```
./lhc start
```

Synopsis

```
lhc {start|debug_start|start_no_cfg|stop|restart|
force-reload|generate_config}
```

Parameters

`start`



Note that after starting LHC using the `start` parameter, the daemon automatically reads in a configuration file in the `/opt/ bladeservices/etc/lhc` directory. The filename is of the form `lhc.<shelf>.<slot>.<site>.cfg`.

Starts `lhcd`.

`debug_start`

Starts `lhcd` with debug-level logging (7) rather than the default (5).

`start_no_cfg`

Starts `lhcd` without reading in a configuration file.

`stop`

Terminates lhcd.

restart

Terminates lhcd, and then starts lhcd.

force-reload

Terminates lhcd, and then starts lhcd.

generate_config

Deletes the configuration file of the form, if it exists, and then regenerates it by executing the file `lhcdConfig.gen` in the `/opt/bladeServices/etc/lhc` directory.

Environment Variables



You do not need to explicitly set the following variables. Under normal operating conditions the init script sets the environmental variables by executing `/etc/default/hpmvars`.

SHELF_NUMBER	Specifies the shelf number used with the lhcd -f option.
SLOT_NUMBER	Specifies the logical slot number of the blade used with the lhcd -s option.
SITE_NUMBER	Specifies the site number used with the lhcd -t option.

6.5 lhcd—LHC Command Line Utility

Description

The LHC command utility, `lhccmd`, provides shell-level access to the LHC daemon management component (`lhcd`) for LHC configuration and monitoring.

Synopsis

`lhccmd [-v]`

lhccmd command

Parameters

-v

Shows version of lhccmd. Also displays version of lhcd if it is running.

6.5.1 Command Overview

The following table lists the commands provided by the lhccmd utility. For complete command information, see [Available Commands on page 121](#).

Command	Description	Command Reference
get objectName index	MIB Get	get on page 122
get tableName index	MIB Getrow	get on page 122
help ?	Print usage information	help on page 122
index tableName	Show MIB index information for a table	index on page 122
loglevel 0...7	Set/Show log level	loglevel on page 123
mem dump	Dump LEAP memory	
mem ignore	Ignore allocated LEAP memory	
mem unignore	Un-ignore all LEAP memory	
next objectName index	MIB Next	next on page 124
next tableName index	MIB Nextrow	next on page 124
objects tableName	Show MIB object IDs for table	objects on page 125
quit q exit	Exit	exit q quit on page 121
set objectName index value_keyword	MIB Enumerated Value Set	set on page 125
setc objectName index "value"	MIB Character String Set	set on page 125
seti objectName index value	MIB Integer Set	set on page 125
seto objectName index value	MIB Octet String Set	set on page 125

Command	Description	Command Reference
tables	Show MIB table IDs	tables on page 126
values objectName	Show values for MIB object	values on page 126
version	Display version information	version on page 127
walk tableName	MIB table Walk	walk on page 127

6.5.2 Command Usage for Common Parameters

Many commands support common parameters to specify MIB objects to operate on. The common command parameters include:

- **tablename**
Name of a MIB table. For specific values, use the `lhccmd tables` command. The `tableName` parameter is case-sensitive. Table names must be entered exactly as they appear in the MIB.
- **objectName**
Name of a MIB object within a table. For specific values, use the `lhccmd objects tableName` command, where `tableName` is the name of a specific table. The `objectName` parameter is case-sensitive. Object names must be entered exactly as they appear in the MIB.
- **index**
MIB index as a sequence of numbers (for example, 2.1.1.12). The format of the index parameter is a dot-separated group of fields. In general, each field of the index is a single 32-bit value. However, fields that denote a MAC address or an IP address have multiple dot-separated elements.
A MAC address has six elements; each element is eight bits of the 48-bit MAC address. Note that MAC addresses are ordinarily expressed as a sequence of hexadecimal octets, for example: 00.0E.83.EB.33.6F. To indicate that an index element is a hexadecimal value, prefix it with "0x" as follows: 0x00.0x0E.0x83.0xEB.0x33.0x6F.

The fields that make up index vary for each type of object, as described in the following table. For more information about specific indices, refer to the LHC MIB `/opt/ bladeservices/mibs/LHC-MIB.txt`.

MIB Table	Index Format
lhTable	shelf.slot.site
lhComTable	shelf.slot.site.instance
lhProctorTable	shelf.slot.site.instance
lhResponderTable	shelf.slot.site.instance
lhL2InterfaceTable	shelf.slot.site.instance.L2interfaceindex
lhProctorL2InterfaceTable	shelf.slot.site.instance.L2interfaceindex
lhProctorResponderGroupTable	shelf.slot.site.instance.L2interfaceindex.RGL2address
lhProctorExpectedResponderTable	shelf.slot.site.instance.L2interfaceindex.RGL2address.ERshelf.Erslot.Ersite
lhAuthorizedProctorTable	shelf.slot.site.instance.L2interfaceindex.RGL2address.APshelf.APslot.APsite

- value
Value to set for a read-write object. For specific values, see the LHC MIB `/opt/ bladeservices/mibs/LHC-MIB.txt`.

6.5.3 Available Commands

This section lists the supported commands.

6.5.3.1 exit | q | quit

Description

Terminates lhcd. MIB tables for status and control of LHC are destroyed.

Synopsis

exit
q
quit

6.5.3.2 get

Description

This command gets the specified MIB object or table row. Depending on whether `objectName` or `tableName` is used, the command corresponds to a MIB get or MIB getrow command.

Synopsis

```
get [objectName] [index]
get [tableName] [index]
```

Parameters

`objectName`

See [Command Usage for Common Parameters on page 120](#).

`tableName`

See [Command Usage for Common Parameters on page 120](#).

`index`

See [Command Usage for Common Parameters on page 120](#).

6.5.3.3 help

Description

This command displays all available commands.

Synopsis

```
help <command>
?
```

6.5.3.4 index

Description

This command displays the list of elements that make up the MIB index for the table name provided as an argument. For each index element, the number of 32-bit values required for the element appears in parentheses. For example, an IP address will use four 32-bit values (x.x.x.x) when appearing in a MIB index.

Synopsis

```
index [tableName]
```

Parameters

tableName

See [Command Usage for Common Parameters](#) on page 120.

6.5.3.5 loglevel

Description

This command is used to set the LHC level.

Synopsis

```
loglevel [level]
```

Parameters

level

Is a valid syslog log level from 0 to 7.

All log messages with a level equal to or numerically lower than the selected level will appear in the system log file. A value of 0 indicates that only the most critical log messages will appear. A value of 7 indicates that all log messages will appear.

Log Level	Description
0	Emergency
1	Alert
2	Critical
3	Error
4	Warning
5	Notice (default)
6	Information
7	Debug

6.5.3.6 next

Description

This command gets the next MIB object or table row after the specified object or table row. Depending on whether `objectName` or `tableName` is used, the command corresponds to a MIB `next` or MIB `nextrow` command.

Synopsis

```
next [objectName] [index]
next [tableName] [index]
```

Parameters

`objectName`

See [Command Usage for Common Parameters on page 120](#).

`index`

See [Command Usage for Common Parameters on page 120](#).

6.5.3.7 objects

Description

This command displays a list of MIB objects within lhcd.

Synopsis

```
objects [tableName]
```

Parameters

tableName

See [Command Usage for Common Parameters on page 120](#).

6.5.3.8 set

Description

This command sets the value of a specified object.

Synopsis

```
set [objectName] [index] [value_keyword]  
seti [objectName] [index] [value]  
setc [objectName] [index] [\"value\"]  
seto [objectName] [index] [value]
```

Parameters

objectName

See [Command Usage for Common Parameters on page 120](#).

index

See [Command Usage for Common Parameters on page 120](#).

value

See [Command Usage for Common Parameters on page 120](#).

Command	Description
<code>set</code>	<p>Enumerated value set. This command sets the requested MIB object to the integer value associated with the <code>value_keyword</code> argument, where <code>value_keyword</code> is the textual representation of the integer value as defined in LHC-MIB. Allowable values are found in the SYNTAX section of a particular MIB object. Values for <code>value_keyword</code> are case-sensitive.</p> <p>For example, the SYNTAX of <code>lhcRole</code> is defined by the MIB as:</p> <pre>SYNTAX lhcRole</pre> <p>To set <code>lhcRowStatus</code> for index 2.2.255.1 to up, either of the following two commands may be used:</p> <pre>seti lhcRowStatus 2.2.255.1 1 (integer set) set lhcRowStatus 2.2.255.1 up (enumerated value set)</pre>
<code>seti</code>	<p>Integer set. Sets the object using an integer value, where value in this case is a specific integer. Value may be a decimal integer or hexadecimal integer (that is, preceded by 0x, for example, 0x100).</p>
<code>setc</code>	<p>Character string set. Sets the object using a character string, where value in this case is a character string. Double quotes are a required part of the command syntax.</p> <p>When used with <code>lhccmd</code> from a shell prompt or shell script, the double quotes must be escaped by using backslashes before each double quote or by enclosing the quoted value in single quotes.</p>
<code>seto</code>	<p>Octet string set. Sets the object using an octet string, where value in this case is a dot separated hexadecimal string of the form <code>hh.hh...hh</code>, for example, <code>FF.01.02.A1</code>.</p>

6.5.3.9 tables

Description

This command displays a list of MIB tables supported by `lhcd`.

Synopsis

```
tables
```

6.5.3.10 values

Description

When an object is defined in the MIB as having an enumerated list of integer values, this command will display both the text (which may be provided as the value argument in the `lhccmd set` command) and the associated integer value (which may be provided as the value argument in the `lhccmd seti` command).

Synopsis

```
values [objectName]
```

Parameters

objectName

See [Command Usage for Common Parameters on page 120](#).

6.5.3.11 version

Description

Displays the version of the loaded lhcd executable.

Synopsis

```
version
```

6.5.3.12 walk

Description

This command walks the specified MIB table, displaying every row.

Synopsis

```
walk [tableName]
```

Parameters

tableName

See [Command Usage for Common Parameters on page 120](#).

6.6 LHC Configuration Script and Configuration File

LHC ships with a configuration script called `lhcConfig.gen`. It is located at `/opt/bladervices/etc/lhc/`. The first time the LHC start-stop script (see [lhc—lhcd Start-Stop Script on page 116](#)) is used to start the LHC daemon, the configuration script is executed and generates a configuration file with a name of the format `lhc.<shelf>.<slot>.<site>.cfg`. The start-stop script then starts the LHC daemon, passing the generated configuration file name as a command line argument. The LHC daemon reads in the generated configuration file in order to learn its initial configuration.



The `lhc` start-stop script checks for the existence of the generated configuration file. If a configuration file exists, the `lhc` start-stop script does not regenerate a configuration file from the configuration script.

6.7 LHC Fault Management

LHC exists as an aid to Fault Management (FM). LHC checks that the internal system network links are healthy, and reports failure and subsequent recovery of the links. Additionally, LHC is responsible for ensuring that all blades in a system use the same network plane. When FM (or some other entity) on a system controller determines that a switchover of the active network plane must be performed, LHC proctor is notified via its API. LHC then distributes the current active network plane to all blades in the system. On a ATCA-7107 or ATCA-7221 payload blade (responder), the LHC daemon receives the QUERY message indicating that the active plane has changed. LHC informs FM via an "active plane" FM notification. It is then up to the FM software to decide what to do.

6.7.1 Determining to Change Active Network Plane

When FM receives a "RESPONSE delinquent" or "QUERY delinquent" notification, it is an indication that there is a link failure to the blade identified in the notification. Either of these notifications could cause FM to decide to switchover the active network plane.

6.7.2 Controlling the Active Network Plane

If FM decides to switchover the active network plane, a MIB set communicates this fact to LHC. The following LHC command may be used to set the MIB variable, or an actual MIB set could be used: `lhccmd seti lhcProctorRequestedActivePlane 1.2.255.1 2`

This command would tell the (local) Proctor with indexing <shelf 1, slot 2, site 255, instance 1> to make plane 2 the active network plane.

6.7.3 Monitoring for Changes to the Active Network Plane

When LHC determines that an active network plane switchover has occurred, LHC generates an “Active Plane” FM notification. The same FM notification is generated whether the LHC role is Proctor or Responder.

6.7.4 Fault Management Notifications

When LHC detects a fault, LHC generates a Fault Management notification. LHC uses syslog to send the notifications to FM. Each FM notification begins with the standard syslog preamble including timestamp, followed by the string "LHC #<instance number>:" where <instance number> is the LHC instance number as used in the MIB indexing. The rest of the notification varies depending upon what fault is being notified. The format of each notification is shown in the following table.

Name	Definition/Semantics	Syntax	Dependencies
Active Plane	Inform which plane is active	LHC #<inst_num>: active plane <plane_num>, originator sh <shelf> sl <slot> st <site> serial <ser_num>	-
Config file not found	The configuration file specified on the command line was not found.	LHC: Config file (<file_name>) not found, errno=<error_number>	-
Duplicate Response	RESPONSE message has been received with the same sequence number from the same source.	LHC #<inst_num>: RESPONSE duplicate <eth_name>/<shelf>/<slot>/<site>/<mcast_mac_address> seq_num=<sequence_num> src MAC=<source mac address>	-
Late or spurious response	RESPONSE message was received containing an unknown sequence number. The message either arrived late or was sent in error.	LHC #<inst_num>: RESPONSE late or spurious <eth_name>/<shelf>/<slot>/<site>/<mcast_mac_address> seq_num=<sequence_num> src MAC=<source mac address>	-
Layer 2 connection failed	The layer 2 connection failed to open. LHC will not be able to communicate on the indicated interface.	LHC #<inst_num>: L2 connection (<eth_name>) failed with error <error_number>	-
Layer 2 connection restored	The layer 2 connection that previously failed has now been successfully opened.	LHC #<inst_num>: L2 connection (<eth_name>) restored	-

Name	Definition/Semantics	Syntax	Dependencies
QUERY Delinquent	QUERY message has not been received from an authorized proctor	LHC #<inst_num>: QUERY delinquent <eth_name>/<shelf>/<slot>/<site>/<mcast_mac_address>	For a particular Authorized Proctor, once this notification appears, it will not appear again until the "QUERY Received" notification appears
QUERY Received	QUERY message has been received from an authorized proctor	LHC #<inst_num>: QUERY received <eth_name>/<shelf>/<slot>/<site>/<mcast_mac_address>	For a particular Authorized Proctor, once this notification appears, it will not appear again until the "QUERY Delinquent" notification appears
QUERY from unauthorized proctor	QUERY message has been received from an unauthorized proctor	LHC #<inst_num>: QUERY from unauthorized proctor <eth_name>/<shelf>/<slot>/<site>/<mcast_mac_address>	-

Name	Definition/Semantics	Syntax	Dependencies
RESPONSE Delinquent	RESPONSE message not received from an expected responder	LHC #<inst_num>: RESPONSE delinquent <eth_name>/<shelf>/<slot>/<site>/<mcast_mac_address>	For a particular expected responder, once this notification appears, it will not appear again until the "RESPONSE received" notification appears
RESPONSE Received	RESPONSE message has been received from an expected responder	LHC #<inst_num>: RESPONSE received <eth_name>/<shelf>/<slot>/<site>/<mcast_mac_address>	For a particular expected responder, once this notification appears, it will not appear again until the "RESPONSE Delinquent" notification appears
RESPONSE from unexpected responder	RESPONSE message has been received from an unexpected responder	LHC #<inst_num>: RESPONSE from unexpected responder <eth_name>/<shelf>/<slot>/<site>	-
Src MAC address changed	The source MAC address in the QUERY message is different from the MAC address received in the previous QUERY. This could indicate a misconfiguration, i.e., two proctors are configured with the same shelf/slot/site.	LHC <inst_num>: src MAC changed since last QUERY <eth_name>/<shelf>/<slot>/<site>/<mcast_mac_address> new MAC=<new mac address> prev MAC=<previous mac address>	

6.8 LHC Configuration Examples

This section provides some examples on how to configure LHC. LHC configuration is done via the LHC MIB.

An L2 Interface entry represents an L2 interface, such as eth2, or a VLAN on an L2 interface, such as eth2.21. A Responder Group entry represents an LHC QUERY message sent to a configured MAC address (usually a multicast address) on a periodic basis, to which some number of Expected Responders should respond with an LHC RESPONSE message. An Expected Responder entry represents an entity from whom an LHC RESPONSE message is expected to be received. An Authorized Proctor entry represents an entity from whom an LHC QUERY message is expected and allowed to be received.

The examples in this section are all based on the following single shelf system (shelf #1). Configuration of only the base interface is shown, whereas normally, the base and fabric interfaces are configured. The example single shelf system contains two switches (in logical slots 1 & 2) and two payload blades (in logical slots 4 & 5). Node blade #4 is a "standard" blade, while #5 is a carrier blade with two AMCs (in sites 7 & 8). On SCxB #1, VLAN eth0.21 connects to the node blades and SCxB #2 while VLAN eth0.22 connects to SCxB #2. On node blade #4, eth0 connects to SCxB #1 and eth1 connects to SCxB #2. On Node blade #5 baseboard processor, eth0.21 connects to SCxB #1, eth0.35 connects to AMC #7 and AMC #8. On the AMCs, eth0.35 connects to the baseboard processor. Note that the site number in MIB indexing for non-AMCs is 255.

6.8.1 Proctor Configuration Examples

Configuration for a proctor involves creating L2 Interfaces, responder groups, expected responders, and typically, authorized proctors.

LHC Instance #1 is created with role proctor. (shelf 1 slot 1 site 255 instance 1)

```
lhccmd set lhcRowStatus 1.1.255.1 createAndWait
lhcccmd set lhcRole      1.1.255.1 proctor
lhccmd set lhcRowStatus 1.1.255.1 active
```

Two L2 interfaces are created within the LHC instance #1, interface #1 for eth0.21 and #2 for eth0.22. (shelf 1 slot 1 site 255 instance 1 index 1) and (shelf 1 slot 1 site 255 instance 1 index 2).

```
lhccmd set   lhcL2InterfaceRowStatus   1.1.255.1.1   createAndWait
lhccmd setc  lhcL2InterfaceName        1.1.255.1.1   \"eth0.21\"
lhccmd set   lhcL2InterfaceRowStatus   1.1.255.1.1   active
lhccmd set   lhcL2IntefaceRowStatus    1.1.255.1.2   createAndWait
lhccmd setc  lhcL2InterfaceName        1.1.255.1.2   \"eth0.22\"
lhccmd set   lhcL2InterfaceRowStatus   1.1.255.1.2   active
```

Within interface #1, create a single responder group #1 with destination MAC address 01.c0.f9.00.00.01. This responder group fields RESPONSE messages from the payload blades and SCxB #2. (shelf 1 slot 1 site 255 instance 1 index 1 MAC 01c0f9000001)

```
lhccmd set   lhcProctorResponderGroupRowStatus
              1.1.255.1.1.0x01.0xc0.0xf9.0x00.0x00.0x01
createAndGo
```

Within that Responder Group, create three expected responders to represent the two payload blades and SCxB #2. (shelf 1 slot 1 site 255 instance 1 index 1 MAC 01c0f9000001 ERshelf 1 ERslot 2 ERsite 255) and (shelf 1 slot 1 site 255 instance 1 index 1 MAC 01c0f9000001 ERshelf 1 ERslot 4 ERsite 255) and (shelf 1 slot 1 site 255 instance 1 index 1 MAC 01c0f9000001 ERshelf 1 ERslot 5 ERsite 255)

```
lhccmd set   lhcProctorExpectedResponderRowStatus
              1.1.255.1.1.0x01.0xc0.0xf9.0x00.0x00.0x01.1.2.255
createAndGo
```

```
lhccmd set   lhcProctorExpectedResonderRowStatus
              1.1.255.1.1.0x01.0xc0.0xf9.0x00.0x00.0x01.1.4.255
createAndGo
```

```
lhccmd set   lhcProctorExpectedResponderRowStatus
              1.1.255.1.1.0x01.0xc0.0xf9.0x00.0x00.0x01.1.5.255
createAndGo
```

Within interface #2, create an authorized proctor #1 with destination MAC address 01.c0.f9.00.00.01. This AP fields QUERY messages from SCxB #2. (shelf 1 slot 1 site 255 instance 1 index 2 MAC 01c0f9000001 APshelf 1 APslot 2 APsite 255)

```

lhccmd set    lhcAuthorizedProctorRowStatus
            1.1.255.1.2.0x01.0xc0.0xf9.0x00.0x00.0x01.1.2.255
createAndWait

lhccmd set    lhcAuthorizedProctorGuardTimerEnable
            1.1.255.1.2.0x01.0xc0.0xf9.0x00.0x00.0x01.1.2.255    true

lhccmd set    lhcProctorExpectedResponderRowStatus
            1.1.255.1.2.0x01.0xc0.0xf9.0x00.0x00.0x01.1.2.255    active

```

6.8.2 Responder Configuration Examples

Configuration for a responder involves creating L2 Interfaces and authorized proctors.

LHC Instance #1 is created with role responder. (shelf 1 slot 4 site 255 instance 1)

```

lhccmd set    lhcRowStatus      1.4.255.1      createAndWait
lhccmd set    lhcRole           1.4.255.1      responder
lhccmd set    lhcRowStatus      1.4.255.1      active

```

Two L2 interfaces are created within LHC instance#1, interface#1 for eth0 and #2 for eth1. (shelf1 slot 4 site 255 instance 1 index 1) and (shelf 1 slot 4 site 255 instance 1 index 2)

```

lhccmd set    lhcL2InterfaceRowStatus 1.4.255.1.1 createAndWait
lhccmd setc   lhcL2InterfaceName      1.4.255.1.1 \"eth0\"
lhccmd set    lhcL2InterfaceName      1.4.255.1.1 active
lhccmd set    lhcL2InterfaceRowStatus 1.4.255.1.2 createAndWait
lhccmd setc   lhcL2InterfaceName      1.4.255.1.2 \"eth1\"
lhccmd set    lhcL2InterfaceRowStatus 1.4.255.1.2 active

```

Within interface #1, create a single authorized proctor #1 with destination MAC address 01.c0.f9.00.00.1. This AP fields QUERY messages from SCxB #1. (shelf 1 slot 4 site 255 instance 1 index 1 MAC 01c0f9000001 APshelf 1 APslot 1 APsite 255)

```
lhccmd set   lhcAuthorizedProctorRowStatus
           1.4.255.1.1.0x01.0xc0.0xf9.0x00.0x00.0x01.1.1.255
createAndWait

lhccmd set   lhcAuthorizedProctorGuardTimerEnable
           1.4.255.1.1.0x01.0xc0.0xf9.0x00.0x00.0x01.1.1.255 true

lhccmd set   lhcAuthorizedProctorRowStatus
           1.4.255.1.1.0x01.0xc0.0xf9.0x00.0x00.0x01.1.1.255 active
```

Within interface #2, create a single authorized proctor #1 with destination MAC address 01.c0.f9.00.00.01. This AP fields QUERY messages from SCxB#2. (shelf 1 slot 4 site 255 instance 1 index 2 MAC 01c0f9000001 AP shelf 1 APslot 2 AP site 255)

Within interface #2, create a single authorized proctor #1 with destination MAC address 01.c0.f9.00.00.01. This AP fields QUERY messages from SCxB #2. (shelf 1 slot 4 site 255 instance 1 index 2 MAC 01c0f9000001 APshelf 1 APslot 2 APsite 255)

```
lhccmd set   lhcAuthorizedProctorRowStatus
           1.4.255.1.2.0x01.0xc0.0xf9.0x00.0x00.0x01.1.1.2.255
createAndWait

lhccmd set   lhcAuthorizedProctorGuardTimerEnable
           1.4.255.1.2.0x01.0xc0.0xf9.0x00.0x00.0x01.1.2.255 true

lhccmd set   lhcAuthorizedProctorRowStatus
           1.4.255.1.1.0x01.0xc0.0xf9.0x00.0x00.0x01.1.2.255 active
```

6.8.3 Baseboard Processor on Carrier Blade Configuration Example

Configuration on a carrier blade baseboard processor involves creating two LHC instances, one with role responder to handle the LHC conversation to the SCxBs and one with role proctor to handle the LHC conversation to the AMCs.

LHC Instance #1 is created with role proctor (shelf 1 slot 5 site 255 instance 1).

```
lhccmd set   lhcRowStatus 1.5.255.1. proctor

lhccmd set   lhcRole 1.5.255.1 proctor

lhccmd set   lhcRowStatus 1.5.255.1 active
```

One L2 Interface is created within LHC instance #1, interface #1 for eth0.35 (shelf 1 slot 5 site 255 instance 1 index 1).

```
lhccmd set  lhcL2InterfaceRowStatus 1.5.255.1.1 createAndWait
```

```
lhccmd setc lhcL2InterfaceName1.5.255.1.1 \"eth0.35\"
```

```
lhccmd set  lhcL2InterfaceRowStatus 1.5.255.1.1 active
```

Within interface #1, create a single responder Group #1 with destination MAC address 01.c0.f9.00.00.01. This Responder Group fields RESPONSE messages from the AMCs. (shelf 1 slot 5 site 255 instance 1 index 1 MAC 01c0f9000001)

```
lhccmd set  lhcProctorResponderGroupRowStatus
            1.5.255.1.10x01.0xc0.0xf9.0x00.0x00.0x01 createAndGo
```

Within that responder group, create two expected responders to represent the two AMCs. (shelf 1 slot 5 site 255 instance 1 index 1 MAC 01c0f9000001 ERshelf 1 ERslot 5 ERsite 7) and (shelf 1 slot 5 site 255 instance 1 index 1 MAC 01c0f9000001 ERshelf 1 ERslot 5 ERsite 8)

```
lhccmd set  lhcProtorExpectedResponderRowStatus
            1.5.255.1.1.0x01.0xc0.0xf9.0x00.0x00.0x01.1.1.5.7
createAndGo
```

```
lhccmd set  lhcProctorExpectedResponderRowStatus
            1.5.255.1.1.0x01.0xc0.0xf9.0x00.0x00.0x01.1.1.5.8
createAndGo
```

LHC Instance #2 is created with role responder. (shelf 1 slot 5 site 255 instance 2)

```
lhccmd set  lhcRowStatus                1.5.255.2                createAndWait
```

```
lhccmd set  lhcRole                      1.5.255.2                responder
```

```
lhccmd set  lhcRowStatus                1.5.255.2                active
```

One L2 Interface is created within LHC instance #2, interface #1 for eth0.21. (shelf 1 slot 5 site 255 instance 2 index 1)

```
lhccmd set  lhcL2InterfaceRowStatus 1.5.255.2.1                createAndWait
```

```
lhccmd setc lhcL2InterfaceName        1.5.255.2.1                \"eth0.21\"
```

```
lhccmd set   lhcL2InterfaceRowStatus 1.5.255.2.1      active
```

Within interface #1, create an authorized proctor #1 with destination MAC address 01.c0.f9.00.00.01. This AP fields QUERY messages from SCxB #1 (shelf 1 slot 5 site 255 instance 2 index 1 APshelf 1 APslot 1 APsite 255).

```
lhccmd set   lhcAuthorizedProctorRowStatus
              1.5.255.2.1.0xc0.0xf9.0x00.0x00.0x01.1.1.255
createAndWait
```

```
lhccmd set   lhcAuthorizedProctorGuardTimerEnable
              1.5.255.2.1.0xc0.0xf9.0x00.0x00.0x01.1.1.255      true
```

```
lhccmd set   lhcAuthorizedProctorRowStatus
              1.5.255.2.1.0xc0.0xf9.0x00.0x00.0x01.1.1.255      active
```

6.8.4 AMC/PMC Module on Carrier Blade Configuration Example

The configuration on an AMC/PMC is similar to a standard payload blade except that there is only a single L2 interface for the base. The two AMC/PMC modules have duplicate configurations except for the site number, so only AMC/PMC #7 is shown here.

LHC Instance #1 is created with the role responder. (shelf 1 slot 5 site 7 instance 1)

```
lhccmd set   lhcTRowStatus          1.5.7.1      createAndWait
```

```
lhccmd set   lhcRole                1.5.7.1      responder
```

```
lhccmd set   lhcRowStatus           1.5.7.1      active
```

One L2 Interface is created within LHC instance #1, interface #1 for eth0.35. (shelf 1 slot 5 site 7 instance 1 index 1)

```
lhccmd set   lhcL2InterfaceRowStatus 1.5.7.1.1    createAndWait
```

```
lhccmd setc  lhcL2InterfaceName      1.5.7.1.1    \"eth0.35\"
```

```
lhccmd set   lhcL2InterfaceRowStatus 1.5.7.1.1    active
```

Within interface #1, create a single authorized proctor #1 with destination MAC address 01.c0.f9.00.00.01. This AP fields QUERY messages from the baseboard processor. (shelf 1 slot 5 site 7 instance 1 index 1 MAC 01c0f9000001 APshelf 1 APslot 5 APsite 255)

```

lhccmd set  lhcAuthorizedProctorRowStatus
            1.5.7.1.1.0xc0.0xf9.0x00.0x00.0x01.1.5.255
createAndWait

lhccmd set  lhcAuthorizedProctorGuardTimerEnable
            1.5.7.1.1.0xc0.0xf9.0x00.0x00.0x01.1.5.255            true

lhccmd set  lhcAuthorizedProctorRowStatus
            1.5.7.1.1.0xc0.0xf9.0x00.0x00.0x01.1.5.255            active

```

6.8.5 Leaky Bucket Description and Configuration Example

LHC uses a 'leaky bucket' mechanism (described below) to give the user control over the frequency of certain FM notifications. The FM notifications that have this control are:

- RESPONSE Delinquent
- RESPONSE Received
- QUERY Delinquent
- QUERY Received

There are two independent leaky buckets, one that controls the RESPONSE pair of FM notifications and one that controls the QUERY pair of FM notifications.

There are two writable MIB objects to control each leaky bucket: upper threshold (UT) and lower threshold (LT). The UT and LT are controlled on a per-responder group and per-authorized proctor basis.

The following description applies to both the RESPONSE leaky bucket and the QUERY leaky bucket, but is described from the RESPONSE leaky bucket perspective.

When a proctor sends a QUERY message, a response timer is started. Each time that the response timer expires, if a RESPONSE message has not been received from an expected responder (ER), then a drop is added to the leaky bucket for that ER. If a RESPONSE message is received from an ER, then a drop is removed from the leaky bucket for that ER. The bucket size does not go below zero and does not get larger than the UT. LHC uses an internal variable to track whether the most recent FM notification was "Delinquent" or "Received". If upon adding a

drop to the leaky bucket it equals UT and the most recent notification was "Received", then a "Delinquent" notification is generated. If upon removing a drop from the leaky bucket it equals LT and the most recent notification was "Delinquent" then a "Received" notification is generated.

By changing the UT and LT values, one can control the frequency of FM notifications such that not every dropped RESPONSE or QUERY is reported and that the reception of a single RESPONSE or QUERY is reported.

HPI-B Software

7.1 Overview

To help ease the implementation of highly available systems with off-the-shelf building blocks, the Service Availability Forum (SA Forum) Hardware Platform Interface (HPI) specification HPI-B defines a set of platform-independent programming interfaces to monitor and control systems, such as AdvancedTCA systems, designed to provide high availability. HPI provides applications and middleware a consistent, standardized interface for managing hardware components.

This BBS release contains an HPI-B library package. For more information on Artesyn Embedded Technologies's HPI-B implementation, refer to the *System Management Interface Based on HPI-B User's Guide*.

Board Control Module

8.1 Overview

Board control is a kernel module which provides access to the board FPGA. The board control module creates a boardinfo directory in the `/proc` file system that contains general information on the ATCA-7367. The following table describes the information in boardinfo directory.

File	Description	Sample output
<code>bios_releasedate</code>	Shows the release date of the currently installed BIOS.	05/14/2010
<code>board_name</code>	Shows the board name, as provided by the BIOS.	ATCA-7367
<code>board_version</code>	Shows the board version, as provided by the BIOS.	0106865F01A

File	Description	Sample output
bios_version	Shows the BIOS version.	1.0.0
board_serialn umber	Shows the serial number of the board, as provided by the BIOS.	ENG00177
fpga	Shows additional FPGA information.	FPGA version: 0x0B . . .
summary	Shows a summary of the board state (FPGA registers) and BIOS provided information.	<pre> Board Vendor: Emerson Board Name: ATCA-7367 Board Version: 0106865F01A.... Board Serial Number: ENG00177.... BIOS Vendor: Emerson BIOS Version: 0.0.25G BETA BIOS Release Date: 12/09/2009 Last Reset Source: PowerOn CPU IPMI Cold Reset Memory Module: Device/Bank: DIMM_Socket_P01/Node0_Channel0_Dim m0 Size: 2048 Mbyte Data Width: 64 Bit Manufacturer: A1_Manufacturer0 Memory Module: Device/Bank: DIMM_Socket_P11/Node1_Channel0_Dim m0 Size: 2048 Mbyte Data Width: 64 Bit Manufacturer: A2_Manufacturer0 IPMI Interface Type: 1 KCS (Keyboard Control Style) IPMI Spec Rev: 2.0 I2C Slave Addr: 0x9A NV Stor.Dev.Addr: Not Present Base Addr: 0x00000CA3 IRQ: 0x0 </pre>

8.2 Board Control Tool

The board control module provides an IOCTL interface which can be used by the userland applications. The following sections describes userland applications, such as LEDCTRL and FPGA_TEST.

8.2.1 LEDCTRL

Description

Allows to control the 3 front panel LEDs, according to their capabilities.

LEDCTRL can be found at `/opt/bladeservices/bin/ledctrl`.

Synopsis

```
ledctl [options] [led1] [led2] ...
```

Here, `led<n>` are zero-based LED numbers. If no LED numbers are given, the option is applied to all the available LEDs.

The options can have following values.

Option	Description
-n	Print number of available LEDs.
-i	Display information about LED capabilities.
-s	Print current LED settings.
-c <color>	Set LED(s) <color> to: g[reen], y[ellow], r[ed], b[lue], a[mber], hdd, or eth.
-b <freq>	Set blink frequency to: off or p[ermanent].

8.2.2 FPGA_TEST

Description

Dumps the FPGA register set.

FPGA_TEST can be found at `/opt/bladeservices/bin/fpga_test`.

Synopsis

```
fpga_test -d
```

Here, -d option is used to dump the complete FPGA register set.

Clock Agent Command Module

9.1 Overview

The clock agent command module provides a CLI for configuring ATCA-7367 to route and generate clock signals. The clock agent command module is delivered as `bbs-clkagentcmd-atca7367-1.0.0-1-pne30.rpm`. This rpm contains the following files:

- `/opt/bladeservices/bin/clkcml` - Contains the clock command CLI.
- `/opt/bladeservices/etc/clkconf` - Contains the clock configuration sample script that is based-on the clock command CLI.

The clock command CLI allows to setup most common clock configurations. If the blade acts as a line card, the clock agent implements a set of Line Card Control Block (LCCB) commands.

The clock command also provides an option to continuously check the LCCB status and reporting it in the syslog. It also allows to perform automatic clock configuration based-on AMC presence, AMC type, and logical slot position where the blade is installed.

9.2 clkcml

You can use the `clkcml` command as:

```
clkcml [-L] <command> [<arg>] [<options>]
```

The `-L` option is used for LCCB commands only. Refer [Table 9-2](#), for the options used by LCCB.

[Table 9-1](#) describes the commands and options available with the `clkcml` command.

Table 9-1 Clock commands and options

Commands and Options	Description
<code>-h</code>	Displays help for the <code>clkcml</code> command.
<code>-vh</code>	Displays help for the <code>clkcml</code> command along with detailed examples.
<code>-L</code>	To run the LCCB command subset. It is required to setup and query LCCB.
<code>-e</code>	Enables clock buffers or specified mode/auto configuration.
<code>-d</code>	Disables clock buffers or specified mode/auto configuration.

Table 9-1 Clock commands and options (continued)

Commands and Options	Description
-r <rclk>	Sets the source for the reference clock. Requires source clock to be specified using the -c option.
-s <sclk>	Sets the system clock to be equal to <sclk>.
-g	Gets the status. This option can be used along with the -c <clock> or -m <mode> to get the clock status (static/toggle) or the current mode setup.
-c <clk>	Specifies the clock to be enabled or queried.
-m <mode>	Specifies the generic mode to be enabled.
-M <conf>	Specifies the generic auto configuration mode to be activated.
-l	Lists different entities, such as clock, modes, and configuration. It requires the related entity option to be specified, such as -l -c all.
-v	Increases the verbose output level(maximum level 3).

Table 9-2 describes the commands and options available with the -L option for LCCB commands.

Table 9-2 Clock commands and options, for LCCB only

Commands and Options	Description
-m	Setup the LCCB operating mode.
-D	Setup the default LCCB configuration.
-c <clock> -f <freq>	Setup the LCCB clock output to generate frequency <freq>.
-s <sclk>	Setup the LCCB to work with system clock <sclk>.
-x	Start the status daemon.

9.2.1 Enable Clock Buffer

Description

This command enables the clock buffer for the specified clock id.

Synopsis

```
clkcmd -e -c <clock>
```

Parameters

You can enable the clock buffers for the following clock ids.

- CLK1A
- CLK1B
- CLK2A
- CLK2B
- CLK3A
- CLK3B
- AMC1_TCLKA
- AMC1_TCLKC
- RTM_TCLKA
- RTM_TCLKC



You can not enable CLKxA and CLKxB at the same time, with different frequencies. CLKxA and CLKxB are intended to provide redundancy, in case of a switchover. Hence, CLKxA and CLKxB must use the same frequency.

Example

To enable the clock buffer related to clock 1A.

```
clkcmd -e -c CLK1A
```

9.2.2 Enable Clock Routing Mode

Description

This command enables the clock routing mode.

Synopsis

```
clkcmd [-e] -m <mode>
```

Parameters

Table 9-3, describes the clock routing mode ids.

Table 9-3 Routing mode ids

Mode id	Description
AMC_CGM_MODE	Enables the CGM mode for the ATCA-7367 blade only.
AMC_LINECARD_MODE	Enables the line card mode (default) for the ATCA-7367 blade only.

Example

To enable the clock routing master chassis mode.

```
clkcmd -e -m AMC_CGM_MODE
```

9.2.3 Automatic Configuration

Description

This command enables the automatic configuration.

Synopsis

```
clkcmd -e -M <conf id>
```

Parameters

You can use `AUTO_CONF_1` conf id to automatically detect the presence of the AMC, its type (CGM or not), and the slot position (left/right logical slot position). Based on this information it performs following setup:

- If AMC in the bay is CGM - set the AMC CGM mode.
 - If left AMC slot (odd slot) - enable clock buffer 1A and 2A.
 - If right AMC slot (even slot) - enable clock buffer 1B and 2B.
- If AMC in the bay is Line Card or not present - set system clock to CLK1.

9.2.4 LCCB Mode

Description

This command sets the SONET or SDH mode in LCCB.

Synopsis

```
clkcmd -L -m <LCCB mode id>
```

Parameters

[Table 9-4](#), describes the LCCB mode id.

Table 9-4 LCCB mode id

Mode id	Description
SDH	Setup the on-board LCCB to work in SDH mode.
SONET	Setup the on-board LCCB to work in SONET mode.

Example

To set the LCCB operating mode to SONET.

```
clkcmd -L -m SONET
```

9.2.5 Reference Clock Selection

Description

This command allows to select the source for the reference clocks; 3A and 3B.

Synopsis

```
clkcmd -r <ref_clock> -c <src_clock>
```

Parameters

Table 9-5, describes the combinations of the reference clock and related source setup.

Table 9-5 Reference and source clock ids

Clock reference id	Clock source id	Description
CLK3A	RCVD_AMC1	Set the source for clock 3A equal to the recovered clock from AMC bay.
	RCVD_RTM	Set the source for clock 3A equal to the recovered clock from RTM.
CLK3B	RCVD_AMC1	Set the source for clock 3B equal to the recovered clock from AMC bay.
	RCVD_RTM	Set the source for clock 3B equal to the recovered clock from RTM.

Example

To set the source of reference clock 3A equal to the recovered clock from AMC bay 1.

```
clkcmd -r CLK3A -c RCVD_AMC1
```

9.2.6 System Clock Selection

Description

This command allows you to select the system clock; 1 or 2.

Synopsis

```
clkcmd -L -s <src_clock>
```

```
clkcmd -s <src_clock>
```

Parameters

[Table 9-6](#), describes the identifiers that can be selected as system clock.

Table 9-6 System clock id

Clock id	Description
CLK1	LCCB use CLK1 as the system clock.
CLK2	LCCB use CLK2 as the system clock.



You should run this command with and without the -L option, in order to route the system clock and configure the LCCB.

Example

To set the active system clock as CLK1.

```
clkcmd -s CLK1
```

To set the system clock on LCCB to clock 2.

```
clkcmd -L -s CLK2
```

9.2.7 Get Status

Description

This command provides information either about the clocks (if available) or about the LCCB settings (if -L option is used).

Synopsis

```
clkcmd [-L] -g [-c <clock>] [-m <mode>]
```

Parameters

Table 9-7, describes the options for the get status command.

Table 9-7 Options for the get status command

Commands and Options	Description
No option used.	Displays the status of the clock buffer, clock signals, and current setup mode.
-L	Displays the current LCCB status. In particular this is the alarm status, currently selected source, and DPLL operating mode.
-c (without -L)	Displays the specific status of a clock.
-m current	Displays the current setup mode.

Example

To get the status for all clock signals.

```
clkcmd -g -c all
```

To get the status for all the available clock buffers, signals, and current setup mode.

```
clkcmd -g
```

9.2.8 List Entity

Description

This command gets the string identifiers of clocks, mode, automatic configuration, and frequencies; usually needed by `clkcmd`.

Synopsis

```
clkcmd -l {-c all | -m all | -M all | -f all}
```

Parameters

None.

Some of the displayed entities i.e. mode, are relevant only in the context of LCCB setup (along with the `-L` option).

9.2.9 LCCB Default Configuration

Description

This command allows you to bring LCCB to its default configuration. This configuration adapts the LCCB configuration as per the board functionality.

Synopsis

```
clkcmd -L -D
```

Parameters

None.

Example

To initialize the LCCB DPLL functionality.

```
clkcmd -L -D
```

9.2.10 Set LCCB Output Clock

Description

This command allows you to enable and set frequency for the available LCCB output.

Synopsis

```
clkcmd -L -c <clock> -f <freq>
```

Parameters

[Table 9-8](#), describes the available clock ids and related frequencies.

Table 9-8 LCCB output clock id

Clock id	Available frequency	Description
AMC1	FREQ_8K, FREQ_1_544M, FREQ_2_048M, FREQ_19_44M.	Set the LCCB output connected to the AMC to the specified frequency.
RTM	FREQ_8K, FREQ_1_544M, FREQ_2_048M, FREQ_19_44M.	Set the LCCB output connected to the RTM to the specified frequency.



Frequencies can be selected depending on the configured mode. For example, FREQ_1_544M will be rejected when mode SDH is set.

Example

To activate clock output for AMC1 with 8K frequency.

```
clkcmd -L -c AMC1 -f FREQ_8K
```



It is not possible to modify the external output frequency divider factor, that is set to 1.

9.2.11 LCCB Status Daemon

Description

You can start `clkcmd` in a daemon mode, to continuously check the status of system clock and log status changes, such as change of DPLL operating mode and DPLL alarms. All information is logged in the `syslog`-file and is displayed on the screen. During initialization of the daemon, status information (option: `clkcmd -L -g`) is logged. After that only status changes are logged.

Synopsis

```
clkcmd -L -x
```

```
clkcmd -L -x& // To start the daemon in background.
```

Parameters

None.

Example

The following code displays a sample status daemon output.

```
// CLK1 and CLK2 not enabled  
  
--LCCB Status Information
```

```
LCCBStatus: OperatingMode:          DPLL_FREE_RUN
LCCBStatus: SourceStatus:           SOURCE invalid
LCCBStatus: Curr. sel. Source:       NO_SOURCE_SELECTED
LCCBStatus: Alarm:                   ACTICITY_SEC1_TTL set
LCCBStatus: Alarm:                   ACTICITY_SEC2_TTL set
```

// activation of CLK1A

```
LCCBStatus: Alarm ACTICITY_SEC1_TTL changed from set ---> cleared
LCCBStatus: SourceStatus: SEC1_TTL changed from invalid ---> valid
LCCBStatus: OperatingMode changed from DPLL_FREE_RUN ---> DPLL_PRELOCKED
LCCBStatus: Curr. Sel. Source changed from NO_SOURCE_SELECTED ---> SEC1_TTL
LCCBStatus: OperatingMode changed from DPLL_PRELOCKED ---> DPLL_LOCKED
```

// activation of CLK2A

```
LCCBStatus: Alarm ACTICITY_SEC2_TTL changed from set ---> cleared
LCCBStatus: SourceStatus: SEC2_TTL changed from invalid ---> valid
```

// deactivation of CLK1A

```
LCCBStatus: OperatingMode changed from DPLL_LOCKED ---> DPLL_PHASE_LOST
LCCBStatus: OperatingMode changed from DPLL_PHASE_LOST --->
DPLL_PRELOCKED2
LCCBStatus: Alarm ACTICITY_SEC1_TTL changed from cleared ---> set
LCCBStatus: SourceStatus: SEC1_TTL changed from valid ---> invalid
LCCBStatus: Curr. Sel. Source changed from SEC1_TTL ---> SEC2_TTL
LCCBStatus: OperatingMode changed from DPLL_PRELOCKED2 ---> DPLL_LOCKED
```

9.2.12 Verbose Output and Status Information

Description

This command is used to query the status of internal routing/LCCB registers and to get information about the current AMC bays population. It can also be used to get more information about each step performed by clkcmd.

Synopsis

```
clkcmd -v [other commands]
```

Parameters

The `-v` option can be used for normal status query and debug output. It can be used to print the routing register information. Along with other commands it provides first level debug output.

9.2.13 Example

An example for routing the clock from an AMC B1 to the backplane with ATCA-7367:

```
clkcmd -e -c CLK3A
clkcmd -r CLK3A -c RCVD_AMC1
clkcmd -e -c AMC1_TCLKA
clkcmd -e -m AMC_LINECARD_MODE
clkcmd -L -m SDH
clkcmd -L -c AMC1 -f FREQ_8K
clkcmd -L -s CLK1
clkcmd -L -s CLK2
```


Kernel and Root File System Config using PNE 3.0

10.1 Building Kernel and Root File System

This section provides an introduction for building the Linux kernel and root file system for an ATCA-7367 with Wind River PNE 3.0.

10.1.1 Prerequisites

The local RedHat Linux system should have Wind River PNE 3.0 along with the update package 1 installed and running.

The LSP is delivered and verified with the following Wind River packages.

Item	DVD Names
PNE3.0 – Base Package	DVD-R138714.1-1-00 DVD-R138715.1-1-00 DVD-R138716.1-1-00 DVD-R138717.1-1-00
Update Package	Download and install Update Package 1 and Update Package 2 for Wind River Enterprise Linux from the Wind River download server. DVD-138729.1-1-00_part1 DVD-138729.1-1-00_part2 DVD-R138729.1-1-02_part1 DVD-R138729.1-1-02_part2 DVD-R138729.1-1-02_part3
WR Provided Patchsets	WRL_3_0_1-base-kernel-20091203-spin1.zip WRL_3_0_1-base-ldat-20091116-spin1.zip WRL_3_0_1-base-tgt-net-snmp-20091030-spin1.zip WRL_3_0_1-base-tgt-openssl-20091116-spin1.zip WRL_3_0_1-base-tgt-iscsi-initiator-utils-20091117-spin1.zip WRL_3_0_2-base-kernel-20100305-spin1.zip

10.1.2 Additional Kernel Patches

Table 10-1, describes the additional kernel packages required for ATCA-7367. These patches are stored in `ATCA7367_custom_layer/templates/board/atca7367/linux/atca7367_patch/` and are applied automatically during project configuration.

Table 10-1 ATCA-7367 specific kernel patches

Patch name	Description
PciLastBus.patch	Allows PCI devices at location 0xfe or 0xff to be displayed.
coretemp.patch	Uses correct tjmax temperature.
lsi_fusion_4.22.0.0-1.patch	LSI MPT SAS driver (4.22).
i8042.patch	Suppress invalid error message.



implicit source NAT change warning message not needed.

10.1.3 Project Setup

To setup the project, extract the ATCA-7367 custom layer on your build machine. You need access to Wind River PNE3.0.

```
tar -xvzf ATCA7367_custom_layer.tgz
```

You can configure the ATCA-7367 platform project using either of the following:

- Project configure script
- Wind River work bench for PNE 3.0

The ATCA-7367 custom layer is stored in the `ATCA7367_custom_layer` folder. The custom layer consists of the following sub-folders and files:

- `ATCA7367_custom_layer/bbs/` - It contains the ATCA-7367 setup and configuration scripts, along with the pre-build BBS packages.
- `ATCA7367_custom_layer/dist` and `ATCA7367_custom_layer/packages` - It contains additional/modified tools/services or specific patches.
- `ATCA7367_custom_layer/templates/` - It contains the board specific configuration files. It consists of the following files, along with other sub-folders and files.
 - `ATCA7367_custom_layer/templates/board/atca7367/linux/atca7367.scc` - The kernel configuration file.
 - `ATCA7367_custom_layer/templates/board/atca7367/pkglist.add` and `ATCA7367_custom_layer/templates/board/atca7367/pkglist.remove` - RFS package list files.

10.1.3.1 Project Configure Script

You can use the following script to configure the project,
`ATCA7367_custom_layer/bbs/scripts/setEnv.sh`.

Parameters MUST be specified for this script:

```
setEnv.sh <ATCA7367_OBJ_DIR> <PROJECT_PATH> <PROJECT_LAYER_PATH>
<WINDRIVER_INSTALL_PATH>
```

ATCA7367_OBJ_DIR: Directory where your BBS application making modules object files will be put.

PROJECT_PATH: Directory of your PNE platform project. In this case:
`/user/PNE3_0/workspace/ATCA7367_PNE30_prj`

PROJECT_LAYER_PATH: Directory where you have installed `ATCA7367_custom_layer`. In this case: `/user/PNE3_0/workspace/ATCA7367_custom_layer`

WINDRIVER_INSTALL_PATH: Directory where the WindRiver PNE 3.0 workbench installed and the WindRiver PNE 3.0 `wrenv.sh` file can be found. In this case: `/opt/windriver/PNE3.0/`


To use this script you should create a new project directory, such as
`/user/PNE3_0/workspace/ATCA7367_PNE30_prj`.

After successfully set your building environment using `setEnv.sh`, now you can run another script of `atca7367_setup.sh` to configure your ATCA-7367 PNE 3.0 workspace against the configuration in the `ATCA7367_custom_layer` and build the project (including kernel and root file system). The project setup and the results are identical to the ones generated by the WindRiver workbench as specified in [Using Wind River Work Bench for PNE3.0 on page 164](#).


10.1.3.2 Using Wind River Work Bench for PNE3.0

To setup the project using Wind River work bench for PNE 3.0.

1. Login as an end (non-root) user.
2. Select File > New > Wind River Linux Platform Project to display the New WindRiver Linux Platform Project screen as shown below.



- Specify the project name and location for saving the project.
- Click Next in the New WindRiver Linux Platform Project screen to display the Configure Options as shown below.



- Specify the following values under the General settings section.
 Board - common_pc_64
 RootFS - glibc_cgl
 Kernel - cgl
 Build spec - Common_pc_64-glibc_cgl
 Layers - {path to the ATCA7367_custom_layer}
 {template path of ATCA7367_custom_layer}
 Templates - feature/grub_x86_32_for_x86_64

6. Click Finish to complete the project creation. Verify that after the project creation, the `{project_dir}/templates` file contains `kernel/cgl` and `board/atca7367` entries.
7. After performing the above steps, you should be able to build rootfs and kernel.

10.1.4 Kernel Configuration

The ATCA-7367 uses the 64-bit kernel configuration. The kernel configuration file, is stored as `ATCA7367_custom_layer/templates/board/atca7367/linux/atca7367.scc` and a file of `atca7367.cfg` is referred by the file of `atca7367.scc`. You can directly modify `atca7367.cfg` to tune your own custom-built kernel. The kernel configuration will be applied automatically, if you are using the layer structure.

10.1.5 Root File System Configuration

The file system provided with ATCA-7367 supports the Multilibs feature of Wind River PNE 3.0, that allows running of both 32-bit and 64-bit applications on the board. As a result, the package-list contains 32-bit packages also. You can adapt the packages used in your projects as per the requirement. The `ATCA-7367 pkglist.add` and `pkglist.remove` files are stored in `ATCA7367_custom_layer/templates/board/atca7367/` directory.



The original PNE 3.0 does not include a tftp server. Therefore an open source tftp server is incorporated (see `ATCA7367_custom_layer/dist/tftp/`).

The onboard Intel 82576/82599 ethernet controller driver `igb/ixgbe` is built as an loadable Linux module by the script of `ATCA7367_custom_layer/bbs/scripts/atca7367_make_bbs.sh` (instead of building from PNE kernel).

Check the source code and adapted Makefiles at `ATCA7367_custom_layer/bbs/src/igb.tgz` and `ATCA7367_custom_layer/bbs/src/ixgbe.tgz`.

10.1.6 Making BBS modules

BBS modules delivered to you in source code format and igb/ixgbe driver source code are available here `ATCA7367_custom_layer/bbs/src`. You may need to modify the script of `ATCA7367_custom_layer/bbs/scriptsatca7367_make_bbs.sh` (delete those modules you do/could not need to be built from source or adapt the source code repository directory) according to your building environment and project requirement.

Please run the script of

`ATCA7367_custom_layer/bbs/scriptsatca7367_make_bbs.sh` to build your BBS modules.

10.1.7 Getting Root File System and RAMDISK Image

The root file system and RAMDISK (including BBS packages) is created after successfully building kernel and root file system followed by post configuration of the root file system, such as create admin-user, change ownership for ntp-scripts, create additional links to rc-scripts, add additional device nodes, and remove locals to save space in RAMDISK. The post configuration tasks are performed by `atca7367_make_image.sh` script stored in `ATCA7367_custom_layer/bbs/scripts` directory. Before executing the `atca7367_make_image.sh` script, update `PROJECT_PATH` and `PROJECT_LAYER_PATH` as per the location of `ATCA7367_custom_layer`. For example:

```
PROJECT_PATH=/user/PNE3_0/workspace/ATCA7367_PNE30_prj
PROJECT_LAYER_PATH=/user/PNE3_0/workspace/ATCA7367_custom_layer
```

A sample output of the `atca7367_make_image.sh` script is:

```
[scripts 09:38]$sudo ./atca7367_make_image.sh
```

```
Password:
```

```
--- Project Path:
```

```
/user/PNE3_0/workspace/ATCA7367_PNE30_prj
```

```
--- Project layer path:
```

```
/user/PNE3_0/workspace/ATCA7367_custom_layer
```

```
--- Path to Result files:
```

```
/user/PNE3_0/workspace/ATCA7367_PNE30_prj/export
```

```
--- Path to Patch files:
/user/PNE3_0/workspace/ATCA7367_custom_layer/bbs

--- results from build process:

    Symbol Files:
/user/PNE3_0/workspace/ATCA7367_PNE30_prj/export/atca7367-vmlinux-
symbols-WR2.0bl_cgl

    System Map:
/user/PNE3_0/workspace/ATCA7367_PNE30_prj/export/atca7367-System.map-
WR2.0bl_cgl

    Kernel:
/user/PNE3_0/workspace/ATCA7367_PNE30_prj/export/atca7367-default_kernel_
image-WR2.0bl_cgl

    RootFileSystem:
/user/PNE3_0/workspace/ATCA7367_PNE30_prj/export/atca7367-glibc_cgl-cgl-
dist.tar.bz2

    LinuxModules:
/user/PNE3_0/workspace/ATCA7367_PNE30_prj/export/atca7367-linux-modules-
WR2.0bl_cgl.tar.bz2
```

```
=====
=                                                                 =
=      Building rootfs and ramdisk image for ATCA7367          =
=                                                                 =
=====
```

The `atca7367_make_image.sh` script creates the following files in `{project path}/export/images/` directory:

- `bbs-rpms`
- `kernel`

- ramdisk-image
- rootfile-system
- linux modules
- checksum file (required for flashdisk and harddisk installation)
- kernel command line (required for network boot)

Ethernet Controller Five Tuple Filter Utility

11.1 Introduction

This chapter describes the Layer 3/Layer 4 Five Tuple Filter Utility.

This utility leverages the Five Tuple Filter silicon features available on the Ethernet Controller chips populated on ATCA-7367 from a software layer under WindRiver PNE 3.0.2 Linux.

11.2 Multi-queue Ethernet Controllers in ATCA-7367

ATCA-7367 is adapted with Intel Westmere-EP Six-Core processor (Intel XEON 5600 series) as its central processing unit.

The 10GbE Ethernet controllers of Intel 82599EB are populated as its fabric interfaces and the GbE Ethernet controllers of Intel 82576 are populated for its base and AMC interfaces. The ancillary RTM blades including RTM-ATCA-7360, RTM-ATCA-7360-L, and RTM-ATCA-7360-FC adopt Intel 82576 as their front panel Ethernet interfaces.

Both Intel 82599EB and Intel 82576 have introduced in the technology of multi-queue to facilitate the performance improvement especially on a multi-core based platform like Westmere. This technology makes it possible to distribute Ethernet network interfaces I/O workloads across available CPU cores. By holding packets in multiple-queues, the controller can keep packets from getting dropped when processor cores are loaded heavily.


11.2.1 Multi-queue of Intel 82599EB

Each port of the dual port 10GbE controller Intel 82599EB supports a maximum number of 128Tx queues and 128Rx queues. The runtime number of queues can be configured as a load time driver parameter of RSS (Receive-Side Scaling).

The Intel 82599EB driver is configured to automatically support with the number of Tx-Rx-queues exactly the same as the online CPU core numbers (including both the physical cores and hyper-threading logical cores). For details, check the `/etc/init.d/bbsrpms.sh` file and the readme file included in `ixgbe.tar.gz` which is enclosed with the BBS release package.

For ATCA-7367 with hyper-threading off, the number of Tx-Rx-queue will be 6 (mapping to the 6 physical CPU cores of Westmere), in which Tx-Rx-queue bind its MSI-X interrupt.

Figure 11-1 Intel 82599EB multi-queue



11.2.2 Multi-queue of Intel 82576

Each port of the dual port GbE controller Intel 82576 supports a maximum number of 8 Tx-Rx-queues. The runtime number of queues can be configured as a load time driver parameter of RSS.

The Intel 82576 driver is configured to automatically support with the number of Tx-Rx-queues with the lesser value of the online number of CPU cores or the maximum number of supported Tx-Rx-queues (which equals to 8 as described above). For details, check the `/etc/init.d/bbsrpms.sh` file and the readme file included in `igb.tar.gz` which is enclosed with the BBS release package.

11.2.3 Queue's MSI-X Interrupt Affinity with CPU Core

Both the Intel 82599EB and Intel 82576 controller's gives each Tx-Rx-queue its own MSI-X interrupt vectors. With an interrupt vector for each queue, the controller can handle multiple interrupts simultaneously preventing the bottlenecks associated with funneling all interrupts through a single vector.



Check the file of `/proc/interrupts` to get the MSI-X vector number bound to the Tx-Rx-queue of each controller. For example, the following command will list out all of the interrupt vector numbers bound to the interface named "fabric1" on ATCA-7367:

```
root@ATCA-7367-9:~# cat /proc/interrupts | grep fabric1
```

This provides the flexibility to target an I/O interrupt to a specific CPU core for each I/O request. Linux SMP affinity mechanism enables the user to re-assign the MSI-X interrupts bound to each Tx-Rx-queue to specific CPU cores. This is done by changing the core bitmask table value in the `/proc/irq/<IRQ_number>/smp_affinity` file. For example, the following command will bind the IRQ#1203 to the CPU core #0:

```
root@ATCA-7367-9:~# echo 1 > /proc/irq/1203/smp_affinity
```

For details, check the *Documentation/IRQ-affinity.txt* file included in the Linux source tree.

In system boot up phase, the MSI-X interrupt vectors of Intel 82599EB and Intel 82576 are averagely distributed to each of the online CPU cores using the `/etc/init.d/bbsvlan.sh` script. The fabric2 interface's MSI-X vector affinity status is shown below.


```
root@ATCA-7367-7:~# cat /proc/interrupts | grep fabric2
```

	CPU0	CPU1	CPU2	CPU3	CPU4	CPU5	
1202:	0	0	0	0	0	0	PCI-MSI-edge fabric2:lsc
1203:	0	0	0	0	0	11175	PCI-MSI-edge fabric2-TxRx-5
1204:	0	0	0	0	11175	0	PCI-MSI-edge fabric2-TxRx-4
1205:	0	0	0	11175	0	0	PCI-MSI-edge fabric2-TxRx-3
1206:	0	0	11175	0	0	0	PCI-MSI-edge fabric2-TxRx-2
1207:	0	11175	0	0	0	0	PCI-MSI-edge fabric2-TxRx-1

```
1208:11175 0 0 0 0 0 PCI-MSI-edge fabric2-TxRx-0
```

The following diagram shows an overview of the affinity status.

Figure 11-2 Overview of Affinity Status




11.3 L3/L4 Five Tuple Filter Introduction

Both the Intel 82599EB/ES and Intel 82576 have introduced the 'Rx Queue Assignment' technology which provides a series of filter mechanisms to enable users to route received packets to various Tx-Rx-queues. The L3/L4 five tuple is one of these filter mechanisms. Each of the L3/L4 flows could be exclusively described using a 5-tuple combination: the protocol, source and destination IP addresses, source and destination TCP/UDP/SCTP port. The L3/L4 five tuple filters identifies the specific L3/L4 flow or set of L3/L4 flows and route the packets of these flows into expected Tx-Rx-queues.

For the packets which do not match with any of the L3/L4 five tuple filters, the final filter mechanism of RSS (Receive-Side Scaling) adopts a hash algorithm to make sure that the received packets are 'evenly' distributed to the available queues.

The received packets queuing assignment of the base, fabric, AMC and RTM Ethernet interfaces of ATCA-7367 are made according to the following flow:

Figure 11-3 Rx Queue Assignment



Fragmented packets may lead to side-effects if not handled properly by the filtering mechanism. This has been considered in the silicon design of Intel 82599EB and Intel 82576.

- For Intel 82599EB, fragmented packets miss the 5-tuple filters. 5-tuple filters will be bypassed (ignored) for all fragmented packets.
- For Intel 82576, the 5-tuple filter will bypass (ignore) the tuple ingredients of the source port and destination port, it can still be used to filter the protocol, source, and destination IPv4 address.

11.4 Utility Usage

11.4.1 Using ethtuple

ATCA-7367 5-tuple utility provides a shell command utility `ethtuple` as a friendly and easy-to-use interface to make the 5-tuple filter configuration including adding, checking and deletion.

Description

The command utility `ethtuple` translates the user command line into transactions of `ethtool` service requests which is handled by Linux `ethtool` facility.

The shell command `ethtuple` can be found in `/opt/bladeservices/tools/` directory.

Synopsis

To set/add a new 5-tuple filter:

```
ethtuple <ethInterface> set <tupleIndex> <queueIndex> <dport>
<sport> <daddr> <saddr> <protocol> <priority> [verbose:0|1]
```

To get/check or delete a 5-tuple filter:

```
ethtuple <ethInterface> <get|del> <tupleIndex> [verbose:0|1]
```

Parameters

Parameter function and valid values are defined in the following table:

Table 11-1 ethtuple parameters

Parameter	Description	Valid Values
<code>ethInterface</code>	The Ethernet controller's interface name in Linux.	<i>base1, base2, fabric1, fabric2, amc1, amc2, amc3, amc4, rtm1, rtm2, rtm3, rtm4, rtm5, rtm6.</i>
<code>tupleIndex</code>	The index value of a 5-tuple filter item.	Valid value <i>[0, max]</i> . <i>max</i> is the maximum number of the 5-tuple filters which the <code>ethInterface</code> supports. This is a silicon capacity dependent value. Intel 82599EB supports a maximum number of 128, 5-tuple filters and Intel 82576 supports a maximum number of 8 5-tuple filters. A <code>tupleIndex</code> value of <i>max</i> for a <code>get</code> operation will dump all the 5-tuple filters out to console. For example, specify the <code>tupleIndex</code> value of 8 for a <code>get</code> operation to dump all of the 5-tuple filter items of an Intel 82576 interface.

Table 11-1 *ethtuple parameters (continued)*

Parameter	Description	Valid Values
queueIndex	The index value of Rx queue to which the packets that matches this filter will be routed.	Valid value <code>[0 , maxRxQueueIndex]</code> . The maxRxQueueIndex value can be got by the below command: <code>ethtool -S ethInterface grep rx_queue grep packets</code>
dport/sport	The decimal destination and source TCP/UDP/SCTP port number.	Set as 0 for any ports. NOTE: For Intel 82576, this parameter is only valid when the protocol parameter is specified either as TCP or UDP.
daddr/saddr	The dot divided decimal destination/source IPv4 address of the packets.	Set as '0 . 0 . 0 . 0' for any IP address.
protocol	Identifies the IP protocol.	Valid values: <code>TCP UDP SCTP ALL OTHER</code> Set the parameter as <code>ALL</code> for all kinds of IP protocols. Set the parameter as <code>OTHER</code> for IP protocols which is not <code>TCP</code> , <code>UDP</code> , or <code>SCTP</code> . NOTE: For Intel 82576 based interfaces, only the following protocol parameter supported: <code>TCP UDP SCTP</code>
priority	The priority of the filter.	Valid value: <code>[0 , 7]</code> A larger number means a higher priority for the filter. A higher priority filter will override a lower one when the 5-tuple setting matches both of them. User must ensure that a packet should never matches two or more filters with the same priority value. Otherwise, the behavior of 5-tuple filtering will be uncertain.
verbose	Value '1' will print the debug messages on console.	Valid value: <code>[0 , 1]</code>



The **ethtuple** utility is a shell script based program and should only be called synchronously in a single shell context. Concurrent calling of the **ethtuple** service from multiple shells or system call threads is not supported and that may leads to malfunction the 5-tuple service.

Example

- 1. The following command sets the 5-tuple filter #1 of Ethernet interface 'fabric1' to route the UDP packets received from anywhere destinating to the local port 20000 into specified Tx-Rx-queue #0. The priority of this filter has the lowest value of 0.

```
ethtuple fabric1 set 1 0 20000 0 0.0.0.0 0.0.0.0 UDP 0
```

- 2. The following command sets the 5-tuple filter #35 of Ethernet interface 'fabric1' to route the TCP packets received from 192.168.21.44:1000 into Tx-Rx-queue #5. The priority of this filter is 1.

```
ethtuple fabric1 set 35 5 0 1000 0.0.0.0 192.168.21.44 TCP 1
```

- 3. This command will print the #35 filter configuration of fabric1.

```
ethtuple fabric1 get 35
```

Output:

Filter	Queue	DstPort	SrcPort	Protocol	Priority	DstIPAddr	SrcIPAddr
35	5	0	1000	TCP	1	0.0.0.0	192.168.21.44

- 4. This command will list out all of the active 5-tuple filters of fabric1.

```
ethtuple fabric1 get 128
```

Output:

Filter	Queue	DstPort	SrcPort	Protocol	Priority	DstIPAddr	SrcIPAddr
1	1	20000	0	UDP	0	0.0.0.0	0.0.0.0
35	5	0	1000	TCP	1	0.0.0.0	192.168.21.44

11.5 CPU Core Affinity with Application Programs

To accomplish the best performance of a multi-queue Ethernet, the `ethtuple` facility is made as one ingredient of the optimization set. Besides assignment of received flows/packets to expected Rx Queue with `ethtuple`, a proper overall affinity relationship of Rx flow/packet->Rx Queue->CPU Core->Application program should be set up.

- Rx Queue->CPU Core Affinity has been covered in the [Multi-queue Ethernet Controllers in ATCA-7367 on page 171](#).
- CPU Core->Application program Affinity

Linux allow applications to statically bind processes/threads to CPU cores at source code level through pthread API of `sched_setaffinity()`.

```
int sched_setaffinity(pid_t pid, unsigned int cpusetsize, cpu_set_t
*mask);
```


Linux also provides a command of `taskset`.

```
taskset [options] [mask | list ] [pid | command [arg]...]
```

Refer to Linux `man ()` pages for the detailed information.

By making proper affinity configurations, the most optimized binding relationship can be achieved as shown in the following figure:

Figure 11-4 Binding Relationship



Installing and Configuring BBS

A.1 Installing BBS Using Hard Disk

After the system has come up, install Linux with the following procedure:

1. Login as **root**.
2. Identify the Linux device name of the hard disk on which you want to install BBS. To do so, enter **fdisk -l**. This displays available hard disks, their Linux device names and also the storage capacity. An easy way to identify a particular hard disk is by its storage capacity. Refer to the respective hardware user manuals for information about the storage capacities of the hard disks used in your configuration. Another way to identify a particular hard disk, is via the device name. Linux uses different device names for different hard disk types. The exact format, however, differs between Linux versions and distributions. Refer to your Linux documentation for further details.
3. Run the **linuxrc** script from the `/opt/ bladeservices/tools` directory:
./linuxrc
 The hard disk installation begins by checking for necessary commands on the system. The screen output will look similar to this:

```
Checking for necessary commands...
awk                [exists]
chroot             [exists]
mount              [exists]
umount             [exists]
tar                [exists]
gzip               [exists]
mkdir              [exists]
rmdir              [exists]
rm                 [exists]
cp                 [exists]
```

```

mv                [exists]
date              [exists]
chmod             [exists]
chown             [exists]
grep              [exists]
dd                [exists]
stty              [exists]
sed               [exists]
...               ...

```

Necessary commands found, safe to continue...

The following disks are available:

/dev/sda: 40.0 GB

/dev/sdb: 4110 MB

Following default settings were found:

export AUTO_DEV_NAME=sda

export AUTO_TFTPSRV=192.168.22.55

export AUTO_TFTPLOC=ATCA7367

export AUTO_TZ=n

export AUTO_NTPUSE=n

export AUTO_MDATEUSE=n

export AUTO_HOSTNAME=ATCA7367

Do you want to use predefined values? [y/n] **n**

Select the disk/flash device where you want to have the
filesystem installed (e.g. sdc) []: **sda**

Verifying disk device: /dev/sda...done.

4. Start the installation by entering **y** for yes.

Do you wish to begin the installation? [y/n]

There is no default answer to this question. Choosing y will begin the installation.

Choosing n will abort the installation.

Starting the installation will cause the hard disk drive to be partitioned and formatted while displaying the message:

```
Disk /dev/sda: 4864 cylinders, 255 heads, 63 sectors/track
```

```
Old situation:
```

```
Units = mebibytes of 1048576 bytes, blocks of 1024 bytes, counting from 0
```

Device	Boot	Start	End	MiB	#blocks	Id	System
/dev/sda1		0+	1004-	1005-	1028159+	83	Linux
/dev/sda2	*	1004+	6008-	5005-	5124735	83	Linux
/dev/sda3		6008+	11013-	5005-	5124735	83	Linux
/dev/sda4		11013+	38154-	27142-	27792450	5	Extended
/dev/sda5		11013+	16017-	5005-	5124734+	83	Linux
/dev/sda6		16017+	21022-	5005-	5124734+	83	Linux
/dev/sda7		21022+	22560-	1538-	1574369+	82	Linux swap/Solaris
/dev/sda8		22560+	26560-	4001-	4096574+	83	Linux
/dev/sda9		26560+	27078-	518-	530144+	83	Linux
/dev/sda10		27078+	27596-	518-	530144+	83	Linux

```
New situation:
```

```
Units = mebibytes of 1048576 bytes, blocks of 1024 bytes, counting from 0
```

Device	Boot	Start	End	MiB	#blocks	Id	System
--------	------	-------	-----	-----	---------	----	--------

```

/dev/sda1          0+   1004-   1005-   1028159+  83  Linux
/dev/sda2    *  1004+   6008-   5005-   5124735   83  Linux
/dev/sda3          6008+  11013-   5005-   5124735   83  Linux
/dev/sda4          11013+  38154-  27142-  27792450    5  Extended
/dev/sda5          11013+  16017-   5005-   5124734+  83  Linux
/dev/sda6          16017+  21022-   5005-   5124734+  83  Linux
/dev/sda7          21022+  22560-   1538-  1574369+  82  Linux swap/Solaris
/dev/sda8          22560+  26560-   4001-  4096574+  83  Linux
/dev/sda9          26560+  27078-    518-   530144+  83  Linux
/dev/sda10         27078+  27596-    518-   530144+  83  Linux

```

Successfully wrote the new partition table

Re-reading the partition table ...

If you created or changed a DOS partition, /dev/foo7, say, then use dd(1) to zero the first 512 bytes: dd if=/dev/zero of=/dev/foo7 bs=512 count=1 (See fdisk(8).)

5. Choose Dynamic IP Configuration.

You will be prompted to either accept dynamic IP configuration for the installation interface, or to choose static configuration:

Artesyn recommends to use dynamic IP configuration for all blades

Do you wish use static IP management [y/N]?

Enter **N** or press <Enter>.

6. Choose the TFTP Server.

The TFTP server houses all of the files necessary for the installation. There is no default choice.

Which TFTP Server do you wish to use? [xxx.xxx.xxx.xxx]

A series of 'pings' are sent to the server at the given address to ensure connectivity.

If the connection to the tftp server cannot be established, the query will be repeated.

7. Select the TFTP server installation directory.

A known set of files is expected to be available on the TFTP server to proceed the installation. Only the location of these files on the TFTP server can be configured.

Note: Please enter the directory name without leading or trailing slashes.

What is the installation files directory? []

For example: ATCA7367

8. Downloading of Files

During the download of the files the following is displayed, for example:

```
Downloading files.shalsum from ATCA7367....Done.
```

```
Downloading kernel from ATCA7367....Done.
```

```
Downloading rootfs.tar.gz from ATCA7367....Done.
```

```
Downloading modules.tar.bz2 from ATCA7367....Done.
```

```
Downloading bbs-boardctrl-atca7367-1.0.1-3-pne30.rpm from
ATCA7367....Done.
```

```
Downloading bbs-fuf-atca7367-1.3.8-2-pne30.rpm from ATCA7367....Done.
```

```
Downloading bbs-hpmagentcmd-atca7367-1.3.12-2-pne30.rpm from
ATCA7367....Done.
```

```
Downloading bbs-pram-atca7367-0.1.0-1-pne30.rpm from ATCA7367....Done.
```

```
Downloading bbs-sfmem-atca7367-1.0.0-1-pne30.rpm from
ATCA7367....Done.ATCA7367....Done.
```

9. Set the time zone, if necessary. The time zone (24-hour clock) is by default set to US/Eastern on all the blades. In order to change the time zone, enter **y** for Yes when being prompted. See the following output example.

Your current time zone is set to US/Eastern

Do you want to change that? [n]:

y

```
1) Africa
```

```

2) Americas
3) Antarctica
4) Arctic Ocean
5) Asia
6) Atlantic Ocean
7) Australia
8) Europe
9) Indian Ocean
10) Pacific Ocean
11) none - I want to specify the time zone using the Posix TZ format.
#?8
Please select a country.
  1) Aaland Islands 18) Greece          35) Norway
  2) Albania        19) Guernsey       36) Poland
  3) Andorra        20) Hungary       37) Portugal
  4) Austria        21) Ireland       38) Romania
  5) Belarus        22) Isle of Man   39) Russia
  6) Belgium        23) Italy         40) San Marino
  7) Bosnia & Herzegovina 24) Jersey    41) Serbia
  8) Britain (UK)  25) Latvia        42) Slovakia
  9) Bulgari       26) Liechtenstein  43) Slovenia
 10) Croatia       27) Lithuania     44) Spain
 11) Czech Republic 28) Luxembourg    45) Sweden
 12) Denmark       29) Macedonia     46) Switzerland
 13) Estonia       30) Malta          47) Turkey
 14) Finland       31) Moldova        48) Ukraine
 15) France        32) Monaco         49) Vatican City
 16) Germany       33) Montenegro
 17) Gibraltar     34) Netherlands
#?16

```

Choose a time zone out of the list that is displayed and enter the corresponding number. After choosing Germany, for example, the following output would be displayed.

```

The following information has been given:
Germany
Therefore TZ='Europe/Berlin' will be used.
Local time is now:      Sun Jan 2 12:58:05 CET 2005.
Universal Time is now:  Sun Jan 2 11:58:05 UTC 2005.

```

Is the above information OK?

1) Yes

2) No

#?1

10. Set the time used on the blade. It is possible to set the time automatically using an NTP server if an NTP server is available, or to set it manually. It is strongly advised that one of two methods is used to ensure that a valid date and time is set on the system before the installation of files begins.

If a valid NTP server is available, answer the following question with **y** and enter the IP address of the NTP server.

Do you wish to use NTP to set the current time? [Y/n]

Please enter the NTP server address [xxx.xxx.xxx.xxx]

If a NTP sever is not available, then the time can be set manually. To do so, answer the following question with **y** and enter the date and time manually.

Do you wish to set the date manually? [Y/n]**y**

Enter date in 'MM/DD/YYYY' format. [] Enter time in 'HH:MM' and 24-hour format. []

The values entered are validated and ensure accuracy.

The value that is either gathered from the NTP server or entered manually is written to the hardware clock of the blade.

11. Check SHA1 Checksums and Install

Once the files have been downloaded, the SHA1 checksums of the downloaded files are compared to their expected values and if they are correct, the root file system is un-compressed and finally the BBS software's RPMs are installed.

A.2 Setting up the Kdump Utility on a Hard Disk Driver Installed System

Kexec and kdump are the new features in 2.6 mainstream Linux kernel. The purpose of these features is to ensure faster boot up and creation of reliable kernel vmcores for diagnostic purposes in case of system crash.

Kexec

kexec is a Linux kernel mechanism that allows live booting of a new kernel over the currently running kernel. kexec skips the bootloader stage (hardware initialization phase by the firmware or BIOS) and directly loads the new kernel into memory, where it starts executing immediately.

Kdump

Kdump is a kexec based kernel crash dumping mechanism, which is being perceived as a reliable crash dumping solution for Linux. Dump is captured with the help of a custom built kernel, the second kernel, which runs with a small amount of memory. This custom built kernel is called dump-capture kernel and is booted upon a system crash event without clearing crashed kernel's memory.

The first kernel reserves a portion of memory that the second kernel (the dump-capture kernel) uses to boot (in our case the memory region is 64M~256M). While dump-capture kernel boots, first kernel's memory is not overwritten except for the small amount of memory used by newly booted up dump-capture kernel for its execution. Kdump uses this feature of kexec and add hooks in kexec code to boot into the dump-capture kernel upon a panic event without losing crashed kernel's memory. Then the dump-capture kernel retrieves the saved register states and backup region contents, and dump the old kernel's crashed image into a kernel interface file: the `/proc/` in ELF core format. The exported `/proc/vmcore` file can be directly analyzed using ELF core format aware analysis tools such as `gdb` or `crash`.

NOTE: The `/proc/vmcore` implementation does not support discontinuous memory systems and assumes memory is contiguous. Hence it exports only one ELF program header for the whole memory.

makedumpfile

To reduce the size of the `/proc/vmcore` dump file, kdump allows user to specify an external application (a core collector) to compress the data, and optionally leave out all irrelevant information. Currently, the fully supported core collector is `makedumpfile`.

To enable the core collector, open the `/etc/kdump.conf` configuration file in a text editor such as `vi` or `nano` and remove the hash sign `"#"` from the beginning of the following line:

```
#core_collector makedumpfile -c --message-level 1 -d 31
```

Provide the command line options according to your requirement as described below.

To enable the dump file compression, add the `-c` parameter. For example:


```
core_collector makedumpfile -c -d 17
```

To remove certain pages from the dump file, add the `-d` value parameter, where value is a sum of the values of pages you want to omit as described in following Table:

Table A-1 Supported filtering levels

Option	Description
1	Zero pages
2	Cache pages
4	Cache private
8	User pages
16	Free pages

For example, to remove both zero and free pages, use the following:

```
core_collector makedumpfile -c -d 17
```

Use `makedumpfile -h` to make a complete list of available options.

The default setting used by BBS is:

```
core_collector makedumpfile -c -d 17
```



The `kdump` utility is ONLY available on BBS system installed on hard disk driver, onboard eUSB flash or USB sticks.

With default configurations, user can easily configure the system to get and analysis the dumped vmcore file.

Following are the list of files with procedure to perform the postmortem analysis:

1. Configuration files

File	Configurable	Comments
/etc/kdump.conf	YES	Configures the options on how/where to store the kdump /proc/vmcore file.
/etc/sysconfig/kdump	YES	Configures the capture kernel options.
/etc/init.d/kdump	NO	Start and stop kdump service. The kdump init script provides the support necessary for loading a capture kernel into memory at system boot up time, and propagate network keys for ssh utility, when the user specifies a network place to save the vmcore file.
/boot/grub.conf	NO	Set boot parameter of "crashkernel" to reserve a continues memory space for the dump-capture kernel, in this case crashkernel=256M@64M.

2. Description for /etc/kdump.conf options

This file contains a series of commands to perform (in order) when a kernel crash has happened and the dump-capture kdump kernel has been loaded.

Currently only one dump target and path may be configured at once if the configured dump target fails, the default action will be configured with the default directive as below.

- A Typical /etc/kdump.conf looks like as below:

```
auto_dump yes
#raw /dev/sda5
#ext3 /dev/sda8
#ext3 LABEL=/boot
#ext3 UUID=bfc7ac2a-da95-47ff-8ea6-bc84c9118a34
#net my.server.com:/export/tmp
#net netdumpuser@192.168.16.100
path /var/crash
core_collector makedumpfile -c -d 17
#link_delay 60
#default poweroff
```

- Configuration option and value description

Option	Value Description
auto_dump	<p>Set <code>auto_dump</code> as 'yes' to enable the capture kernel to save the <code>/proc/vmcore</code> core automatically and if option 'default' is not set, the system would reboot by default, else the 'default' action would perform.</p> <p>Comment <code>auto_dump</code> if you would like to make manually <code>/proc/vmcore</code> saving when the capture kernel starts up. In this case, when you log in the system, the hostname would be <code>HOSTNAME-VMCORE</code>.</p> <p>NOTE: If you comment this option, all other options would make no sense.</p>
raw <partition>	<p>This option will store <code>/proc/vmcore</code> into given <partition>.</p> <p>NOTE: Improper usage of this option may destroy partition file system.</p>
<fs type> <partition>	<p>This option will mount <code>-t <fs type> <partition> /mnt</code> and copy <code>/proc/vmcore</code> to directory <code><mnt>/path/`date "+%Y-%m-%d-%H:%M" `</code>, where the path is specified by <code>path</code> option.</p>
net <nfs mount>	<p>This option will mount <code>nfs</code> and copies <code>/proc/vmcore</code> to the directory <code><mnt>/path/`date "+%Y-%m-%d-%H:%M" `</code>, where path is specified by <code>path</code> option, supports DNS.</p>
net <user@server>	<p>This option will <code>scp /proc/vmcore</code> to <code><mnt>/path/`date "+%Y-%m-%d-%H:%M" `</code>, where path is specified by <code>path</code> option, supports DNS.</p> <p>NOTE: Make sure user has necessary write permissions on server. It is strongly recommended to run <code>/etc/init.d/kdump propagate</code> before enable this option.</p> <p>NOTE: The dump data in this manner is in the flattened format. Analysis tools cannot read the flattened format directly. For analysis, the dump data in the flattened format should be rearranged to a readable dump file by <code>-R</code> option. For more information, please refer to <code>makedumpfile -h</code>.</p>

Option	Value Description
<code>path <path></code>	<p>Append path to the filesystem device which you are dumping to. Ignored for raw device dumps. If unset, will default to <code>/var/crash</code>.</p> <p>NOTE: If the path is the mount point of the device, it is strongly recommended to use this path with <code><fs type></code> <code><partition></code>, such as with <code>"ext3 /dev/sda8"</code>.</p>
<code>core_collector makedumpfile <options></code>	<p>This directive allows you to use the dump filtering program <code>makedumpfile</code> to retrieve your core, which on some arches can drastically reduce core file size.</p> <p>Refer to <code>/sbin/makedumpfile --help</code> for a list of options.</p> <p>Note that the <code>-i</code> and <code>-g</code> options are not needed here, as the <code>initrd</code> will automatically be populated with a config file appropriate for the running kernel.</p>
<code>link_delay <seconds></code>	<p>Some network cards takes a long time to initialize, and some spanning tree enabled networks do not transmit user traffic for long period after a link state changes. This optional parameter defines a wait period after a link is activated in which the <code>initramfs</code> will wait before attempting to transmit user data</p>
<code>default <reboot shell poweroff halt ></code>	<p>Action to perform instead of mounting root fs and running <code>init</code> process.</p> <p><code>reboot</code>: If the default action is <code>reboot</code> simply reboot the system and loose the core that you are trying to retrieve.</p> <p><code>shell</code>: If the default action is <code>shell</code>, then drop to an hush session inside the <code>initramfs</code> from where you can try to record the core manually. Exiting this shell reboots the system.</p> <p>NOTE: If no default action is specified, the <code>initramfs</code> will reboot the system after the <code>/proc/vmcore</code> is copied completely.</p>

You can use `"#"` as prefix to comment out those options which you do not want to use.

3. Description for `/etc/sysconfig/kdump` options

Option	Value Description
KDUMP_COMMANDLINE	The kdump command line needs to be passed off to the kdump kernel. This will likely match the contents of the grub kernel line. If a command line is not specified, the default will be taken from <code>/proc/cmdline</code> . By default, KDUMP_COMMANDLINE=" ".
KDUMP_COMMANDLINE_APPEND	This variable lets us to append arguments to the current kdump command line. As taken from either KDUMP_COMMANDLINE above, or from <code>/proc/cmdline</code> . By default, KDUMP_COMMANDLINE_APPEND="irqpoll maxcpus=1".
KEXEC_ARGS	Any additional kexec arguments required. By default, KEXEC_ARGS=" --args-linux".
KDUMP_BOOTDIR	To find the kernel booting image. By default, KDUMP_BOOTDIR="/boot "
KDUMP_IMG	To define the image type used for kdump. By default, KDUMP_IMG="vmlinuz".
KDUMP_IMG_EXT	To define the images extension. Relocatable kernels do not have any extension. By default, KDUMP_IMG_EXT=" ".

4. Files under `/boot/` used by kdump

<code>bzImage-2.6.27.39-grsec</code>	System kernel. Used to boot up BBS system.
--------------------------------------	--

<code>vmlinuz-2.6.27.39-grsec</code>	Dump-capture kernel, loaded by <code>kexec</code> .
<code>vmlinuz-2.6.27.39-grsec</code>	<code>vmlinuz-2.6.27.39-grsec</code> is a statically linked Linux kernel executable file which includes the necessary information to make kernel debugging.
<code>initrd-2.6.27.39-grsec.img</code>	Assists system kernel to boot up, it is a root filesystem which is embedded into the kernel and loaded at an early stage of the boot process. It is referred by <code>kdump</code> to construct <code>initramfs</code> for dump-capture kernel.
<code>modules4kdump.tar.bz2</code>	Include modules to assist dump-capture kernel to copy <code>/proc/vmcore</code> .

5. Kernel debug information file

To support postmortem analysis, the file `/boot/vmlinuz-2.6.27.39-grsec` is provided. It is required for kernel debugging with `crash` utility.

6. Make your own configuration

User has to modify the configuration file `/etc/kdump.conf` to specify the location where `/proc/vmcore` dumped file is to be saved. In order to reduce the time to copy `/proc/vmcore`, it is strongly recommended to enable `core_collector` option.

Restart the `kdump` service by running the following command to make your modified configuration activated:

```
root@ATCA-7367-9:~# /etc/init.d/kdump restart
Stopping kdump:[ OK ]
Detected /etc/kdump.conf or /boot/vmlinuz-2.6.27.39-grsec change
Rebuilding /boot/initrd-2.6.27.39-grseckdump.img
42280 blocks
Starting kdump:[ OK ]
```

7. Analysis dump file with `crash` utility

Use the utility "`crash`" with option `--no_data_debug` to make the postmortem analysis. For example:

```
root@ATCA-7367-9:~# crash --no_data_debug /var/crash/2011-03-15-17\
:27/vmcore /boot/vmlinuz-2.6.27.39-grsec
```

8. An Example

You can enforce a crash to the system by echoing a `c` into `/proc/sysrq-trigger`:

```
root@ATCA-7367-9:~# echo c > /proc/sysrq-trigger
```

You can see some panic output, followed by the system restarting into dump-capture kernel.

If you have enabled "auto_dump" option in `/etc/kdump.conf`, the boot process would copy the dumped file `/proc/vmcore` automatically to the specified path (`<path>/<YYYY-MM-DD-HH:MM>/vmcore`), then the system reboots back into your normal kernel.

If you have commented "auto_dump" option in `/etc/kdump.conf`, the boot process will boot up dump-capture kernel, you have to copy `/proc/vmcore` manually by yourself. Once back to your normal kernel, you can use the crash kernel in conjunction with the kernel-debuginfo file `vmlinux` to perform the postmortem analysis, for example:

```
root@ATCA-7367-9:~# crash --no_data_debug /var/crash/2011-03-15-17\27/vmcore /boot/vmlinux-2.6.27.39-grsec
crash 5.0.8
Copyright (C) 2002-2010 Red Hat, Inc.
Copyright (C) 2004, 2005, 2006 IBM Corporation
Copyright (C) 1999-2006 Hewlett-Packard Co
Copyright (C) 2005, 2006 Fujitsu Limited
Copyright (C) 2006, 2007 VA Linux Systems Japan K.K.
Copyright (C) 2005 NEC Corporation
Copyright (C) 1999, 2002, 2007 Silicon Graphics, Inc.
Copyright (C) 1999, 2000, 2001, 2002 Mission Critical Linux, Inc.
This program is free software, covered by the GNU General Public License,
and you are welcome to change it and/or distribute copies of it under
certain conditions. Enter "help copying" to see the conditions.
This program has absolutely no warranty. Enter "help warranty"
for details.
```

```
GNU gdb (GDB) 7.0
Copyright (C) 2009 Free Software Foundation, Inc.
License GPLv3+: GNU GPL version 3 or later
<http://gnu.org/licenses/gpl.html>
This is free software: you are free to change and redistribute it.
```

There is NO WARRANTY, to the extent permitted by law. Type "show copying" and "show warranty" for details.
This GDB was configured as "x86_64-unknown-linux-gnu"...

```

please wait... (gathering module symbol data)
WARNING: invalid kernel module size: 0
      KERNEL: /boot/vmlinux-2.6.27.39-grsec
      DUMPFILE: /var/crash/2011-03-15-17:27/vmcore [PARTIAL DUMP]
      CPUS: 12
      DATE: Tue Mar 15 17:26:46 2011
      UPTIME: 00:23:40
LOAD AVERAGE: 0.30, 0.22, 0.11
      TASKS: 299
      NODENAME: 7367-ga04-9
      RELEASE: 2.6.27.39-grsec
      VERSION: #1 SMP PREEMPT Sat Mar 12 01:39:44 HKT 2011
      MACHINE: x86_64 (1994 Mhz)
      MEMORY: 4 GB
      PANIC: "SysRq : Trigger a crashdump"
      PID: 27362
      COMMAND: "bash"
      TASK: ffff88013acb9db0 [THREAD_INFO: ffff880133d16000]
      CPU: 0
      STATE: TASK_RUNNING (SYSRQ)
crash> bt
PID: 27362 TASK: ffff88013acb9db0 CPU: 0 COMMAND: "bash"
#0 [ffff880133d17da0] crash_kexec at ffffffff81065981
#1 [ffff880133d17e70] __handle_sysrq at ffffffff81282b0d
#2 [ffff880133d17eb0] write_sysrq_trigger at ffffffff8111cb0a
#3 [ffff880133d17ec0] proc_reg_write at ffffffff811144f0
#4 [ffff880133d17f00] vfs_write at ffffffff810c51ab
#5 [ffff880133d17f30] sys_write at ffffffff810c53f4
RIP: 000000371cac1f30 RSP: 000078aa55f32ba0 RFLAGS: 00010287
RAX: 0000000000000001 RBX: ffffffff810034cb RCX:
00000000000000400
RDX: 0000000000000002 RSI: 00007f05b2548000 RDI:
0000000000000001

```



```
    RBP: 0000000000000000    R8: 00007f05b25426f0    R9:
0000000000000000
    R10: 000000371cd4d9b0    R11: 00000000000000246    R12:
000078aa55f3347c
    R13: 00000000000000002    R14: 000000371cd4c780    R15:
00007f05b2548000
    ORIG_RAX: 0000000000000001    CS: 0033    SS: 002b
crash> q
```


Related Documentation

B.1 Artesyn Embedded Technologies - Embedded Computing Documentation

The publications listed below are referenced in this manual. You can obtain electronic copies of Artesyn Embedded Technologies - Embedded Computing publications by contacting your local Artesyn sales office. For released products, you can also visit our Web site for the latest copies of our product documentation.

1. Go to www.artesyn.com/computing.
2. Under SUPPORT, click TECHNICAL DOCUMENTATION.
3. Under FILTER OPTIONS, click the Document types drop-down list box to select the type of document you are looking for.
4. In the Search text box, type the product name and click GO.

Table B-1 Artesyn Embedded Technologies - Embedded Computing Publications

Document Title	Publication Number
ATCA-7367 Installation and Use Guide	6806800J07
RTM-ATCA-7360 Installation and Use	6806800J08
Centellis 2000 Preliminary Installation and Use	6806800G45
Centellis 4440 Installation and Use	6806800H23

B.2 Related Specifications

For additional information, refer to the following table for related specifications. As an additional help, a source for the listed document is provided. Please note that, while these sources have been verified, the information is subject to change without notice.

Table B-2 Related Specifications

Document Title	Source
IPMI Specifications http://www.intel.com/design/servers/ipmi	
IPMI Spec V.2.0	Intel Corporation, Hewlett-Packard, DEC, NEC
IPMI Platform Management FRU Information Storage Definition V1.0, September 27, 1999	Intel Corporation
PCI Industrial Computer Manufacturers Group (PICMG) Specifications http://www.picmg.org	
PICMG 3.0 Revision 2.0 Advanced Telecommunications Computing Architecture (AdvancedTCA) Base Specification	PICMG

B.3 Additional Resources

The following table lists additional resources which may be useful in working with Artesyn's AdvancedTCA systems.

Table B-3 Additional Resources

Resource	Source
OpenHPI open source software project http://openhpi.org	
OpenHPI 1.0 Manual	OpenHPI
OpenHPI NetSNMP Subagent Development Manual	OpenHPI
Net-SNMP http://net-snmp.sourceforge.net/	

Table B-3 Additional Resources (continued)

Resource	Source
Pigeon Point Systems http://www.pigeonpoint.com	
IPM Sentry Shelf-External Interface Reference	Pigeon Point Systems
IPM Sentry Shelf Manager User Guide	Pigeon Point Systems
OpenIPMI http://openipmi.sourceforge.net/	



Artesyn Embedded Technologies, Artesyn and the Artesyn Embedded Technologies logo are trademarks and service marks of Artesyn Embedded Technologies, Inc. All other product or service names are the property of their respective owners.

© 2014 Artesyn Embedded Technologies, Inc.